

Smarter. Greener. Together.

Industrial Automation Headquarters

Delta Electronics, Inc.

Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan City, Taoyuan County 33068, Taiwan TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Jiangsu) Ltd.

Wujiang Plant 3
1688 Jiangxing East Road,
Wujiang Economic Development Zone
Wujiang City, Jiang Su Province,
People's Republic of China (Post code: 215200)
TEL: 86-512-6340-3008 / FAX: 86-769-6340-7290

Delta Greentech (China) Co., Ltd.

238 Min-Xia Road, Pudong District, ShangHai, P.R.C. Post code: 201209 TEL: 86-21-58635678 / FAX: 86-21-58630003

Delta Electronics (Japan), Inc.

Tokyo Office 2-1-14 Minato-ku Shibadaimon, Tokyo 105-0012, Japan TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

Delta Electronics (Korea), Inc.

1511, Byucksan Digital Valley 6-cha, Gasan-dong, Geumcheon-gu, Seoul, Korea, 153-704 TEL: 82-2-515-5303 / FAX: 82-2-515-5302

Delta Electronics Int'l (S) Pte Ltd

4 Kaki Bukit Ave 1, #05-05, Singapore 417939 TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No 43 Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India TEL: 91-124-4874900 / FAX: 91-124-4874945

Americas

Delta Products Corporation (USA)

Raleigh Office P.O. Box 12173,5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: 1-919-767-3800 / FAX: 1-919-767-8080

Delta Greentech (Brasil) S.A

Sao Paulo Office

Rua Itapeva, 26 - 3° andar Edificio Itapeva One-Bela Vista 01332-000-São Paulo-SP-Brazil TEL: +55 11 3568-3855 / FAX: +55 11 3568-3865

Europe

Delta Electronics (Netherlands) B.V.

Eindhoven Office

De Witbogt 20, 5652 AG Eindhoven, The Netherlands TEL: 31-40-2592850 / FAX: 31-40-2592851

*We reserve the right to change the information in this catalogue without prior notice.







Delta Sensorless Vector Control Compact Drive VFD-E Series User Manual



www.deltaww.com



VFD-E Manual_20151130.indd 1 2015/11/30 下午 03:33:55

Delta

Sensoriess

Compact

VFD-E

Thank you for choosing DELTA's high-performance VFD-E Series. The VFD-E Series is manufactured with high-quality components and materials and incorporate the latest microprocessor technology available.

This manual is to be used for the installation, parameter setting, troubleshooting, and daily maintenance of the AC motor drive. To guarantee safe operation of the equipment, read the following safety guidelines before connecting power to the AC motor drive. Keep this operating manual at hand and distribute to all users for reference.

To ensure the safety of operators and equipment, only qualified personnel familiar with AC motor drive are to do installation, start-up and maintenance. Always read this manual thoroughly before using VFD-E series AC Motor Drive, especially the WARNING, DANGER and CAUTION notes. Failure to comply may result in personal injury and equipment damage. If you have any questions, please contact your dealer.

For Drive Board version 1.20 & Control Board version 2.20.

PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



- 1. AC input power must be disconnected before any wiring to the AC motor drive is made.
- A charge may still remain in the DC-link capacitors with hazardous voltages, even if the power
 has been turned off. To prevent personal injury, please ensure that power has turned off before
 opening the AC motor drive and wait ten minutes for the capacitors to discharge to safe voltage
 levels.
- 3. Never reassemble internal components or wiring.
- 4. The AC motor drive may be destroyed beyond repair if incorrect cables are connected to the input/output terminals. Never connect the AC motor drive output terminals U/T1, V/T2, and W/T3 directly to the AC mains circuit power supply.
- 5. Ground the VFD-E using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed. Refer to the Basic Wiring Diagram.
- 6. VFD-E series is used only to control variable speed of 3-phase induction motors, NOT for 1-phase motors or other purpose.
- 7. VFD-E series shall NOT be used for life support equipment or any life safety situation.



- 1. DO NOT use Hi-pot test for internal components. The semi-conductor used in AC motor drive easily damage by high-voltage.
- 2. There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. To prevent damage to these components, do not touch these components or the circuit boards with metal objects or your bare hands.
- 3. Only qualified persons are allowed to install, wire and maintain AC motor drives.



- 1. Some parameters settings can cause the motor to run immediately after applying power.
- 2. DO NOT install the AC motor drive in a place subjected to high temperature, direct sunlight, high humidity, excessive vibration, corrosive gases or liquids, or airborne dust or metallic particles.
- 3. Only use AC motor drives within specification. Failure to comply may result in fire, explosion or electric shock.
- 4. To prevent personal injury, please keep children and unqualified people away from the equipment.
- 5. When the motor cable between AC motor drive and motor is too long, the layer insulation of the motor may be damaged. Please use a frequency inverter duty motor or add an AC output reactor to prevent damage to the motor. Refer to appendix B Reactor for details.
- 6. The rated voltage for AC motor drive must be \leq 240V (\leq 480V for 460V models) and the short circuit must be \leq 5000A RMS (\leq 10000A RMS for the \geq 40hp (30kW) models).

DeviceNet is a registered trademark of the Open DeviceNet Vendor Association, Inc. Lonwork is a registered trademark of Echelon Corporation. Profibus is a registered trademark of Profibus International. CANopen is a registered trademark of CAN in Automation (CiA). Other trademarks belong to their respective owners.

Chapt	er 1 Introduction
1.1	Receiving and Inspection1-2
1.2	Preparation for Installation and Wiring1-11
1.3	Dimensions1-17
Chapt	er 2 Installation and Wiring
2.1	Wiring2-3
2.2	External Wiring2-13
2.3	Main Circuit2-14
2.4	Control Terminals2-19
Chapt	er 3 Keypad and Start up
3.1	Keypad3-1
3.2	Operation Method3-2
3.3	Trial Run
Chapt	er 4 Parameters
4.1	Summary of Parameter Settings4-2
4.2	Parameter Settings for Applications4-37
4.3	Description of Parameter Settings4-42
4.4	Different Parameters for VFD*E*C Models4-172
Chapt	er 5 Troubleshooting
5.1	Over Current (OC)5-1
5.2	Ground Fault5-2
5.3	Over Voltage (OV)5-2
5.4	Low Voltage (Lv)5-3

	5.5 Over Heat (OH)	5-4
	5.6 Overload	5-4
	5.7 Keypad Display is Abnormal	5-5
	5.8 Phase Loss (PHL)	5-5
	5.9 Motor cannot Run	5-6
	5.10 Motor Speed cannot be Changed	5-7
	5.11 Motor Stalls during Acceleration	5-8
	5.12 The Motor does not Run as Expected	5-8
	5.13 Electromagnetic/Induction Noise	5-9
	5.14 Environmental Condition	5-9
	5.15 Affecting Other Machines	5-10
CI	hapter 6 Fault Code Information and Maintenance	
	6.1 Fault Code Information	6-1
	6.2 Maintenance and Inspections	6-7
Α _Ι	ppendix A Specifications	A-1
Α _Ι	ppendix B Accessories	
	B.1 All Brake Resistors & Brake Units Used in AC Motor Drives	B-1
	B.2 No-fuse Circuit Breaker Chart	B-7
	B.3 AC Reactor	B-8
	B.4 Remote Controller RC-01	B-12
	B.5 PU06	B-13
	B.6 KPE-LE02	B-16
	B.7 Extension Card	B-20
	B.8 Fieldbus Modules	B-30
	B.9 DIN Rail	B-42

B.10 EMI Filter	B-44
B.11 Fan Kit	B-47
B.12 KPC-CC01 keypad	B-48
Appendix C How to Select the Rights AC Motor Drive	
C.1 Capacity Formulas	C-2
C.2 General Precaution	C-4
C.3 How to Choose a Suitable Motor	
Appendix D How to Use PLC Function	
D.1 PLC Overview	D-1
D.2 Start-up	D-2
D.3 Ladder Diagram	D-7
D.4 PLC Devices	D-20
D.5 Commands	D-32
D.6 Error Code	D-67
Appendix E CANopen Function	
E.1 Overview	E-2
E.2 CANopen Communication Interface Description	E-21
Appendix F Suggestions and Error Corrections for Standar	
Drives F.1 Maintenance and Inspections	F-2
F.2 Greasy Dirt Problem	F-6
F.3 Fiber Dust Problem	F-7
F.4 Erosion Problem	F-8
F.5 Industrial Dust Problem	F-9
F.6 Wiring and Installation Problem	F-10
F.7 Multi-function Input/Output Terminals Problem	F-11

Chapter 1 Introduction

The AC motor drive should be kept in the shipping carton or crate before installation. In order to retain the warranty coverage, the AC motor drive should be stored properly when it is not to be used for an extended period of time. Storage conditions are:



- 1. Store in a clean and dry location free from direct sunlight or corrosive fumes.
- 2. Store within an ambient temperature range of -20 °C to +60 °C.
- 3. Store within a relative humidity range of 0% to 90% and non-condensing environment.
- 4. Store within an air pressure range of 86 kPA to 106kPA.
- 5. DO NOT place on the ground directly. It should be stored properly. Moreover, if the surrounding environment is humid, you should put exsiccator in the package.
- 6. DO NOT store in an area with rapid changes in temperature. It may cause condensation and frost.
- 7. If the AC motor drive is used but did not use more than three months, the temperature should not be higher than 30 °C. Storage longer than one year is not recommended, it could result in the degradation of the electrolytic capacitors.
- 8. When the AC motor drive is not used for longer time after installation on building sites or places with humidity and dust, it's best to move the AC motor drive to an environment as stated above.
- 9. If the electrolytic capacitors do not energize for a long time, its performance will decline. Therefore, the unused drive must be charged 3 ~4 hours every two years (*) to recover the performance of internal electrolytic capacitor of drive.

*Note: It need to use the adjustable AC power source when the inverter power transmission (eg.: AC autotransformer) and pressurize to the rated voltage gradually, do not do the power transmission by using rated voltage directly.


1.1 Receiving and Inspection

This VFD-E AC motor drive has gone through rigorous quality control tests at the factory before shipment. After receiving the AC motor drive, please check for the following:


- Check to make sure that the package includes an AC motor drive, the User Manual/Quick Start and CD.
- Inspect the unit to assure it was not damaged during shipment.
- Make sure that the part number indicated on the nameplate corresponds with the part number of your order.

1.1.1 Nameplate Information


Example for 1HP/0.75kW 3-phase 230V AC motor drive



1.1.2 Model Explanation



1.1.3 Series Number Explanation



If the nameplate information does not correspond to your purchase order or if there are any problems, please contact your distributor.

1.1.4 Drive Frames and Appearances

0.25-2HP/0.2-1.5kW (Frame A)

VFD002E11A/21A/23A,

VFD004E11A/21A/23A/43A,

VFD007E21A/23A/43A,

VFD015E23A/43A,

VFD002E11C/21C/23C,

VFD004E11C/21C/23C/43C,

VFD007E21C/23C/43C, VFD015E23C/43C,

VFD002E11T/21T/23T,


VFD004E11T/21T/23T/43T,

VFD007E21T/23T/43T, VFD015E23T/43T,

VFD002E11P/21P/23P,


VFD004E11P/21P/23P/43P,

VFD007E21P/23P/43P, VFD015E23P/43P



1-5HP/0.75-3.7kW (Frame B)

VFD007E11A, VFD015E21A, VFD022E21A/23A/43A, VFD037E23A/43A, VFD007E11C, VFD015E21C, VFD022E21C/23C/43C, VFD037E23C/43C,



7.5-15HP/5.5-11kW (Frame C)

VFD055E23A/43A.


VFD075E23A/43A.

VFD055E23C/43C,

VFD075E23C/43C.

VFD110E23A/23C.

VFD110E43A/43C,




20-30HP/15-22kW (Frame D)

VFD150E23A/23C;


VFD150E43A/43C;

VFD185E43A/43C:

VFD220E43A/43C:



Internal Structure




- ♠ READY: power indicator
 - RUN: status indicator
 - FAULT: fault indicator
- 1. Switch to ON for 50Hz, refer to P 01.00 to P01.02 for details
 - 2. Switch to ON for free run to stop refer to P02.02
 - 3. Switch to ON for setting frequency source to ACI (P 02.00=2)
- Keypad mounting port
- ACI terminal (ACI/AVI2 switch)
- NPN/PNP
- Mounting port for extension card
- **©** RS485 port (RJ-45)




The LED "READY" will light up after applying power. The light won't be off until the capacitors are discharged to safe voltage levels after power off.

RFI Jumper Location

Frame A: near the output terminals (U/T1, V/T2, W/T3)





Frame B: above the nameplate




Frame C (230V): near the input terminals (R/L1, S/L2, T/L3)

Frame C (460V): near the input terminals (R/L1, S/L2, T/L3)





Frame D: near the input terminals (R/L1, S/L2, T/L3), under terminal R/L1.



Main power isolated from earth:

If the AC motor drive is supplied from an isolated power (IT power), the RFI jumper must be cut off. Then the RFI capacities (filter capacitors) will be disconnected from ground to prevent circuit damage

(according to IEC 61800-3) and reduce earth leakage current.



- 1. After applying power to the AC motor drive, do not cut off the RFI jumper. Therefore, make sure that main power has been switched off before cutting the RFI jumper.
- 2. The gap discharge may occur when the transient voltage is higher than 1,000V. Besides, electromagnetic compatibility of the AC motor drives will be lower after cutting the RFI jumper.
- 3. Do NOT cut the RFI jumper when main power is connected to earth.
- 4. The RFI jumper cannot be cut when Hi-pot tests are performed. The mains power and motor must be separated if high voltage test is performed and the leakage currents are too high.
- 5. To prevent drive damage, the RFI jumper connected to ground shall be cut off if the AC motor drive is installed on an ungrounded power system or a high resistance-grounded(over 30 ohms) power system or a corner grounded TN system.

Frame	Power range	Models
		VFD002E11A/11C/11T/11P; VFD002E21A/21C/21T/21P; VFD002E23A/23C/23T/23P;
Α	0.25-2hp (0.2-1.5kW)	VFD004E11A/11C/11T/11P; VFD004E21A/21C/21T/21P; VFD004E23A/23C/23T/23P; VFD004E43A/43C/43T/43P; VFD007E21A/21C/21T/21P; VFD007E23A/23C/23T/23P; VFD007E43A/43C/43T/43P;
		VFD015E23A/23C/23T/23P; VFD015E43A/43C/43T/43P;
	1-5hp	VFD007E11A/11C; VFD015E21A/21C;
В	(0.75-3.7kW)	VFD022E21A/21C; VFD022E23A/23C; VFD022E43A/43C; VFD037E23A/23C; VFD037E43A/43C;
С	7.5-15hp (5.5-11kW)	VFD055E43A/43C; VFD075E43A/43C; VFD110E43A/43C;
D	20-30hp (15-22kW)	VFD150E23A/23C; VFD150E43A43C; VFD185E43A/43C; VFD220E43A/43C;

Note: Frame C VFD055E23A/23C; VFD075E23A/23C; VFD110E23A/23C; do not provide RFI functions.

1.1.5 Remove Instructions

Remove Keypad

Press and hold in the latch on each side of cover then pull the cover up to release.



Remove RST Terminal Cover

For Frame B, C and D: it only needs to turn the cover lightly to open it.

For Frame A, it doesn't have cover and can be wired directly.



Remove UVW Terminal Cover


For Frame B, C and D: it only needs to turn the cover lightly to open it.

For Frame A, it doesn't have cover and can be wired directly.





Remove Front Cover

Press the control board terminal cover first as shown in Figure A, then slide downwards as shown in Figure B, you can easily remove it.



Remove Cooling Fan





Remove Extension Card

For Frame A, Frame B, Frame C and Frame D

Loosen the screws first then press and hold in the latches on each side of the extension card and pull the extension card up to release. On the other hand, it can install the extension card into the AC motor drive with screws.



1.2 Preparation for Installation and Wiring

1.2.1 Ambient Conditions

Install the AC motor drive in an environment with the following conditions:

motan the Ac	inotor arive in an e	invironment with the following conditions.
	Air Temperature:	-10 ~ +50°C (14 ~ 122°F) for UL & cUL -10 ~ +40°C (14 ~ 104°F) for side-by-side mounting
	Relative Humidity:	<90%, no condensation allowed
Operation	Atmosphere pressure:	86 ~ 106 kPa
Operation	Installation Site Altitude:	<1000m
		10Hz≦f≦57Hz, Fix Amplitude: 0.075mm
	Vibration:	57Hz≦f≦150Hz, fix Acceleration: 1G
		(According to IEC 60068-2-6)
	Temperature:	-20°C ~ +60°C (-4°F ~ 140°F)
Storage	Relative Humidity:	<90%, no condensation allowed
Transportation	Atmosphere pressure:	86 ~ 106 kPa
	Vibration:	According to ISTA Procedure 1A
Pollution Degree	2: good for a factory	type environment.

Frame A Mounting Clearances


Single drive

Side-by-side installation


120mm


120mm


120mm




Frame B, C and D Mounting Clearances








For VFD-E-P series: heat sink system example





- Operating, storing or transporting the AC motor drive outside these conditions may cause damage to the AC motor drive.
- 2. Failure to observe these precautions may void the warranty!
- 3. Mount the AC motor drive vertically on a flat vertical surface object by screws. Other directions are not allowed.
- 4. The AC motor drive will generate heat during operation. Allow sufficient space around the unit for heat dissipation.
- 5. The heat sink temperature may rise to 90°C when running. The material on which the AC motor drive is mounted must be noncombustible and be able to withstand this high temperature.
- 6. When AC motor drive is installed in a confined space (e.g. cabinet), the surrounding temperature must be within 10 ~ 40°C with good ventilation. DO NOT install the AC motor drive in a space with bad ventilation.
- 7. Prevent fiber particles, scraps of paper, saw dust, metal particles, etc. from adhering to the heatsink.
- 8. When installing multiple AC more drives in the same cabinet, they should be adjacent in a row with enough space in-between. When installing one AC motor drive below another one, use a metal separation between the AC motor drives to prevent mutual heating.

Installation with Metal Separation Installation without Metal Separation 120mm ↓ 150mm ↓ 120mm 150mm 150mm 🗸 120mm Air flow 120mm 150mm Frame B, C and D Frame A



1φ/110V		
Model	Total Power Dissipation (W)	Flow rate (CFM)
VFD002E11A/C/T	22	Natural Convection
VFD004E11A/C/T	33	Natural Convection
VFD007E11A	54	14
VFD002E11P	22	-
VFD004E11P	33	-
1φ/230V		
Model	Total Power Dissipation (W)	Flow rate (CFM)
VFD002E21A/C/T	22	Natural Convection
VFD004E21A/C/T	34	Natural Convection
VFD007E21A/C/T	57	Natural Convection
VFD015E21A/C	97	14
VFD022E21A/C	142	14
VFD002E21P	22	-
VFD004E21P	34	-
VFD007E21P	57	-
3φ/230V		
Model	Total Power Dissipation (W)	Flow rate (CFM)
VFD002E23 A/C/T	19	Natural Convection
VFD004E23 A/C/T	29	Natural Convection
VFD007E23 A/C/T	49	Natural Convection
VFD015E23 A/C/T	87	14

VFD022E23A/C	117	14
VFD037E23A/C	182	14
VFD055E23A/C	265	36
VFD075E23A/C	352	36
VFD110E23A/C	480	36
VFD150E23A/C	695	72
VFD002E23P	19	-
VFD004E23P	29	-
VFD007E23P	49	-
VFD015E23P	87	-
3φ/480V		
Model	Total Power Dissipation (W)	Flow rate (CFM)
\/FD004E42A/C/T	30	Natural Convection
VFD004E43A/C/T	30	Natural Convection
VFD004E43A/C/T	51	Natural Convection
VFD007E43A/C/T	51	Natural Convection
VFD007E43A/C/T VFD015E43A/C/T	51 84	Natural Convection 14
VFD007E43A/C/T VFD015E43A/C/T VFD022E43A/C	51 84 100	Natural Convection 14 14
VFD007E43A/C/T VFD015E43A/C/T VFD022E43A/C VFD037E43A/C	51 84 100 155	Natural Convection 14 14 14
VFD007E43A/C/T VFD015E43A/C/T VFD022E43A/C VFD037E43A/C VFD055E43A/C	51 84 100 155 235	Natural Convection 14 14 14 14 36
VFD007E43A/C/T VFD015E43A/C/T VFD022E43A/C VFD037E43A/C VFD055E43A/C VFD075E43A/C	51 84 100 155 235 327	Natural Convection 14 14 14 36 36
VFD007E43A/C/T VFD015E43A/C/T VFD022E43A/C VFD037E43A/C VFD055E43A/C VFD075E43A/C VFD110E43 A/C	51 84 100 155 235 327 436	Natural Convection 14 14 14 36 36 36
VFD007E43A/C/T VFD015E43A/C/T VFD022E43A/C VFD037E43A/C VFD055E43A/C VFD075E43A/C VFD110E43 A/C VFD150E43 A/C	51 84 100 155 235 327 436 538	Natural Convection 14 14 14 36 36 36 38 88
VFD007E43A/C/T VFD015E43A/C/T VFD022E43A/C VFD037E43A/C VFD055E43A/C VFD075E43A/C VFD110E43 A/C VFD150E43 A/C VFD185E43 A/C	51 84 100 155 235 327 436 538 570	Natural Convection 14 14 14 36 36 36 38 88
VFD007E43A/C/T VFD015E43A/C/T VFD022E43A/C VFD037E43A/C VFD055E43A/C VFD075E43A/C VFD110E43 A/C VFD150E43 A/C VFD185E43 A/C VFD220E43 A/C	51 84 100 155 235 327 436 538 570 676	Natural Convection 14 14 14 36 36 36 38 88 88


84

VFD015E43P

1.2.2 DC-bus Sharing: Connecting the DC-bus of the AC Motor Drives in Parallel

- 1. This function is not for VFD-E-T series.
- 2. The AC motor drives can absorb mutual voltage that generated to DC bus when deceleration.
- 3. Enhance brake function and stabilize the voltage of the DC bus.
- 4. The brake module can be added to enhance brake function after connecting in parallel.
- 5. Only the same power system and capacity can be connected in parallel.
- 6. It is recommended to connect 5 AC motor drives in parallel (no limit in horsepower but these 5 drives should be the same power system and capacity).

power should be applied at the same time (only the same power system and capacity can be connected in parallel) Power 208/220/230/380/440/480 (depend on models)





For frame A, terminal + (-) is connected to the terminal + (-) of the brake module. For frame B, C and D, terminal +/B1 (-) is connected to the terminal + (-) of the brake module.


1.3 Dimensions


Frame A

VFD002E11A/11C/11T; VFD002E21A/21C/21T; VFD002E23A/23C/23T; VFD004E11A/11C/11T; VFD004E21A/21C/21T; VFD004E23A/23C/23T; VFD004E43A/43C/43T; VFD007E21A/21C/21T; VFD007E23A/23C/23T; VFD007E43A/43C/43T;













Frame	W	W1	Н	H1	D	D1	D2	S1	S2
A1	72.0	60.0	142.0	120.0	152.0	50.0	4.5	5.2	5.2
AI	[2.83]	[2.36]	[5.59]	[4.72]	[5.98]	[1.97]	[0.18]	[0.20]	[0.20]

Frame A VFD015E23A/23C/23T; VFD015E43A/43C/43T;













Frame	W	W1	Н	H1	D	D1	D2	S1	S2
40	72.0	60.0	142.0	120.0	152.0	50.0	4.5	5.2	5.2
A2	[2.83]	[2.36]	[5.59]	[4.72]	[5.98]	[1.97]	[0.18]	[0.20]	[0.20]

Frame A VFD002E11P/21P/23P; VFD004E11P/21P/23P/43P; VFD007E21P/23P/43P; VFD015E23P/43P;












Frame	W	W1	Ι	H1	D	D1	S1
۸۵	72.0	56.0	155.0	143.0	111.5	9.5	5.3
A3	[2.83]	[2.20]	[6.10]	[5.63]	[4.39]	[0.37]	[0.21]

Frame B
VFD007E11A/11C; VFD015E21A/21C; VFD022E21A/21C; VFD022E23A/23C; VFD022E43A/43C; VFD037E23A/23C; VFD037E43A/43C;













Frame	W	W1	Н	H1	D	D1	D2	S1	S2
В	100.0	89.0	174.0	162.0	152.0	50.0	4.0	5.5	5.5
D	[3.94]	[3.50]	[6.86]	[6.38]	[5.98]	[1.97]	[0.16]	[0.22]	[0.22]













Frame	W	W1	Н	H1	D	D1	D2	S1	S2
	130.0	116.0	260.0	246.5	169.2	78.5	8.0	6.5	5.5
	[5.12]	[4.57]	[10.24]	[9.70]	[6.66]	[3.09]	[0.31]	[0.26]	[0.22]

Frame D VFD150E23A/23C; VFD150E43A43C; VFD185E43A/43C; VFD220E43A/43C;









Unit: mm [inch]

Frame	W	W1	Н	H1	D	D1	D2	S1	S2
D	200.0	180.0	310.0	290.0	190.0	92.0	10.0	10.0	9.0
	[7.87]	[7.09]	[12.20]	[11.42]	[7.48]	[3.62]	[0.39]	[0.39]	[0.35]

Chapter 2 Installation & Wiring

After removing the front cover, check if the power and control terminals are clear. Be sure to observe the following precautions when wiring.

General Wiring Information

Applicable Codes

All VFD-E series are Underwriters Laboratories, Inc. (UL) and Canadian Underwriters Laboratories (cUL) listed, and therefore comply with the requirements of the National Electrical Code (NEC) and the Canadian Electrical Code (CEC).

Installation intended to meet the UL and cUL requirements must follow the instructions provided in "Wiring Notes" as a minimum standard. Follow all local codes that exceed UL and cUL requirements. Refer to the technical data label affixed to the AC motor drive and the motor nameplate for electrical data.

The "Line Fuse Specification" in Appendix B, lists the recommended fuse part number for each VFD-E Series part number. These fuses (or equivalent) must be used on all installations where compliance with U.L. standards is a required.



- Make sure that power is only applied to the R/L1, S/L2, T/L3 terminals. Failure to comply may
 result in damage to the equipment. The voltage and current should lie within the range as
 indicated on the nameplate.
- 2. All the units must be grounded directly to a common ground terminal to prevent lightning strike or electric shock.
- 3. Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration.
- 4. Check following items after finishing the wiring:
 - A. Are all connections correct?
 - B. No loose wires?
 - C. No short-circuits between terminals or to ground?



- A charge may still remain in the DC bus capacitors with hazardous voltages even if the power
 has been turned off. To prevent personal injury, please ensure that the power is turned off and
 wait ten minutes for the capacitors to discharge to safe voltage levels before opening the AC
 motor drive.
- 2. Only qualified personnel familiar with AC motor drives is allowed to perform installation, wiring and commissioning.
- 3. Make sure that the power is off before doing any wiring to prevent electric shock.

2.1 Wiring

Users must connect wires according to the circuit diagrams on the following pages. Do not plug a modem or telephone line to the RS-485 communication port or permanent damage may result. The pins 1 & 2 are the power supply for the optional copy keypad only and should not be used for RS-485 communication.

Figure 1 for models of VFD-E Series VFD002E11A/21A, VFD004E11A/21A, VFD007E21A, VFD002E11C/21C, VFD004E11C/21C, VFD007E21C, VFD002E11P/21P, VFD004E11P/21P, VFD007E21P





Figure 2 for models of VFD-E Series VFD002E23A, VFD004E23A/43A, VFD007E23A/43A, VFD015E23A/43A, VFD002E23C, VFD004E23C/43C, VFD007E23C/43C, VFD0015E23C/43C, VFD002E23P, VFD004E23P/43P, VFD007E23P/43P









Figure 4 for models of VFD-E Series

VFD022E23A/43A, VFD037E23A/43A, VFD055E23A/43A, VFD075E23A/43A, VFD110E23A/43A, VFD022E23C/43C, VFD037E23C/43C, VFD055E23C/43C, VFD075E23C/43C, VFD150E23A/23C, VFD150E43A/43C, VFD185E43A/43C, VFD220E43A/43C






NOTE For VFD-E-Tseries, the braking resistor can be used by connecting terminals (B1 and B2) directly. But it can't connect DC-BUS in parallel.




NOTE For VFD-E-T series, the braking resistor can be used by connecting terminals (B1 and B2) directly. But it can't connect DC-BUS in parallel.


Figure 7 Wiring for NPN mode and PNP mode A. NPN mode without external power



B. NPN mode with external power



C. PNP mode without external power



D. PNP mode with external power




Figure 8 Pin definition for VFD*E*C CANopen models (Note: CANopen models can't use PU06)

PIN	Signal	Description
1	CAN_H	CAN_H bus line (dominant high)
2	CAN_L	CAN_L bus line (dominant low)
3	CAN_GND	Ground / 0V /V-
4	SG-	485 communication
5	SG+	485 communication
6	GND	Ground
7	CAN_GND	Ground / 0V /V-
8	EV	Power




- 1. The wiring of main circuit and control circuit should be separated to prevent erroneous actions.
- 2. Please use shield wire for the control wiring and not to expose the peeled-off net in front of the terminal.
- 3. Please use the shield wire or tube for the power wiring and ground the two ends of the shield wire or tube.
- 4. Damaged insulation of wiring may cause personal injury or damage to circuits/equipment if it comes in contact with high voltage.
- 5. The AC motor drive, motor and wiring may cause interference. To prevent the equipment


Chapter 2 Installation & Wiring |

- damage, please take care of the erroneous actions of the surrounding sensors and the equipment.
- 6. When the AC drive output terminals U/T1, V/T2, and W/T3 are connected to the motor terminals U/T1, V/T2, and W/T3, respectively. To permanently reverse the direction of motor rotation, switch over any of the two motor leads.
- 7. With long motor cables, high capacitive switching current peaks can cause over-current, high leakage current or lower current readout accuracy. To prevent this, the motor cable should be less than 20m for 3.7kW models and below. And the cable should be less than 50m for 5.5kW models and above. For longer motor cables use an AC output reactor.
- 8. The AC motor drive, electric welding machine and the greater horsepower motor should be grounded separately.
- 9. Use ground leads that comply with local regulations and keep them as short as possible.
- 10. No brake resistor is built in the VFD-E series, it can install brake resistor for those occasions that use higher load inertia or frequent start/stop. Refer to Appendix B for details.

11. Multiple VFD-E units can be installed in one location. All the units should be grounded directly to a common ground terminal, as shown in the figure below. Ensure there are no ground loops.



2.2 External Wiring



Items	Explanations	
Power supply	Please follow the specific power supply requirements shown in Appendix A.	
Fuse/NFB (Optional)	There may be an inrush current during power up. Please check the chart of Appendix B and select the correct fuse with rated current. Use of an NFB is optional.	
Magnetic contactor (Optional)	Please do not use a Magnetic contactor as the I/O switch of the AC motor drive, as it will reduce the operating life cycle of the AC drive.	
Input AC Line Reactor (Optional)	Used to improve the input power factor, to reduce harmonics and provide protection from AC line disturbances _₹ (surges, switching spikes, short interruptions, etc.). AC line reactor should be installed when the power supply capacity is 500kVA or more or advanced capacity is activated .The wiring distance should be ≤ 10m. Refer to appendix B for details.	
Zero-phase Reactor (Ferrite Core Common Choke) (Optional)	Zero phase reactors are used to reduce radio noise especially when audio equipment is installed near the inverter. Effective for noise reduction on both the input and output sides. Attenuation quality is good for a wide range from AM band to 10MHz. Appendix B specifies the zero phase reactor. (RF220X00A)	
EMI filter	To reduce electromagnetic interference.	
Brake resistor and Brake unit (Optional)	Used to reduce the deceleration time of the motor. Please refer to the chart in Appendix B for specific Brake resistors.	
Output AC Line Reactor (Optional)	Motor surge voltage amplitude depends on motor cable length. For applications with long motor cable (>20m), it is necessary to install a	

2.3 Main Circuit

2.3.1 Main Circuit Connection

Figure 1

For frame A: VFD002E11A/21A/23A, VFD004E11A/21A/23A/43A, VFD007E21A/23A/43A, VFD002E11C/21C/23C, VFD004E11C/21C/23C/43C, VFD007E21C/23C/43C, VFD002E11P/21P/23P, VFD004E11P/21P/23P/43P, VFD007E21P, VFD015E23A/43A /23P /43P




Figure 2
For frame B: VFD007E11A, VFD015E21A, VFD022E21A/23A/43A, VFD037E23A/43A, VFD007E11C, VFD015E21C, VFD022E21C/23C/43C, VFD037E23C/43C

For frame C: VFD055E23A/43A, VFD075E23A/43A, VFD110E23A/43A, VFD055E23C/43C, VFD075E23C/43C, VFD110E23C/43C

For frame D: VFD150E23A/23C, VFD150E43A/43C, VFD185E43A/43C, VFD220E43A/43C Brake Resistor(Optional)





Figure 3
For Frame A: VFD002E11T/21T/23T, VFD004E11T/21T/23T/43T, VFD007E21T/23T/43T, VFD015E23T/43T



Terminal Symbol	Explanation of Terminal Function		
R/L1, S/L2, T/L3	AC line input terminals (1-phase/3-phase)		
U/T1, V/T2, W/T3	AC drive output terminals for connecting 3-phase induction motor		
+/B1~ B2	Connections for Brake resistor (optional)		
+/B1, -	Connections for External Brake unit (BUE series)		
-	Earth connection, please comply with local regulations.		




Mains power terminals (R/L1, S/L2, T/L3)

- Connect these terminals (R/L1, S/L2, T/L3) via a no-fuse breaker or earth leakage breaker to 3-phase AC power (some models to 1-phase AC power) for circuit protection. It is unnecessary to consider phase-sequence.
- It is recommended to add a magnetic contactor (MC) in the power input wiring to cut off power quickly and reduce malfunction when activating the protection function of AC motor drives. Both ends of the MC should have an R-C surge absorber.
- Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration.
- Please use voltage and current within the regulation shown in Appendix A.
- When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200mA or above, and not less than 0.1-second operation time to avoid nuisance tripping. For the specific GFCI of the AC motor drive, please select a current sensor with sensitivity of 30mA or above.
- Do NOT run/stop AC motor drives by turning the power ON/OFF. Run/stop AC motor drives by RUN/STOP command via control terminals or keypad. If you still need to run/stop AC drives by turning power ON/OFF, it is recommended to do so only ONCE per hour.
- Do NOT connect 3-phase models to a 1-phase power source.

Output terminals for main circuit (U, V, W)

- The factory setting of the operation direction is forward running. The methods to control the operation direction are: method 1, set by the communication parameters. Please refer to the group 9 for details. Method2, control by the optional keypad KPE-LE02. Refer to Appendix B for details.
- When it needs to install the filter at the output side of terminals U/T1, V/T2, W/T3 on the AC motor drive. Please use inductance filter. Do not use phase-compensation capacitors or L-C (Inductance-Capacitance) or R-C (Resistance-Capacitance), unless approved by Delta.
- DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives.
- Use well-insulated motor, suitable for inverter operation.

Terminals [+/B1, B2] for connecting brake resistor




- Connect a brake resistor or brake unit in applications with frequent deceleration ramps, short deceleration time, too low brake torque or requiring increased brake torque.
- If the AC motor drive has a built-in brake chopper (frame B, frame C and VFDxxxExxT models), connect the external brake resistor to the terminals [+/B1, B2] or [B1, B2].
- Models of frame A don't have a built-in brake chopper. Please connect an external optional brake unit (BUE-series) and brake resistor. Refer to BUE series user manual for details.
- Connect the terminals [+(P), -(N)] of the brake unit to the AC motor drive terminals [+/B1,]. The length of wiring should be less than 5m with cable.
- When not used, please leave the terminals [+/B1, -] open.



Short-circuiting [B2] or [-] to [+/B1] can damage the AC motor drive.

2.3.2 Main Circuit Terminals

Frame A




Main circuit terminals:


R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, (, +, -

Models	Wire	Torque	Wire Type
VFD002E11A/11C/11T/11P; VFD002E21A/21C/21T/21P; VFD002E23A/23C/23T/23P; VFD004E11A/11C/11T/11P; VFD004E21A/21C/21T/21P; VFD004E23A/23C/23T/23P; VFD004E43A/43C/43T/43P; VFD007E23A/23C/23T/23P; VFD007E43A/43C/43T/43P; VFD015E23A/23C/23T/23P; VFD015E43A/43C/43T/43P;	14 AWG. (2.1mm ²)	14kgf-cm (12in-lbf)	Stranded copper only 600V, 75°C or above

Recommend round terminal spec(UL recognized)



Frame B




Main circuit terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, (+/B1, B2, -


Models	Wire (Min.)	Wire (Max.)	Torque	Wire Type
VFD007E11A/11C	10 AWG (5.3mm ²)			
VFD015E21A/21C	12 AWG (3.3mm ²)			
VFD022E21A/21C	10 AWG (5.3mm ²)	_		Stranded
VFD022E23A/23C	12 AWG (3.3mm ²)	10 AWG (5.3mm ²)	18kgf-cm (15.6in-lbf)	copper only 600V, 75°C
VFD022E43A/43C	14 AWG. (2.1mm ²)	(0.011111)	(10.011 101)	or above
VFD037E23A/23C	10 AWG (5.3mm ²)			
VFD037E43A/43C	14 AWG. (2.1mm²)			

Recommend round terminal spec (UL recognized)



Chapter 2 Installation & Wiring |

Frame C




Main circuit terminals:


R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, (+/B1, B2, -

Models	Wire (Min.)	Wire (Max.)	Torque	Wire Type
VFD055E23A/23C	8 AWG (8.4mm ²)			
VFD075E23A/23C	8 AWG (8.4mm ²)			
VFD110E23A/23C	6 AWG (13.3mm ²)	6 AWG	30kgf-cm	Stranded copper only
VFD055E43A/43C	12 AWG (3.3mm ²)	(13.3mm ²)	(26in-lbf)	600V , 75℃ or above
VFD075E43A/43C	10 AWG (5.3mm ²)			or above
VFD110E43A/43C	8 AWG (8.4mm ²)			

Recommend round terminal spec (UL recognized)



Frame D




Main circuit terminals:


R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, , B1, B2, +, -

Models	Wire (Min.)	Wire (Max.)	Torque	Wire Type
VFD150E23A/23C	4 AWG (21.2mm ²)			
VFD150E43A43C	8 AWG (8.4mm ²)	4 AWG	57kgf-cm	Stranded copper only
VFD185E43A/43C	6 AWG (13.3mm ²)	(21.2mm ²)	(49.5in-lbf)	600V , 75℃ or above
VFD220E43A/43C	6 AWG (13.3mm ²)			2. 45010


Recommend round terminal spec (UL recognized)



2.4 Control Terminals



The position of the control terminals



Terminal symbols and functions

Terminal Symbol	Terminal Function	Factory Settings (NPN mode)			
Symbol		ON: Connect to DCM			
MI1	Forward-Stop command	ON: Run in MI1 direction OFF: Stop acc. to Stop Method			
MI2	Reverse-Stop command	ON: Run in MI2 direction OFF: Stop acc. to Stop Method			
MI3	Multi-function Input 3				
MI4	Multi-function Input 4	Refer to Pr.04.05 to Pr.04.08 for programming the Multi-function Inputs.			
MI5	Multi-function Input 5	ON: the activation current is 6mA. OFF: leakage current tolerance is 10 μ A.			
MI6	Multi-function Input 6	$-$ 011. Isakage sarroin tolerance is 10 μ 71.			
+24V	DC Voltage Source	+24VDC, 120mA used for PNP mode.			
DCM	Digital Signal Common	Common for digital inputs and used for NPN mode.			

Chapter 2 Installation & Wiring |

	Chapter 2 Installation & Wiring			
Terminal Symbol	Terminal Function	Factory Settings (NPN mode) ON: Connect to DCM		
RA	Multi-function Relay output (N.O.) a	Resistive Load: 5A(N.O.)/3A(N.C.) 240VAC		
RB	Multi-function Relay output (N.C.) b	5A(N.O.)/3A(N.C.) 24VDC Inductive Load: 1.5A(N.O.)/0.5A(N.C.) 240VAC		
RC	Multi-function Relay common	1.5A(N.O.)/0.5A(N.C.) 24VDC Refer to Pr.03.00 for programming		
MO1	Multi-function Output 1 (Photocoupler)	Maximum 48VDC, 50mA Refer to Pr.03.01 for programming MO1-DCM MO1-DCM MO1 MO1 MO1 MO1 MON MON MON MO		
MCM	Multi-function output common	Common for Multi-function Outputs		
+10V	Potentiometer power supply	+10VDC 3mA		
AVI	Analog voltage Input AVI circuit AVI internal circuit	Impedance: $47kΩ$ Resolution: 10 bits Range: $0 \sim 10VDC =$ $0 \sim Max$. Output Frequency (Pr.01.00) Selection: Pr.02.00, Pr.02.09, Pr.10.00 Set-up: Pr.04.11 \sim Pr.04.14, 04.19 \sim 04.23		
ACM	Analog control signal (common)	Common for AVI, ACI, AFM		
ACI	Analog current Input ACI circuit ACM internal circuit	$\begin{array}{lll} \mbox{Impedance:} & 250\Omega/100 \mbox{k}\Omega \\ \mbox{Resolution:} & 10 \mbox{ bits} \\ \mbox{Range:} & 4 \sim 20 \mbox{mA} = \\ & 0 \sim \mbox{Max. Output Frequency} \\ & (\mbox{Pr.01.00}) \\ \mbox{Selection:} & \mbox{Pr.02.00, Pr.02.09, Pr.10.00} \\ \mbox{Set-up:} & \mbox{Pr.04.15} \sim \mbox{Pr.04.18} \\ \end{array}$		


Chapter 2 Installation & Wiring |

Terminal Symbol	Terminal Function	Factory Settings (NPN mode) ON: Connect to DCM
AFM	Analog output meter ACM circuit AFM 0~10V potentiometer Max. 2mA	$\begin{array}{llllllllllllllllllllllllllllllllllll$

NOTE: Control signal wiring size: 18 AWG (0.75 mm²) with shielded wire.

Analog inputs (AVI, ACI, ACM)

- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (<20m) with proper grounding. If the noise is inductive, connecting the shield to terminal ACM can bring improvement.
- If the analog input signals are affected by noise from the AC motor drive, please connect a capacitor (0.1 μ F and above) and ferrite core as indicated in the following diagrams:



wind each wires 3 times or more around the core

Digital inputs (MI1~MI6, DCM)

When using contacts or switches to control the digital inputs, please use high quality components to avoid contact bounce.

Digital outputs (MO1, MCM)

- Make sure to connect the digital outputs to the right polarity, see wiring diagrams.
- When connecting a relay to the digital outputs, connect a surge absorber or fly-back diode across the coil and check the polarity.


General

- Keep control wiring as far away as possible from the power wiring and in separate conduits to avoid interference. If necessary let them cross only at 90° angle.
- The AC motor drive control wiring should be properly installed and not touch any live power wiring or terminals.



Damaged insulation of wiring may cause personal injury or damage to circuits/equipment if it comes in contact with high voltage.

The specification for the control terminals



The position of the control terminals

	AFM MC	M MO1	
Terminals 2	$\bigcirc \mid \subseteq$		
			RS-485 port
MI1 MI2 MI3 MI4 MI5 MI6 DCM DCM 24V ACM	AVI AC	1 10V	

Frame Control Terminals		Torque	Wire
A B C D	Terminals 1	5 kgf-cm (4.4 in-lbf)	12-24 AWG (3.3-0.2mm ²)
A, B, C, D	Terminals 2	2 kgf-cm (1.7 in-lbf)	16-24 AWG (1.3-0.2mm ²)



Frame A: VFD002E11A/11C/11T/11P; VFD002E21A/21C/21T/21P;

VFD002E23A/23C/23T/23P;VFD004E11A/11C/11T/11P; VFD004E21A/21C/21T/21P; VFD004E23A/23C/23T/23P; VFD004E43A/43C/43T/43P; VFD007E21A/21C/21T/21P; VFD007E23A/23C/23T/23P; VFD007E43A/43C/43T/43P VFD015E23A/23C/23T/23P; VFD015E43A/43C/43T/43P;

Frame B: VFD007E11A/11C, VFD015E21A/21C, VFD022E21A/21C, VFD022E23A/23C,

VFD022E43A/43C, VFD037E23A/23C, VFD037E43A/43C,

Frame C: VFD055E23A/23C, VFD055E43A/43C, VFD075E23A/23C, VFD075E43A/43C,

VFD110E23A/23C, VFD110E43A/43C,

Frame D: VFD150E23A/23C, VFD150E43A/43C, VFD185E43A/43C, VFD220E43A/4



Chapter 3 Keypad and Start Up




- Make sure that the wiring is correct. In particular, check that the output terminals U/T1, V/T2, W/T3, are NOT connected to power and that the drive is well grounded.
- Verify that no other equipment is connected to the AC motor drive
- Do NOT operate the AC motor drive with humid hands.
- Please check if READY LED is ON when power is applied. Check if the connection is well when option from the digital keypad KPE-LE02.



It should be stopped when fault occurs during running and refer to "Fault Code Information and Maintenance" for solution. Please do NOT touch output terminals U, V, W when power is still applied to L1/R, L2/S, L3/T even when the AC motor drive has stopped. The DC-link capacitors may still be charged to hazardous voltage levels, even if the power has been turned off.

3.1 Keypad



There are three LEDs on the keypad:

LED READY: It will light up after applying power. The light won't be off until the capacitors are discharged to safe voltage levels after power off.

LED RUN: It will light up when the motor is running.


LED FAULT: It will light up when fault occurs.



3.2 Operation Method

The operation method can be set via communication, control terminals and optional keypad KPE-LE02.

- A) Connect RS-485 communication port. Use a VFD-USB01 cable or an IFD8500 (IFD6500) communication module to connect your computer to this port.
- B) Control terminals MI~ M6.
- C) Keypad interface





Operation Method	Frequency S	ource	Operation Command Source
Operate from the communication	When setting communication IFD8500 converter to connermal Refer to the communication	ct to the PC.	
Operate from external signal		REV/Stop REV/Stop Multi-step 1 Multi-step 2 Multi-step 4 Digital Signal Commo Ply the mains voltage determinals. SKΩ Analog Signal Commo	DCM External terminals input:
	MI4-DCM (Set Pr.04.06=11)		MI1-DCM MI2-DCM
Operate from the optional keypad (KPE-LE02)		▼	RUN STOP RESET

3.3 Trial Run

The factory setting of the operation source is from the external terminal (Pr.02.01=2).

- 1. Both MI1-DCM and MI2-DCM need to connect a switch for switching FWD/STOP and REV/STOP.
- 2. Please connect a potentiometer among AVI, 10V and DCM or apply power 0-10Vdc to AVI-DCM (as shown in figure 3-1)



- 3. Setting the potentiometer or AVI-DCM 0-10Vdc power to less than 1V.
- 4. Setting MI1=On for forward running. And if you want to change to reverse running, you should set MI2=On. And if you want to decelerate to stop, please set MI1/MI2=Off.
- 5. Check following items:
- Check if the motor direction of rotation is correct.
- Check if the motor runs steadily without abnormal noise and vibration.
- Check if acceleration and deceleration are smooth.

If you want to perform a trial run by using optional digital keypad, please operate by the following steps.


- 1. Connect digital keypad to AC motor drive correctly.
- 2. After applying the power, verify that LED display shows F 0.0Hz.
- 3. Set Pr.02.00=0 and Pr.02.01=0. (Refer to Appendix B operation flow for detail)
- key to set frequency to 4 around 5Hz
- RUN Press 5. key for forward running. And if you want to change to reverse

running, you should press page. And if you want to STOP RESET decelerate to stop, please press

6 Check following items:

key.

- Check if the motor direction of rotation is correct
- Check if the motor runs steadily without abnormal noise and vibration
- Check if acceleration and deceleration are smooth



If the results of trial run are normal, please start the formal run.

The VFD-E parameters are divided into 14 groups by property for easy setting. In most applications, the user can finish all parameter settings before start-up without the need for re-adjustment during operation.

The 14 groups are as follows:

- Group 0: User Parameters
 Group 1: Basic Parameters
- Group 2: Operation Method Parameters
 Group 3: Output Function Parameters
 Group 4: Input Function Parameters
 Group 5: Multi-Step Speed Parameters
- Group 6: Protection Parameters Group 7: Motor Parameters Group 8: Special Parameters
- Group 9: Communication Parameters
 Group 10: PID Control Parameters
- Group 11: Multi-function Input/ Output Parameters for Extension Card
- Group 12: Analog Input/ Output Parameters for Extension Card
- Group 13: PG function Parameters for Extension Card

4.1 Summary of Parameter Settings

★: The parameter can be set during operation.

Group 0 User Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
00.00	Identity Code of the AC motor drive	Read-only	##	
00.01	Rated Current Display of the AC motor drive	Read-only	#.#	
		0: Parameter can be read/written		
		1: All parameters are read only		
		6: Clear PLC program (NOT for VFD*E*C models)		
00.02	Parameter Reset	8: keypad lock	0	
		9: All parameters are reset to factory settings (50Hz, 230V/400V or 220V/380V depends on Pr.00.12)		
		10: All parameters are reset to factory settings (60Hz, 220V/440V)		
		0: Display the frequency command value (Fxxx)		
		1: Display the actual output frequency (Hxxx)		
№ 00.03	Start-up Display	2: Display the content of user-defined unit (Axxx)	0	
·	Selection	3: Multifunction display, see Pr.00.04 (Uxxx)		
		4: FWD/REV command		
		5: PLCx (PLC selections: PLC0/PLC1/PLC2) (NOT for VFD*E*C models)		
		0: Display the content of user-defined unit (Uxxx)		
 ≈ 00.04	Content of Multi-	1: Display the counter value (c)	0	
7 00.04	function Display	2: Display PLC D1043 value (C) (NOT for VFD*E*C models)		
		3: Display DC-BUS voltage (u)		

Parameter	Explanation	Settings	Factory Setting	Customer
		4: Display output voltage (E)		
		5: Display PID analog feedback signal value (b) (%)		
		6: Output power factor angle (n)		
		7: Display output power (P)		
		8: Display the estimated value of torque as it relates to current (t)		
		9: Display AVI (I) (V)		
		10: Display ACI / AVI2 (i) (mA/V)		
		11: Display the temperature of IGBT (h) (°C)		
		12: Display AVI3/ACI2 level (I.)		
		13: Display AVI4/ACI3 level (i.)		
		14: Display PG speed in RPM (G)		
		15: Display motor number (M)		
		16: Display F*Pr.00.05		
₩ 00.05	User-Defined Coefficient K	0.1 to 160.0	1.0	
00.06	Power Board Software Version	Read-only	#.##	
00.07	Control Board Software Version	Read-only	#.##	
00.08	Password Input	0 to 9999 0 to 2: times of wrong password	0	
00.09	Password Set	0 to 9999 0: No password set or successful input in Pr. 00.08	0	
		1: Password has been set		
00.10	Control Method	0: V/f Control	0	
	2 3 2	1: Vector Control		
00.11	Reserved		1	1
00.12	50Hz Base Voltage Selection	0: 230V/400V 1: 220V/380V	0	
	Į			<u> </u>

Group 1 Basic Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
01.00	Maximum Output Frequency (Fmax)	50.00 to 600.0 Hz (Japanese version: 50.00 to 599.00 Hz)	60.00	
01.01	Maximum Voltage Frequency (Fbase) (Motor 0)	0.10 to 600.0 Hz (Japanese version: 0.10 to 599.00 Hz)	60.00	
01.02	Maximum Output	115V/230V series: 0.1V to 255.0V	220.0	
01.02	Voltage (Vmax) (Motor 0)	460V series: 0.1V to 510.0V	440.0	
01.03	Mid-Point Frequency	0.10 to 600.00 Hz	1.50	
	1.03 (Fmid) (Motor 0)	(Japanese version: 0.10 to 599.00 Hz)		
01.04	Mid-Point Voltage	115V/230V series: 0.1V to 255.0V	10.0	
01.04	(Vmid) (Motor 0)	460V series: 0.1V to 510.0V	20.0	
01.05	Minimum Output	0.10 to 600.00 Hz	4.50	
01.05	1.05 Frequency (Fmin) (Motor 0)	(Japanese version: 0.10 to 599.00 Hz)	1.50	
04.00	Minimum Output	115V/230V series: 0.1V to 255.0V	10.0	
01.06	Voltage (Vmin) (Motor 0)	460V series: 0.1V to 510.0V	20.0	
01.07	Output Frequency Upper Limit	0.1 to 120.0%	110.0	
01.08	Output Frequency Lower Limit	0.0 to100.0 %	0.0	
⊮ 01.09	Accel Time 1	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
⊮ 01.10	Decel Time 1	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
⊮ 01.11	Accel Time 2	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
⊮ 01.12	Decel Time 2	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
⊮ 01.13	Jog Acceleration Time	0.1 to 600.0 / 0.01 to 600.0 sec	1.0	
⊮ 01.14	Jog Deceleration Time	0.1 to 600.0 / 0.01 to 600.0 sec	1.0	
⊮ 01.15	Jog Frequency	0.10 Hz to 600.00 Hz (Japanese version: 0.10 to 599.00 Hz)	6.00	

Parameter	Explanation	Settings	Factory Setting	Customer
01.16	Auto acceleration / deceleration (refer to Accel/Decel time setting)	0: Linear Accel/Decel 1: Auto Accel, Linear Decel 2: Linear Accel, Auto Decel 3: Auto Accel/Decel (Set by load) 4: Auto Accel/Decel (set by Accel/Decel Time setting)	0	
01.16	Auto acceleration / deceleration (refer to Accel/Decel time setting)	5: Linear Accel. controlled by current, linear Decel.6: Linear Accel. controlled by current, auto Decel.	- 0	
01.17	Acceleration S- Curve	0.0 to 10.0 / 0.00 to 10.00 sec	0.0	
01.18	Deceleration S- Curve	0.0 to 10.0 / 0.00 to 10.00 sec	0.0	
01.19	Accel/Decel Time Unit	0: Unit: 0.1 sec 1: Unit: 0.01 sec	0	
01.20	Delay Time at 0Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.21	Delay Time at 10Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.22	Delay Time at 20Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.23	Delay Time at 30Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.24	Delay Time at 40Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.25	Delay Time at 50Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.26	Maximum Voltage Frequency (Fbase) (Motor 1)	0.10 to 600.0 Hz (Japanese version: 0.10 to 599.00 Hz)	60.00	
01.27	Maximum Output Voltage (Vmax)	115V/230V series: 0.1V to 255.0V	220.0	
01.21	(Motor 1)	460V series: 0.1V to 510.0V	440.0	
01.28	Mid-Point Frequency (Fmid) (Motor 1)	0.10 to 600.00 Hz (Japanese version: 0.10 to 599.00 Hz)	1.50	
01.29	Mid-Point Voltage	115V/230V series: 0.1V to 255.0V	10.0	
01.20	(Vmid) (Motor 1)	460V series: 0.1V to 510.0V	20.0	
01.30	Minimum Output Frequency (Fmin) (Motor 1)	0.10 to 600.00 Hz (Japanese version: 0.10 to 599.00 Hz)	1.50	
01.31	Minimum Output Voltage (Vmin)	115V/230V series: 0.1V to 255.0V	10.0	
01.01	(Motor 1)	460V series: 0.1V to 510.0V	20.0	

Parameter	Explanation	Settings	Factory Setting	Customer
01.32	Maximum Voltage Frequency (Fbase) (Motor 2)	0.10 to 600.0 Hz (Japanese version: 0.10 to 599.00 Hz)	60.00	
01.33	Maximum Output Voltage (Vmax)	115V/230V series: 0.1V to 255.0V	220.0	
01.33	(Motor 2)	460V series: 0.1V to 510.0V	440.0	
01.34	Mid-Point Frequency (Fmid)	0.10 to 600.00 Hz (Japanese version: 0.10 to 599.00 Hz)	1.50	
	(Motor 2)	115V/230V series: 0.1V to 255.0V	10.0	
01.35	Mid-Point Voltage (Vmid) (Motor 2)	460V series: 0.1V to 510.0V	20.0	
	Minimum Output	0.10 to 600.00 Hz		
01.36	01.36 Frequency (Fmin) (Motor 2)	(Japanese version: 0.10 to 599.00 Hz)	1.50	
04.07	Minimum Output	115V/230V series: 0.1V to 255.0V	10.0	
01.37	01.37 Voltage (Vmin) (Motor 2)	460V series: 0.1V to 510.0V	20.0	
01.38	Maximum Voltage Frequency (Fbase) (Motor 3)	0.10 to 600.0 Hz	60.00	
01.39	Maximum Output	115V/230V series: 0.1V to 255.0V	220.0	
01.39	Voltage (Vmax) (Motor 3)	460V series: 0.1V to 510.0V	440.0	
01.40	Mid-Point Frequency (Fmid)	0.10 to 600.00 Hz	1.50	
01.40	(Motor 3)	(Japanese version: 0.10 to 599.00 Hz)	1.50	
01.41	Mid-Point Voltage	115V/230V series: 0.1V to 255.0V	10.0	
01.41	(Vmid) (Motor 3)	460V series: 0.1V to 510.0V	20.0	
01.42	Minimum Output Frequency (Fmin)	0.10 to 600.00 Hz	1.50	
52	(Motor 3)	(Japanese version: 0.10 to 599.00 Hz)	1.00	
01.43	Minimum Output Voltage (Vmin)	115V/230V series: 0.1V to 255.0V	10.0	
01.40	(Motor 3)	460V series: 0.1V to 510.0V	20.0	

Group 2 Operation Method Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Digital keypad UP/DOWN keys or Multi- function Inputs UP/DOWN. Last used frequency saved.		
₩ 02.00	Source of First	1: 0 to +10V from AVI	4	
	Master Frequency Command	2: 4 to 20mA from ACI or 0 to +10V from AVI2	1	
		3: RS-485 (RJ-45)/USB communication		
		4: Digital keypad potentiometer		
		0: Digital keypad		
		1: External terminals. Keypad STOP/RESET enabled.		
 ∕ ⁄ 02.01	Source of First Operation	2: External terminals. Keypad STOP/RESET disabled.	1	
	Command	3: RS-485 (RJ-45)/USB communication. Keypad STOP/RESET enabled.		
		4: RS-485 (RJ-45)/USB communication. Keypad STOP/RESET disabled.		
		0: STOP: ramp to stop; E.F.: coast to stop		
00.00	Otara Mathand	1: STOP: coast to stop; E.F.: coast to stop		
02.02	Stop Method	2: STOP: ramp to stop; E.F.: ramp to stop	0	
		3: STOP: coast to stop; E.F.: ramp to stop		
02.03	PWM Carrier Frequency Selections	1 to 15kHz	8	
		0: Enable forward/reverse operation		
02.04	Motor Direction Control	1: Disable reverse operation	0	
		2: Disabled forward operation		

Parameter	Explanation	Settings	Factory Setting	Customer
02.05	The source of Power-On command and Running command modifies the operating control of the VFD.	 Start running when Power is on. Don't run when Power is on When the source of the command changes, VFD's operation remains the same. When the source of the command changes, VFD's operation follows the new command. The motor drive can start to run at power on or after reset. When the source of 	1	
02.06	Loss of ACI Signal	command is a 2-wire external terminal, the operating command changes as the external terminal's status changes. 0: Decelerate to 0 Hz 1: Coast to stop and display "AErr"	1	
	(4-20mA)	2: Continue operation by last frequency command		
02.07	Up/Down Mode	0: by UP/DOWN Key1: Based on accel/decel time2: Constant speed (Pr.02.08)3: Pulse input unit (Pr.02.08)	0	
02.08	Accel/Decel Rate of Change of UP/DOWN Operation with Constant Speed	0.01~10.00 Hz/2ms	0.01	
№ 02.09	Source of Second Frequency Command	0: Digital keypad UP/DOWN keys or Multi- function Inputs UP/DOWN. Last used frequency saved. 1: 0 to +10V from AVI 2: 4 to 20mA from ACI or 0 to +10V from AVI2 3: RS-485 (RJ-45)/USB communication 4: Digital keypad potentiometer	0	
⊮ 02.10	Combination of the First and Second Master Frequency Command	O: First Master Frequency Command 1: First Master Frequency Command+ Second Master Frequency Command 2: First Master Frequency Command - Second Master Frequency Command	0	

Parameter	Explanation	Settings	Factory Setting	Customer
 ∕ 02.11	Keypad Frequency Command	0.00 to 600.00Hz (Japanese version: 0.00 to 599.00 Hz)	60.00	
₩ 02.12	Communication Frequency Command	0.00 to 600.00Hz (Japanese version: 0.00 to 599.00 Hz)	60.00	
02.13	The Selections for Saving Keypad or Communication Frequency Command	Save Keypad & Communication Frequency Save Keypad Frequency only Save Communication Frequency only	0	
02.14	Initial Frequency Selection (for keypad & RS485/USB)	0: by Current Freq Command 1: by Zero Freq Command 2: Refer to Pr.02-15 to set up	0	
02.15	Initial Frequency Set point (for keypad & RS485/USB)	0.00 ~ 600.00Hz (Japanese version: 0.00 to 599.00 Hz)	60.00	
02.16	Display the Master Freq Command Source	Read Only Bit0=1: by First Freq Source (Pr.02.00) Bit1=1: by Second Freq Source (Pr.02.09) Bit2=1: by Multi-input function Bit3=1: by PLC Freq command (NOT for VFD*E*C models)	1	
02.17	Display the Operation Command Source	Read Only Bit0=1: by Digital Keypad Bit1=1: by RS485 communication Bit2=1: by External Terminal 2/3 wire mode Bit3=1: by Multi-input function Bit4=1: by PLC Operation Command (NOT for VFD*E*C models) Bit5=1: by CANopen communication	4	
02.18	Selection of Carrier Modulation	by carrier modulation of load current and temperature by carrier modulation of load current	0	
02.19	Selection of Zero speed control mode	0: Enter standby mode when zero speed 1: Run DC brake when zero speed(the max. output voltage *0.05)	0	

Group 3 Output Function Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
		0: No function	8	
	Multi-function 3.00 Output Relay (RA1, RB1, RC1)	1: AC drive operational		
03.00		2: Master frequency attained		
		3: Zero speed		
		4: Over torque detection		
	NA 10: 6	5: Base-Block (B.B.) indication	1	
03.01	Multi-function Output Terminal	6: Low-voltage indication		
	MO1	7: Operation mode indication		
		8: Fault indication		
		9: Desired frequency 1 attained		
		10: Terminal count value attained		
		11: Preliminary count value attained		
		12: Over Voltage Stall supervision		
		13: Over Current Stall supervision		
		14: IGBT overheat warning (ON: 85°C, OFF: 80°C)		
		15: Over Voltage supervision		
		16: PID supervision		
		17: Forward command		
		18: Reverse command		
		19: Zero speed output signal		
		20: Warning(FbE,Cexx, AoL2, AUE, SAvE)		
		21: Brake control (Desired frequency attained)		
		22: Drive ready		
		23: Desired frequency 2 attained		
		24 :Function of Output Frequency Control Multi-output terminal ON/OFF		

Chapter 4 Pa Parameter	Explanation	Settings	Factory Setting	Customer
03.02	Desired Frequency 1 Attained	0.00 to 600.00Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
₩ 03.03	Analog Output Signal Selection (AFM)	Analog frequency meter Analog current meter	0	
№ 03.04	Analog Output Gain	1 to 200%	100	
03.05	Terminal Count Value	0 to 9999	0	
03.06	Preliminary Count Value	0 to 9999	0	
03.07	EF Active When Terminal Count	0: Terminal count value attained, no EF display	0	
	Value Attained	1: Terminal count value attained, EF active		
		0: Fan always ON		
		1: 1 minute after AC motor drive stops, fan will be OFF		
03.08	Fan Control	2: Fan ON when AC motor drive runs, fan OFF when AC motor drive stops	0	
		3: Fan ON when preliminary heatsink temperature attained (ON: 60°ℂ, Off: 40°ℂ)		
		Read only		
		Bit0=1:RLY used by PLC		
		Bit1=1:MO1 used by PLC		
	The Digital Output	Bit2=1:MO2/RA2 used by PLC		
03.09	Used by PLC (NOT for VFD*E*C	Bit3=1:MO3/RA3 used by PLC	##	
	models)	Bit4=1:MO4/RA4 used by PLC		
		Bit5=1:MO5/RA5 used by PLC		
		Bit6=1:MO6/RA6 used by PLC		
		Bit7=1:MO7/RA7 used by PLC		
	The Analog Output	Read only		
03.10	Used by PLC (NOT for VFD*E*C	Bit0=1:AFM used by PLC	##	
models)	•	Bit1=1: AO1 used by PLC		

Parameter	Explanation	Settings	Factory Setting	Customer
		Bit2=1: AO2 used by PLC		
03.11	Brake Release Frequency	0.00 to 20.00Hz	0.00	
03.12	Brake Engage Frequency	0.00 to 20.00Hz	0.00	
03.13	Display the Status of Multi-function Output Terminals	Read only Bit0: RLY Status Bit1: MO1 Status Bit2: MO2/RA2 Status Bit3: MO3/RA3 Status Bit4: MO4/RA4 Status Bit5: MO5/RA5 Status Bit6: MO6/RA6 Status Bit7: MO7/RA7 Status	##	
03.14	Desired Frequency 2 Attained	0.00 to 600.00Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	

Chapter 4 Parameters | Group 4 Input Function Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
₩ 04.00	Keypad Potentiometer Bias	0.0 to 200.0 %	0.0	
№ 04.01	Keypad Potentiometer Bias Polarity	0: Positive bias	_	
		1: Negative bias	0	
⊮ 04.02	Keypad Potentiometer Gain	0.1 to 200.0 %	100.0	
04.03	Keypad Potentiometer	0: No negative bias command	0	
04.03	Negative Bias, Reverse Motion Enable/Disable	1: Negative bias: REV motion enabled	U	
04.04	2-wire/3-wire	0: 2-wire: FWD/STOP, REV/STOP		
	Operation Control Modes	1: 2-wire: FWD/REV, RUN/STOP	0	
		2: 3-wire operation		
04.05	Multi-function Input Terminal (MI3)	0: No function	1	
		1: Multi-Step speed command 1		
		2: Multi-Step speed command 2		
04.06	Multi-function Input Terminal (MI4)	3: Multi-Step speed command 3	2	
		4: Multi-Step speed command 4		
		5: External reset		
04.07	Multi-function Input Terminal (MI5)	6: Accel/Decel inhibit	3	
		7: Accel/Decel time selection command		
		8: Jog Operation		
04.08	Multi-function Input Terminal (MI6)	9: External base block	4	
		10: Up: Increment master frequency		
		11: Down: Decrement master frequency		
		12: Counter Trigger Signal		
		13: Counter reset		
		14: E.F. External Fault Input		
		15: PID function disabled		

Parameter	Explanation	Settings	Factory Setting	Customer
		16: Output shutoff stop		
		17: Parameter lock enable		
		18: Operation command selection (external terminals)		
		19: Operation command selection(keypad)		
		20: Operation command selection (communication)		
		21: FWD/REV command		
		22: Source of second frequency command		
		23: Run/Stop PLC Program (PLC1) (NOT for VFD*E*C models)		
		23: Quick Stop (Only for VFD*E*C models)		
		24: Download/execute/monitor PLC Program (PLC2) (NOT for VFD*E*C models)		
		25: Simple position function		
		26: OOB (Out of Balance Detection)		
		27: Motor selection (bit 0)		
		28: Motor selection (bit 1)		
04.09	Multi-function Input Contact Selection	0~4095	0	
04.10	Digital Terminal Input Debouncing Time	1 to 20 (*2ms)	1	
04.11	Min AVI Voltage	0.0 to 10.0V	0.0	
04.12	Min AVI Frequency	0.0 to 100.0% F max.	0.0	
04.13	Max AVI Voltage	0.0 to 10.0V	10.0	
04.14	Max AVI Frequency	0.0 to 100.0% F max.	100.0	
04.15	Min ACI Current	0.0 to 20.0mA	4.0	
04.16	Min ACI Frequency	0.0 to 100.0% F max.	0.0	
04.17	Max ACI Current	0.0 to 20.0mA	20.0	
04.18	Max ACI Frequency	0.0 to 100.0%	100.0	
04.19	ACI/AVI2 Selection	0: ACI	0	
04.19		1: AVI2		

Parameter	Explanation	Settings	Factory Setting	Customer
04.20	Min AVI2 Voltage	0.0 to 10.0V	0.0	
04.21	Min AVI2 Frequency	0.0 to 100.0% F max.	0.0	
04.22	Max AVI2 Voltage	0.0 to 10.0V	10.0	
04.23	Max AVI2 Frequency	0.0 to 100.0% F max.	100.0	
		Read only		
		Bit0=1:MI1 used by PLC		
		Bit1=1:MI2 used by PLC		
		Bit2=1:MI3 used by PLC		
		Bit3=1:MI4 used by PLC		
	The Digital Input Used by PLC	Bit4=1:MI5 used by PLC		
04.24	(NOT for VFD*E*C models)	Bit5=1:MI6 used by PLC	##	
		Bit6=1: MI7 used by PLC		
		Bit7=1: MI8 used by PLC		
		Bit8=1: MI9 used by PLC		
		Bit9=1: MI10 used by PLC		
		Bit10=1: MI11 used by PLC		
		Bit11=1: MI12 used by PLC		
	The Analog Input Used by PLC (NOT for VFD*E*C models)	Read only		
		Bit0=1:AVI used by PLC		
04.25		Bit1=1:ACI/AVI2 used by PLC	##	
		Bit2=1: Al1 used by PLC		
		Bit3=1: Al2 used by PLC		
	Display the Status of Multi-function Input Terminal	Read only	##	
04.26		Bit0: MI1 Status		
		Bit1: MI2 Status		
		Bit2: MI3 Status		
		Bit3: MI4 Status		
		Bit4: MI5 Status		

Parameter	Explanation	Settings	Factory Setting	
		Bit5: MI6 Status		
		Bit6: MI7 Status		
		Bit7: MI8 Status		
		Bit8: MI9 Status		
		Bit9: MI10 Status		
		Bit10: MI11 Status		
		Bit11: MI12 Status		
04.27	Internal/External Multi-function Input Terminals Selection	0~4095	0	
№ 04.28	Internal Terminal Status	0~4095	0	
04.29	ACI Filter Time	0~9999 (x2ms)	50	

Group 5 Multi-Step Speeds Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
№ 05.00	1st Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
 ∕ ⁄ 05.01	2nd Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
 √ 05.02	3rd Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
№ 05.03	4th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
№ 05.04	5th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
№ 05.05	6th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
№ 05.06	7th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
№ 05.07	8th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
№ 05.08	9th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
№ 05.09	10th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
₩ 05.10	11th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
 ∕ ⁄ 05.11	12th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
 ∕ 05.12	13th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
 ∕ 05.13	14th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
 ∕ 05.14	15th Step Speed Frequency	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	

Group 6 Protection Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
		115/230V series: 330.0V to 410.0V	390.0V	
06.00	Over-Voltage Stall Prevention	460V series: 660.0V to 820.0V	780.0V	
		0.0: Disable over-voltage stall prevention		
06.01	Over-Current Stall Prevention during Accel	0:Disable 20 to 250%	170	
06.02	Over-Current Stall Prevention during Operation	0:Disable 20 to 250%	170	
		0: Disabled		
		Enabled during constant speed operation. After the over-torque is detected, keep running until OL1 or OL occurs.	0	
06.03	Over-Torque Detection Mode (OL2)	2: Enabled during constant speed operation. After the over-torque is detected, stop running.		
		3: Enabled during accel. After the over-torque is detected, keep running until OL1 or OL occurs.		
		4: Enabled during accel. After the over-torque is detected, stop running.		
№ 06.04	Over-Torque Detection Level	10 to 200%	150	
06.05	Over-Torque Detection Time	0.1 to 60.0 sec	0.1	
	Electronic Thermal	0: Standard motor (self cooled by fan)		
06.06	Overload Relay Selection	1: Special motor (forced external cooling)	2	
		2: Disabled		
06.07	Electronic Thermal Characteristic	30 to 600 sec	60	
		0: No fault		
06.00	Present Fault	1: Over current (oc)	_	
06.08	Record	2: Over voltage (ov)	0	
		3: IGBT Overheat (oH1)		

Parameter	Explanation	Settings	Factory Setting	Customer
		4: Reserved		
		5: Overload (oL)		
		6: Overload1 (oL1)		
		7: Motor over load (oL2)		
06.09	Second Most	8: External fault (EF)		
	Recent Fault Record	9: Current exceeds 2 times rated current during accel.(ocA)		
		10: Current exceeds 2 times rated current during decel.(ocd)		
		11: Current exceeds 2 times rated current during steady state operation (ocn)		
		12: Ground fault (GFF)		
		13: Reserved		
		14: Phase-Loss (PHL)		
		15: Reserved		
		16: Auto Acel/Decel failure (CFA)		
06.10	Third Most Recent	17: SW/Password protection (codE)		
	Fault Record	18: Power Board CPU WRITE failure (cF1.0)		
		19: Power Board CPU READ failure (cF2.0)		
		20: CC, OC Hardware protection failure (HPF1)		
06.11	Fourth Most Recent	21: OV Hardware protection failure (HPF2)		
	Fault Record	22: GFF Hardware protection failure (HPF3)		
		23: OC Hardware protection failure (HPF4)		
		24: U-phase error (cF3.0)		
06.12	Fifth Most Recent	25: V-phase error (cF3.1)		
00.12	Fault Record	26: W-phase error (cF3.2)		
		27: DCBUS error (cF3.3)		
		28: IGBT Overheat (cF3.4)		
		29: Reserved		
		30: Control Board CPU WRITE failure (cF1.1)		

Parameter	·	Settings	Factory Setting	Customer
		31: Control Board CPU WRITE failure (cF2.1)		
		32: ACI signal error (AErr)		
		33: Reserved		
		34: Motor PTC overheat protection (PtC1)		
		35: PG feedback signal error (PGEr)		
		36-39: Reserved		
		40: Communication time-out error of control board and power board (CP10)		
		41: dEb error		
		42: ACL (Abnormal Communication Loop)		
		66: U phase output phase loss (oPHL1)		
		67: V phase output phase loss (oPHL2)		
		68: W phase output phase loss (oPHL3)		
06.13	Action for detected Output Phase Loss (OPHL)	0 : Warn and keep operation 1 : Warn and ramp to stop 2 : Warn and coast to stop 3 : No warning	3	
06.14	Deceleration Time of	0.0~120.0 seconds	0.5	
00.14	Output Phase Loss	0.0 120.0 3000Hu3	0.5	
06.15	Detected Current Bandwidth	0~100%	2	
06.16	Detected DC Brake Time of Output Phase Loss	0.0~120.0 seconds	0.1	

Chapter 4 Parameters | Group 7 Motor Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
07.00	Motor Rated Current (Motor 0)	30 %FLA to 120% FLA	FLA	
07.01	Motor No-Load Current (Motor 0)	0%FLA to 99% FLA	0.4*FLA	
 ₩ 07.02	Torque Compensation (Motor 0)	0.0 to 10.0	0.0	
₩ 07.03	Slip Compensation (Used without PG) (Motor 0)	0.00 to 10.00	0.00	
07.04	Motor Parameters Auto Tuning	0: Disable 1: Auto tuning R1 2: Auto tuning R1 + no-load test	0	
07.05	Motor Line-to-line Resistance R1 (Motor 0)	0~65535 mΩ	0	
07.06	Motor Rated Slip (Motor 0)	0.00 to 20.00 Hz	3.00	
07.07	Slip Compensation Limit	0 to 250%	200	
07.08	Torque Compensation Time Constant	0.01 ~10.00 Sec	0.30	
07.09	Slip Compensation Time Constant	0.05 ~10.00 sec	0.20	
07.10	Accumulative Motor Operation Time (Min.)	0 to 1439 Min.	##	
07.11	Accumulative Motor Operation Time (Day)	0 to 65535 Day	##	
07.12	Motor PTC Overheat Protection	0: Disable 1: Enable	0	
07.13	Input Debouncing Time of the PTC Protection	0~9999(*2ms)	100	

Parameter	Explanation	Settings	Factory Setting	Customer
07.14	Motor PTC Overheat Protection Level	0.1~10.0V	2.4	
07.15	Motor PTC Overheat Warning Level	0.1~10.0V	1.2	
07.16	Motor PTC Overheat Reset Delta Level	0.1~5.0V	0.6	
07.17	Treatment of the Motor PTC Overheat	0: Warn and RAMP to stop 1: Warn and COAST to stop 2: Warn and keep running	0	
07.18	Motor Rated Current (Motor 1)	30 %FLA to 120% FLA	FLA	
07.19	Motor No-Load Current (Motor 1)	0%FLA to 99% FLA	0.4*FLA	
₩ 07.20	Torque Compensation (Motor 1)	0.0 to 10.0	0.0	
⊮ 07.21	Slip Compensation (Used without PG) (Motor 1)	0.00 to 10.00	0.00	
07.22	Motor Line-to-line Resistance R1 (Motor 1)	0~65535 mΩ	0	
07.23	Motor Rated Slip (Motor 1)	0.00 to 20.00 Hz	3.00	
07.24	Motor Pole Number (Motor 1)	2 to 10	4	
07.25	Motor Rated Current (Motor 2)	30 %FLA to 120% FLA	FLA	
07.26	Motor No-Load Current (Motor 2)	0%FLA to 99% FLA	0.4*FLA	
₩ 07.27	Torque Compensation (Motor 2)	0.0 to 10.0	0.0	
№ 07.28	Slip Compensation (Used without PG) (Motor 2)	0.00 to 10.00	0.00	

Parameter	Explanation	Settings	Factory Setting	Customer
07.29	Motor Line-to-line Resistance R1 (Motor 2)	0~65535 mΩ	0	
07.30	Motor Rated Slip (Motor 2)	0.00 to 20.00 Hz	3.00	
07.31	Motor Pole Number (Motor 3)	2 to 10	4	
07.32	Motor Rated Current (Motor 3)	30 %FLA to 120% FLA	FLA	
07.33	Motor No-Load Current (Motor 3)	0%FLA to 99% FLA	0.4*FLA	
₩ 07.34	Torque Compensation (Motor 3)	0.0 to 10.0	0.0	
№ 07.35	Slip Compensation (Used without PG) (Motor 3)	0.00 to 10.00	0.00	
07.36	Motor Line-to-line Resistance R1 (Motor 3)	0~65535 mΩ	0	
07.37	Motor Rated Slip (Motor 3)	0.00 to 20.00 Hz	3.00	
07.38	Motor Pole Number (Motor 3)	2 to 10	4	

Chapter 4 Parameters | Group 8 Special Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
08.00	DC Brake Current Level	0 to 100%	0	
08.01	DC Brake Time during Start-Up	0.0 to 60.0 sec	0.0	
08.02	DC Brake Time during Stopping	0.0 to 60.0 sec	0.0	
08.03	Start-Point for DC Brake	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
08.04	Momentary Power Loss Operation Selection	O: Operation stops after momentary power loss Coperation continues after momentary power loss, speed search starts with the Last Frequency Operation continues after momentary power loss, speed search starts with the minimum frequency	0	
08.05	Maximum Allowable Power Loss Time	0.1 to 20.0 sec	2.0	
08.06	Base-block Speed Search	Disable speed search Speed search starts with last frequency Starts with minimum output frequency	1	
08.07	B.B. Time for Speed Search	0.1 to 5.0 sec	0.5	
08.08	Current Limit for Speed Search	30 to 200%	150	
08.09	Skip Frequency 1 Upper Limit	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
08.10	Skip Frequency 1 Lower Limit	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
08.11	Skip Frequency 2 Upper Limit	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
08.12	Skip Frequency 2 Lower Limit	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
08.13	Skip Frequency 3 Upper Limit	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	

Parameter	Explanation	Settings	Factory Setting	Customer
08.14	Skip Frequency 3 Lower Limit	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
08.15	Auto Restart After Fault	0 to 10 (0=disable)	0	
08.16	Auto Reset Time at Restart after Fault	0.1 to 6000 sec	60.0	
08.17	Auto Energy Saving	0: Disable 1: Enable	0	
08.18	AVR Function	0: AVR function enable 1: AVR function disable 2: AVR function disable for decel. 3: AVR function disable for stop	0	
08.19	Software Brake Level	115V / 230V series: 370.0to 430.0V 460V series: 740.0 to 860.0V	380.0 760.0	
№ 08.20	Compensation Coefficient for Motor Instability	0.0~5.0	0.0	
08.21	OOB Sampling Time	0.1 to 120.0 sec	1.0	
08.22	Number of OOB Sampling Times	00 to 32	20	
08.23	OOB Average Sampling Angle	Read only	#.#	
08.24	DEB Function	0: Disable 1: Enable	0	
08.25	DEB Return Time	0 to 25 sec	0	
08.26	Speed Search during Start-up	0: Disable 1: Enable	0	
08.27	Speed Search Frequency during Start-up	0: By setting frequency 1: By max. operation frequency (Pr.01.00)	0	
08.28	Output Voltage Limit	80~150%	100	
08.29	Special Bit Control Parameter	Bit0=1,cancel internal frequency command filter	0	

Group 9 Communication Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
№ 09.00	Communication Address	1 to 254	1	
		0: Baud rate 4800bps		
×00.01	Transmission Chard	1: Baud rate 9600bps	1	
№ 09.01	Transmission Speed	2: Baud rate 19200bps	'	
		3: Baud rate 38400bps		
		0: Warn and keep operating		
×00.00	Transmission Fault	1: Warn and ramp to stop	2	
№ 09.02	Treatment	2: Warn and coast to stop	3	
		3: No warning and keep operating		
№ 09.03	Time-out Detection	0.1 ~ 120.0 seconds 0.0: Disable	0.0	
	Communication Protocol	0: 7,N,2 (Modbus, ASCII)		
		1: 7,E,1 (Modbus, ASCII)		
		2: 7,O,1 (Modbus, ASCII)	0	
№ 09.04		3: 8,N,2 (Modbus, RTU)		
		4: 8,E,1 (Modbus, RTU)		
		5: 8,O,1 (Modbus, RTU)		
		6: 8,N,1 (Modbus, RTU)		
		7: 8,E,2 (Modbus, RTU)		
		8: 8,O,2 (Modbus, RTU)		
		9: 7,N,1 (Modbus, ASCII)		
		10: 7,E,2 (Modbus, ASCII)		
		11: 7,O,2 (Modbus, ASCII)		
09.05	Reserved			
09.06	Reserved		1	
 € 09.07	Response Delay Time	0 ~ 200 (unit: 2ms)	1	

Parameter	Explanation	Settings	Factory Setting	Customer
№ 09.08	Transmission Speed for USB Card	0: Baud rate 4800 bps 1: Baud rate 9600 bps 2: Baud rate 19200 bps 3: Baud rate 38400 bps 4: Baud rate 57600 bps	2	
№ 09.09	Communication Protocol for USB Card	0: 7,N,2 for ASCII 1: 7,E,1 for ASCII 2: 7,O,1 for ASCII 3: 8,N,2 for RTU 4: 8,E,1 for RTU 5: 8,O,1 for RTU 6: 8,N,1 (Modbus, RTU) 7: 8,E,2 (Modbus, RTU) 8: 8,O,2 (Modbus, RTU) 9: 7,N,1 (Modbus, ASCII) 10: 7,E,2 (Modbus, ASCII) 11: 7,O,2 (Modbus, ASCII)	1	
 № 09.10	Transmission Fault Treatment for USB Card	0: Warn and keep operating1: Warn and ramp to stop2: Warn and coast to stop3: No warning and keep operating	0	
 ∕ ⁄ 09.11	Time-out Detection for USB Card	0.1 ~ 120.0 seconds 0.0: Disable	0.0	
09.12	COM port for PLC Communication (NOT for VFD*E*C models)	0: RS485 1: USB card	0	

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Disable PID operation		
		1: Keypad (based on Pr.02.00)		
10.00	PID Set Point	2: 0 to +10V from AVI	0	
	Selection	3: 4 to 20mA from ACI or 0 to +10V from AVI2		
		4: PID set point (Pr.10.11)		
		0: Positive PID feedback from external terminal AVI (0 ~ +10VDC)		
		1: Negative PID feedback from external terminal AVI (0 ~ +10VDC)		
10.01	Input Terminal for PID Feedback	2: Positive PID feedback from external terminal ACI (4 ~ 20mA)/ AVI2 (0 ~ +10VDC).	0	
		3: Negative PID feedback from external terminal ACI (4 ~ 20mA)/ AVI2 (0 ~ +10VDC).		
 10.02	Proportional Gain (P)	0.0 to 10.0	1.0	
№ 10.03	Integral Time (I)	0.00 to 100.0 sec (0.00=disable)	1.00	
№ 10.04	Derivative Control (D)	0.00 to 1.00 sec	0.00	
10.05	Upper Bound for Integral Control	0 to 100%	100	
10.06	Primary Delay Filter Time	0.0 to 2.5 sec	0.0	
10.07	PID Output Freq Limit	0 to 110%	100	
10.08	PID Feedback Signal Detection Time	0.0 to 3600 sec (0.0 disable)	60.0	
	Treatment of the	0: Warn and RAMP to stop		
10.09	Erroneous PID	1: Warn and COAST to stop	0	
	Feedback Signals	2: Warn and keep operation		
10.10	Gain Over the PID Detection Value	0.0 to 10.0	1.0	

Parameter	Explanation	Settings	Factory Setting	Customer
1 0.11	Source of PID Set point	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	0.00	
10.12	PID Offset Level	1.0 to 50.0%	10.0	
10.13	Detection Time of PID Offset	0.1 to 300.0 sec	5.0	
10.14	Sleep/Wake Up Detection Time	0.0 to 6550 sec	0.0	
10.15	Sleep Frequency	0.00 to Fmax. Hz	0.00	
10.16	Wakeup Frequency	0.00 to Fmax. Hz	0.00	
10.17	Minimum PID Output Frequency Selection	0: By PID control 1: By minimum output frequency (Pr.01.05)	0	

Chapter 4 Parameters | Group 11 Parameters for Extension Card

Parameter	Explanation	Settings	Factory Setting	Customer
		0: No function		
44.00	Multi-function	1: AC drive operational	0	
11.00	Output Terminal MO2/RA2	2: Master frequency attained	0	
		3: Zero speed		
		4: Over torque detection		
44.04	Multi-function	5: Base-Block (B.B.) indication		
11.01	Output Terminal MO3/RA3	6: Low-voltage indication	0	
		7: Operation mode indication		
		8: Fault indication		
	Multi-function	9: Desired frequency 1 attained		
11.02	Output Terminal MO4/RA4	10: Terminal count value attained	0	
		11: Preliminary count value attained		
		12: Over Voltage Stall supervision		
		13: Over Current Stall supervision		
11.03	Multi-function Output Terminal	14: IGBT overheat warning (ON: 85°C, OFF:	0	
	MO5/RA5	80°C)		
		15: Over Voltage supervision		
		16: PID supervision		
11.04	Multi-function	17: Forward command		
11.04	Output Terminal MO6/RA6	18: Reverse command	0	
		19: Zero speed output signal		
		20: Warning(FbE,Cexx, AoL2, AUE, SAvE)		
		21: Brake control (Desired frequency attained)	0	
11.05	Multi-function	22: Drive ready		
	Output Terminal MO7/RA7	23: Desired frequency 2 attained		
	WOTTIAL	24 :Function of output frequency control multi-output terminal ON/OFF		

Parameter	Explanation	Settings	Factory Setting	Custome
		0: No function	0	
11.06	Multi-function Input Terminal (MI7)	1: Multi-Step speed command 1		
	,	2: Multi-Step speed command 2		
		3: Multi-Step speed command 3	0	
11.07	Multi-function Input Terminal (MI8)	4: Multi-Step speed command 4		
	- (-,	5: External reset		
		6: Accel/Decel inhibit	0	
11.08	Multi-function Input Terminal (MI9)	7: Accel/Decel time selection command		
	,	8: Jog Operation		
		9: External base block	0	
11.09	Multi-function Input Terminal (MI10)	10: Up: Increment master frequency		
	,	11: Down: Decrement master frequency		
		12: Counter Trigger Signal	0	
11 10	Multi-function Input Terminal (MI11)	13: Counter reset		
11.10		14: E.F. External Fault Input		
		15: PID function disabled		
11.11	Multi-function Input	16: Output shutoff stop	0	
	Terminal (MI12)	17: Parameter lock enable		
		18: Operation command selection (external terminals)		
		19: Operation command selection (keypad)		
		20: Operation command selection (communication)		
		21: FWD/REV command		
		22: Source of second frequency command		
		23: Run/Stop PLC Program (PLC1)		
		(NOT for VFD*E*C models)		
		23: Quick Stop (Only for VFD*E*C models)		
		24: Download/execute/monitor PLC Program (PLC2) (NOT for VFD*E*C models)		

Parameter	Explanation	Settings		Customer
		25: Simple position function		
		26: OOB (Out of Balance Detection)		
		27: Motor selection (bit 0)		
		28: Motor selection (bit 1)		

Chapter 4 Parameters | Group 12: Analog Input/ Output Parameters for Extension Card

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Disabled		
		1: Source of the 1st frequency		
12.00	Al1 Function	2: Source of the 2nd frequency	0	
12.00	Selection	3: PID Set Point (PID enable)	0	
		4: Positive PID feedback		
		5: Negative PID feedback		
12.01	Al1 Analog Signal	0: ACI2 analog current (0.0 ~ 20.0mA)	1	
12.01	Mode	1: AVI3 analog voltage (0.0 ~ 10.0V)	1	
12.02	Min. AVI3 Input Voltage	0.0 to 10.0V	0.0	
12.03	Min. AVI3 Scale Percentage	0.0 to 100.0%	0.0	
12.04	Max. AVI3 Input Voltage	0.0 to 10.0V	10.0	
12.05	Max. AVI3 Scale Percentage	0.0 to 100.0%	100.0	
12.06	Min. ACI2 Input Current	0.0 to 20.0mA	4.0	
12.07	Min. ACI2 Scale Percentage	0.0 to 100.0%	0.0	
12.08	Max. ACI2 Input Current	0.0 to 20.0mA	20.0	
12.09	Max. ACI2 Scale Percentage	0.0 to 100.0%	100.0	
12.10	AI2 Function Selection	0: Disabled 1: Source of the 1st frequency 2: Source of the 2nd frequency 3: PID Set Point (PID enable) 4: Positive PID feedback 5: Negative PID feedback	0	
12.11	Al2 Analog Signal Mode	0: ACI3 analog current (0.0 ~ 20.0mA) 1: AVI4 analog voltage (0.0 ~ 10.0V)	1	

Parameter	Explanation	Settings	Factory Setting	Customer
12.12	Min. AVI4 Input Voltage	0.0 to 10.0V	0.0	
12.13	Min. AVI4 Scale Percentage	0.0 to 100.0%	0.0	
12.14	Max. AVI4 Input Voltage	0.0 to 10.0V	10.0	
12.15	Max. AVI4 Scale Percentage	0.0 to 100.0%	100.0	
12.16	Min. ACI3 Input Current	0.0 to 20.0mA	4.0	
12.17	Min. ACI3 Scale Percentage	0.0 to 100.0%	0.0	
12.18	Max. ACI3 Input Current	0.0 to 20.0mA	20.0	
12.19	Max. ACI3 Scale Percentage	0.0 to 100.0%	100.0	
	AO1 Terminal Analog Signal Mode	0: AVO1		
12.20		1: ACO1 (analog current 0.0 to 20.0mA)	0	
		2: ACO1 (analog current 4.0 to 20.0mA)		
40.04	AO1 Analog Output	0: Analog Frequency	0	
12.21	Signal	1: Analog Current (0 to 250% rated current)	0	
12.22	AO1 Analog Output Gain	1 to 200%	100	
		0: AVO2		
12.23	AO2 Terminal Analog Signal Mode	1: ACO2 (analog current 0.0 to 20.0mA)	0	
	7 maiog olgilai Modo	2: ACO2 (analog current 4.0 to 20.0mA)		
12.24	AO2 Analog Output	0: Analog Frequency	0	
12.24	Signal	1: Analog Current (0 to 250% rated current)	0	
12.25	AO2 Analog Output Gain	1 to 200%		
12.26	AUI Analog Input Selection	0: No function 1: Source of the 1st frequency 2: Source of the 2nd frequency	0	

Parameter	Explanation	Settings	Factory Setting	Customer
⊮ 12.27	AUI Analog Input Bias	0.00~200.00%	0.00	
12.28	AUI Bias Polarity	0: Positive bias 1: Negative bias	0	
⊮ 12.29	AUI Analog Gain	1~200%	100	
12.30	AUI Negative Bias, Reverse Motion Enable/Disable	0: No AUI Negative Bias Command 1: Negative Bias: REV Motion Enabled 2: Negative Bias: REV Motion Disabled	0	
12.31	AUI Analog Input Delay	0~9999	50	

Chapter 4 Parameters | Group 13: PG function Parameters for Extension Card

Parameter	eter Explanation Settings		Factory Setting	ii .iistomeri
		0: Disabled		
13.00	PG Input	1: Single phase	0	
13.00	1 O mpat	2: Forward/Counterclockwise rotation		
		3: Reverse/Clockwise rotation		
13.01	PG Pulse Range	1 to 20000	600	
13.02	Motor Pole Number (Motor 0)	2 to 10	4	
⊮ 13.03	Proportional Gain (P)	0.0 to 10.0	1.0	
1 3.04	Integral Gain (I)	0.00 to 100.00 sec	1.00	
⊮ 13.05	Speed Control Output Frequency Limit	0.00 to 100.00Hz	10.00	
⊮ 13.06	Speed Feedback Display Filter	0 to 9999 (*2ms)	500	
⊮ 13.07	Detection Time for Feedback Signal Fault	0.0: disabled 0.1 to 10.0 sec	1.0	
⊮ 13.08	Treatment of the Feedback Signal Fault	0: Warn and RAMP to stop 1: Warn and COAST to stop 2: Warn and keep operation	1	
⊮ 13.09	Speed Feedback Filter	0 to 9999 (*2ms)	16	
13.10	Source of the High-	0: PG card	Read	
13.10	speed Counter	1: PLC (NOT for VFD*E*C models)	Only	

4.2 Parameter Settings for Applications

Speed Search

Applications	Purpose	Functions	Related Parameters
Windmill, winding machine, fan and all inertia loads	Restart free- running motor	Before the free-running motor is completely stopped, it can be restarted without detection of motor speed. The AC motor drive will auto search motor speed and will accelerate when its speed is the same as the motor speed.	08.04~08.08

DC Brake before Running

Applications	Purpose	Functions	Related Parameters
When e.g. windmills, fans and pumps rotate freely by wind or flow without applying power	standstill.	If the running direction of the free- running motor is not steady, please execute DC brake before start-up.	08.00 08.01

Energy Saving

Applications	Purpose	Functions	Related Parameters
Punching machines fans, pumps and precision machinery	Energy saving and less vibrations	Energy saving when the AC motor drive runs at constant speed, yet full power acceleration and deceleration For precision machinery it also helps to lower vibrations.	08.17

Multi-step Operation

Applications	Purpose	Functions	Related Parameters
Conveying machinery		To control 15-step speeds and duration by simple contact signals.	04.05~04.10 05.00~05.14

Switching acceleration and deceleration times

Applications	Purpose	Functions	Related Parameters
Auto turntable for conveying machinery	Switching acceleration and deceleration times by external signal	When an AC motor drive drives two or more motors, it can reach high-speed but still start and stop smoothly.	01.09~01.12 04.05~04.08

Chapter 4 Parameters | Overheat Warning

Applications	Purpose	Functions	Related Parameters
Air conditioner	Safety measure	When AC motor drive overheats, it uses a thermal sensor to have overheat warning.	03.00~03.01 04.05~04.08

Two-wire/three-wire

Applications	Purpose	Functions	Related Parameters
General application	To run, stop, forward and reverse by external terminals	FWD/STOP REV/STOP TO MI1:("OPEN":STOP) ("CLOSE":FWD) MI2:("OPEN": STOP) ("CLOSE": REV) DCM WFD-E RUN/STOP FWD/REV TO MI1:("OPEN":STOP) ("CLOSE":RUN) MI2:("OPEN":FWD) ("CLOSE":REV) DCM WFD-E 3-wire STOP RUN	02.01 04.04
		STOP RUN MI1:("CLOSE":RUN) MI3:("OPEN":STOP) MI2:("OPEN": FWD) ("CLOSE": REV) DCM VFD-E	

Operation Command

Applications	Purpose	Functions	Related Parameters
General application	Selecting the source of control signal	Selection of AC motor drive control by external terminals, digital keypad or RS485.	02.01 04.05~04.08

Frequency Hold

Applications	Purpose	Functions	Related Parameters
General application	Acceleration/ deceleration pause	Hold output frequency during Acceleration/deceleration	04.05~04.08

Auto Restart after Fault

Applications	Purpose	Functions	Related Parameters
Air conditioners, remote pumps	For continuous and reliable operation without operator intervention	The AC motor drive can be restarted/reset automatically up to 10 times after a fault occurs.	08.15~08.16

Emergency Stop by DC Brake

Applications	Purpose	Functions	Related Parameters
High-speed rotors	Emergency stop without brake resistor	AC motor drive can use DC brake for emergency stop when quick stop is needed without brake resistor. When used often, take motor cooling into consideration.	08.00 08.02 08.03

Over-torque Setting

Applications	Purpose	Functions	Related Parameters
Pumps, fans and extruders	To protect machines and to have continuous/ reliable operation	The over-torque detection level can be set. Once OC stall, OV stall and over-torque occurs, the output frequency will be adjusted automatically. It is suitable for machines like fans and pumps that require continuous operation.	06.00~06.05

Upper/Lower Limit Frequency

Applications	Purpose	Functions	Related Parameters
Pump and fan	Control the motor speed within upper/lower limit	When user cannot provide upper/lower limit, gain or bias from external signal, it can be set individually in AC motor drive.	01.07 01.08

Skip Frequency Setting

Applications	Purpose	Functions	Related Parameters
Pumps and fans	To prevent machine vibrations	The AC motor drive cannot run at constant speed in the skip frequency range. Three skip frequency ranges can be set.	08.09~08.14

Carrier Frequency Setting

Applications	Purpose	Functions	Related Parameters
General application	Low noise	The carrier frequency can be increased when required to reduce motor noise.	02.03

Keep Running when Frequency Command is Lost

Applications	Purpose	Functions	Related Parameters
Air conditioners	For continuous operation	When the frequency command is lost by system malfunction, the AC motor drive can still run. Suitable for intelligent air conditioners.	02.06

Output Signal during Running

Applications	Purpose	Functions	Related Parameters
General application	Provide a signal for running status	Signal available to stop braking (brake release) when the AC motor drive is running. (This signal will disappear when the AC motor drive is freerunning.)	03.00~03.01

Output Signal in Zero Speed

Applications	Purpose	Functions	Related Parameters
General application	Provide a signal for running status	When the output frequency is lower than the min. output frequency, a signal is given for external system or control wiring.	03.00~03.01

Output Signal at Desired Frequency

Applications	Purpose	Functions	Related Parameters
General application	Provide a signal for running status	When the output frequency is at the desired frequency (by frequency command), a signal is given for external system or control wiring (frequency attained).	03.00~03.01

Output Signal for Base Block

Applications	Purpose	Functions	Related Parameters
General application	Provide a signal for running status	When executing Base Block, a signal is given for external system or control wiring.	03.00~03.01

Overheat Warning for Heat Sink

Applications	Purpose	Functions	Related Parameters
General application	For safety	When heat sink is overheated, it will send a signal for external system or control wiring.	03.00~03.01

Multi-function Analog Output

Applications	Purpose	Functions	Related Parameters
General application	Display running status	The value of frequency, output current/voltage can be read by connecting a frequency meter or voltage/current meter.	03.06

4.3 Description of Parameter Settings

Group 0: User Parameters

-			
00.00	Identity Co	ode of the AC Motor Drive	
	Settings	Read Only	Factory setting: ##
00.01	Rated Cur	rent Display of the AC Motor Drive	
	Settings	Read Only	Factory setting: #.#

Pr. 00.00 displays the identity code of the AC motor drive. The capacity, rated current, rated voltage and the max. carrier frequency relate to the identity code. Users can use the following table to check how the rated current, rated voltage and max. carrier frequency of the AC motor drive correspond to the identity code.

Pr.00.01 displays the rated current of the AC motor drive. By reading this parameter the user can check if the AC motor drive is correct.

115V Series							
kW	0.2 0.4 0.75						
HP	0.25 0.5 1.0						
Pr.00.00	0 2 4						
Rated Output Current (A)	1.6 2.5 4.2						
Max. Carrier Frequency	15kHz						

	230V Series									
kW	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
HP	0.25	0.5	1.0	2.0	3.0	5.0	7.5	10	15	20
Pr.00.00	0	2	4	6	8	10	12	14	16	18
Rated Output Current (A)	1.6 2.5 4.2 7.5 11.0 17 25 33 45 65									
Max. Carrier	15kHz									

	460V Series										
kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22
HP	0.5	1.0	2.0	3.0	5.0	7.5	10	15	20	25	30
Pr.00.00	3	5	7	9	11	13	15	17	19	21	23
Rated Output Current (A)	1.5	2.5	4.2	5.5	8.5	13	18	24	32	38	45
Max. Carrier Frequency	I DKTZ										

•	^	00
u	V.	WZ

Parameter Reset

Factory Setting: 0

- Settings 0 Parameter can be read/written
 - 1 All parameters are read-only
 - 6 Clear PLC program (NOT for VFD*E*C models)
 - 8 Keypad Lock
 - 9 All parameters are reset to factory settings (50Hz, 230V/400V or 220V/380V depends on Pr.00.12)
 - All parameters are reset to factory settings (60Hz, 115V/220V/440V) 10
- When Pr.00.02=1, all parameters are read-only. To write all parameters, set Pr.00.02=0.
- When Pr.00.02=6, it clears all PLC program. But this function is NOT for VFD*E*C models.
- If the parameter setting is "8", keypad setting is invalid but the setting of communication parameters is valid. Method to relieve: Press "Enter" 5 seconds then set Pr.00.02=0.
- When the parameter settings are abnormal, all parameters can be reset to factory setting by setting Pr.00.02 to 9 or 10.
- When Pr.00.02=9, all parameters are reset to factory setting for 50Hz users and voltage will be different by Pr.00.12 setting.
- When Pr.00.02=10, all parameters are reset to factory setting for 60Hz users.
- Related parameter: Pr.00.12 (50Hz Base Voltage Selection)



When Pr.00.02=9 or 10, all parameter are reset to factory setting but it doesn't clear all PLC program. Only Pr.00.02=6 can clear all PLC program.

00.03

✓ Start-up Display Selection

Settings 0

Display the frequency command value (Fxxx)

- 1 Display the actual output frequency (Hxxx)
- Display the output current in A supplied to the motor 2 (Axxx)
- 3 Display the content of user-defined unit (Uxxx)
- FWD/REV command 4
- 5 PLCx (PLC selections: PLC0/PLC1/PLC2) (NOT for VFD*E*C models)

Factory Setting: 0

- This parameter determines the start-up display page after power is applied to the drive.
- For setting 5, PLC0: disable, PLC1: run PLC, PLC2: read/write PLC programs into AC motor
- Please refer to Pr.00.04 for multi-function display.
- Related parameter: Pr.00.04 (Content of Multi-function Display)

00.04

			Factory Setting: 0
Settings	0	Display the content of user-defined unit (Uxxx)	U 20
	1	Display the counter value which counts the number of pulses on TRG terminal (c)	c 20
	2	Display PLC D1043 value (C) (NOT for VFD*E*C models)	E 20
	3	Display the actual DC BUS voltage in VDC of the AC motor drive (u)	03 10
	4	Display the output voltage in VAC of terminals U/T1, V/T2, W/T3 to the motor (E)	8220
	5	Display PID analog feedback signal value in % (b)	6 0.0
	6	Display the power factor angle in ° of terminals U/T1, V/T2, W/T3 to the motor (n)	n 9 0.0
	7	Display the output power in kW of terminals U, V and W to the motor (P)	P0.00
	8	Display the estimated value of torque in Nm as it relates to current (t)	£ 0.00
	9	Display the signal of AVI analog input terminal in V (I)	1 0.0
	10	Display the signal of ACI analog input terminal in mA or display the signal of AVI2 analog input terminal in V (i)	<i>i</i> 0.0
	11	Display the temperature of IGBT (h) in °C	h300
	12	Display AVI3/ACI2 level (I.)	1. 0.0
	13	Display AVI4/ACI3 level (i.)	<i>E.</i> 0.0
	14	Display PG speed in RPM (G)	6 20
	15	Display motor number 00~03 (M)	0.5
	16	Display F*Pr.00.05	U. 80

- When Pr00.03 is set to 03, the display is according to the setting of Pr00.04.
- When Pr.00.04 is set to 0 or 16, please refer to Pr.00.05 for details. Related parameter: Pr.00.05 (User Defined Coefficient K)



Please refer to Appendix B.8 KPE-LE02 for the 7-segment LED Display of the Digital Keypad.

00.05	✓ User Defi	ned Coefficient K	
	Settings	0. 1 to 160.0	Factory Setting: 1.0
	The coefficient I	C determines the multiplying factor f	or the user-defined unit.
	When Pr00.04 is		
	User-def	ned unit (U) = Output frequency (H)	* User Defined Coefficient (K)
	When Pr00.04 is	s set to 16:	` ,
	User-defi	ned unit (U) = Output frequency (F)	* User Defined Coefficient (K)
		equency setting * User Defined Coe	
		. , ,	. ,
	Example:		
	•	use RPM to display the motor spee	d when 4-polse motor runs at 60Hz. The

user can display the motor speed by setting Pr.00.04 to 0. The application is shown as follows. From the formula of motor speed, user-defined unit (U) (RPM) = 60X120/4=1800 (disregard



Formula of motor speed
$$n = f \times \frac{120}{P}$$


slip). Therefore, User Defined Coefficient K is 30.0.

n: speed (RPM) (revolution per minute)

P: pole number of motor

f: operation frequency (Hz)

00.0	Power Boa	Power Board Software Version				
	Settings	Read Only				
	Display	#.##				
00.0	Control Boa	ard Software Version				
	Settings	Read Only				
	Display	#.##				
00	.08 Password	Input				
	Settings	0 to 9999	Factory Setting: 0			
	Display	0~2 (times of wrong password)				
Pass	The function of this parameter is to input the password that is set in Pr.00.09. Input the correct password here to enable changing parameters. You are limited to a maximum of 3 attempts. After 3 consecutive failed attempts, a blinking "codE" will show up to force the user to restart the AC motor drive in order to try again to input the correct password. Related parameter: Pr.00.09 (Password Set) assword Decode Flow Chart					



00.09	00.09 Password Set					
	Settings	0 to 9999	Factory Setting: 0			
	Display 0 No		No password set or successful input in Pr. 00.08			
		1	Password has been set			

To set a password to protect your parameter settings.

If the display shows 0, no password is set or password has been correctly entered in Pr.00.08. All parameters can then be changed, including Pr.00.09.

The first time you can set a password directly. After successful setting of password the display will show 1.

Be sure to record the password for later use.

To cancel the parameter lock, set the parameter to 0 after inputting correct password into Pr. 00.08.

The password consists of min. 1 digits and max. 4 digits.

How to make the password valid again after decoding by Pr.00.08:

Method 1: Re-input original password into Pr.00.09 (Or you can enter a new password if you want to use a changed or new one).

Method 2: After rebooting, password function will be recovered.

To lock parameters, you can set Pr.00.02 to 1 or Pr.04.05~04.08 to 17 to prevent changing of parameters settings by unqualified personnel. Please note that it is without password set.

00.10

Control Method

Factory Setting: 0

Settings V/f Control 0

Vector Control

- This parameter determines the control method of the AC motor drive.
- Control of V/f (Voltage/frequency)
 - 1. To operate by the change of frequency and voltage without changing the mechanical characteristic of motor: it can run by open-loop method and also can use with PG card (refer to Appendix B) to run by close-loop method. In this control, it gets the change of the electromagnetic torque of rotor and the load torque from the change of slip ratio.
 - 2. The V/f control is the constant value control mode. Although it prevents the main questions of the decreasing frequency and increasing magnetic field, the magnetic field is decreasing with frequency. In such circumstance, insufficient motor torque will occur when the magnetic field weakens in the low frequency. At this moment, it can get the best operation with Pr.07.02 setting(Torque Compensation) to get the torque compensation. common applications: pump, conveyor belt, compressor and treadmill
- Vector control:
 - 1. To operate by the change of frequency and voltage without changing the mechanical characteristic of motor: it can run by open-loop method and also can use with PG card (refer to Appendix B) to run by close-loop method. In this mode, it is coordinate change. The physical essence is the relativity of motion. That means the change of rotor current only has relation with electromagnetic torque and the change of stator current only has relation with electromagnetic torque. This is the characteristic of vector control.
 - 2. The vector control can eliminate the relation between electromagnetic current vector and armature flux. Thus, it can control the current vector and armature flux independently to raise the transient response of the AC motor drive.
 - Applications: textile equipment, press equipment, life equipment and drilling machine.
- Related parameter: Pr.07.02 (Torque Compensation (Motor 0))


00.11	Reserved			
00.12	50Hz Bas	e Volta	age Selection	
				Factory Setting: 0
	Settings	0	230V/400V	
	· ·	1	220V/380V	
	•		ermines the base voltage for 50Hz.	

- When Pr.00.02 is set to 9, the base voltage for 50Hz will set by Pr.00.12.
- Related parameter: Pr.00.02 (Parameter Reset)

Group 1: Basic Parameters

01.00	Maximum O	output Frequency (Fmax)	Unit: Hz
	Settings	50.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	Factory Setting: 60.00

- This parameter determines the AC motor drive's Maximum Output Frequency. All the AC motor drive frequency command sources (analog inputs 0 to +10V and 4 to 20mA) are scaled to correspond to the output frequency range.
- Please note that output frequency may be not in this setting range due to parameter setting: 1. Pr.00.10 is set to 0: when enabling Pr.07.03 (Slip Compensation) in V/f mode, it may be not in this setting range.
 - 2. Pr.00.10 is set to 1: The AC motor drive will auto compensate slip in vector mode, so it also may be not within this setting range.
- Related parameters: 00.10 (Control Method), 04.12(Min AVI Frequency), 04.14(Max AVI Frequency), 04.16(Min ACI Frequency), 04.18(Max ACI Frequency), 04.19(ACI/AVI2 Selection), 04.21(Min AVI2 Frequency), 04.23(Max AVI2 Frequency) and 07.03(Slip Compensation (Used without PG) (Motor 0))




01	1.01 Maximum Vo	Unit: Hz			
	Settings	0.10 to 600.0Hz	Factory Setting: 60.00		
		(Japanese version: 0.10 to 599.00 Hz)			
	This value should be set according to the rated frequency of the motor as indicated on the				

- motor nameplate. Maximum Voltage Frequency determines the v/f curve ratio. For example, if the drive is rated for 460 VAC output and the Maximum Voltage Frequency is set to 60Hz, the drive will maintain a constant ratio of 7.66 V/Hz (460V/60Hz=7.66V/Hz). This parameter value must be equal to or greater than the Mid-Point Frequency (Pr.01.03).
- If this parameter setting is less than the rated frequency of the motor, it may cause over current and damage the motor or trigger the over current protection.
- If this parameter setting is greater than the rated frequency of the motor, it may cause insufficient motor torque.
- Related parameters: Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr.01.03(Mid-Point Frequency (Fmid) (Motor 0)), Pr.01.04(Mid-Point Voltage (Vmid) (Motor 0)), Pr.01.05(Minimum Output Frequency (Fmin) (Motor 0)) and Pr.01.06(Minimum Output Voltage (Vmin) (Motor 0)).

01	.02 Maximum Output Voltage (Vmax) (Motor 0)	Unit: V
	Settings 115V/230V series 0.1	to 255.0V	Factory Setting: 220.0
	460V series 0.1	to 510.0V	Factory Setting: 440.0
	Output Voltage setting must be small	ler than or equal t	age of the AC motor drive. The Maximur to the rated voltage of the motor as ue must be equal to or greater than the
			nan this setting, the output voltage can't
		d voltage of the m	otor, it may cause over current of the ent protection.
		. •	notor, it may cause the insufficient motor
	Point Frequency (Fmid) (Motor 0)), F	r.01.04(Mid-Poin	uency (Fbase) (Motor 0)), Pr.01.03(Mid- t Voltage (Vmid) (Motor 0)),)) and Pr.01.06(Minimum Output Voltage
01	.03 Mid-Point Frequency (Fmid) (Mo	tor 0)	Unit: Hz
	Settings 0.10 to 600.00Hz (Japanese version: 0.1	0 to 599.00 Hz)	Factory Setting: 1.50
	between Minimum Frequency and M	id-Point frequenci imum Output Fre	/f curve. With this setting, the V/f ratio y can be determined. This parameter quency (Pr.01.05) and equal to or less
		nay cause over cu	irrent, it may cause motor overheat and
	Please note that unsuitable setting n When it is vector control, the settings This setting must be greater than Pr	s of Pr.01.03, Pr.0 01.05.	11.04 and Pr.01.06 are invalid.
	Related parameters: Pr.01.01(Maxin Pr.01.02(Maximum Output Voltage ((Motor 0)), Pr.01.05(Minimum Output Output Voltage (Vmin) (Motor 0)).	Vmax) (Motor 0)),	Pr,01.04(Mid-Point Voltage (Vmid)
01	.04 Mid-Point Voltage (Vmid) (Motor	0)	Unit: V
	Settings 115V/230V series 0.1	to 255.0V	Factory Setting: 10.0
	460V series 0.1	to 510.0V	Factory Setting: 20.0
	This parameter sets the Mid-Point Venture between Minimum Frequency and Minimum Frequency and Minimum Frequency and Minimum Fr.01.01 (Maximum Output Voltage (Motor 0)), Pr.01.05 (Minimum Output Voltage (Output Voltage (Vmin) (Motor 0)).	id-Point Frequenc greater than Minin num Voltage Freq Vmax) (Motor 0)),	cy can be determined. num Output Voltage (Pr.01.06). uency (Fbase) (Motor 0)), Pr,01.03(Mid-Point Frequency (Fmid)


01	.05 Minimum Output Frequency (Fmin) (Motor 0)	Unit: Hz				
	Settings 0.10 to 600.00Hz (Japanese version: 0.10 to 599.00 Hz)	Factory Setting: 1.50				
	This parameter sets the Minimum Output Frequency of the AC motor drive. If the frequency command is greater than this setting, the AC motor drive will accelerate to the frequency command by the accel./decel. time. If the frequency command is less than this setting, the AC motor drive will be ready without output voltage.					
	Please note that unsuitable setting may cause over current to dama over current protection.	age motor or trigger the				
	When Pr.08.04 is set to 1(Operation continues after momentary postarts with the Master Frequency reference value), it won't operate	•				
	starts with the Master Frequency reference value.), it won't operate by V/f curve. Related parameters: Pr.01.01(Maximum Voltage Frequency (Fbase) (Motor 0)), Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr,01.03(Mid-Point Frequency (Fmid) (Motor 0)), Pr.01.04(Mid-Point Voltage (Vmid) (Motor 0)) and Pr.01.06(Minimum Output Voltage (Vmin) (Motor 0))					
01	.06 Minimum Output Voltage (Vmin) (Motor 0)	Unit: V				
	Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0				
	460V series 0.1 to 510.0V	Factory Setting: 20.0				
Q	This parameter sets the Minimum Output Voltage of the AC motor of the setting is too large, it may cause over current to damage motor protection.					
	If the setting is too small, it may cause insufficient motor torque. The settings of Pr.01.01 to Pr.01.06 have to meet the condition of Pr.01.02 \geq Pr.01.04 \geq Pr.01.06 and Pr.01.01 \geq Pr.01.03 \geq Pr.01.05. By this condition, V/f curve is shown in the					
	following figure. In vector control mode (Pr.00.10 is set to 1), Pr.01.03, Pr.01.04 and Pr.01.06 are disabled. But					
	Pr.01.05 is still the minimum output frequency. The V/f curve of motor 0 to motor 3 can be selected by setting the multi-function input terminals MI3~MI6 (Pr.04.05 to Pr.04.08) to 27 and 28. To set the voltage and frequency for each motor, please refer to Pr.01.01~01.06 for motor 0 (factory setting), Pr.01.26~01.31 for motor 1, Pr.01.32~01.37 for motor 2 and Pr.01.38~01.43 for motor 3. Related parameters: Pr.01.01(Maximum Voltage Frequency (Fbase) (Motor 0)), Pr.01.03(Maximum Output Voltage (Vmax) (Motor 0)), Pr.01.03(Maximum Output Voltage (Vmax) (Motor 0)),					
	Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr,01.03(Mic (Motor 0)), Pr.01.04(Mid-Point Voltage (Vmid) (Motor 0)) and Pr.01 Frequency (Fmin) (Motor 0)).					



01	1.07	Output Fro	equency Upper Limit		Unit: %
		Settings	0.1 to 120.0%		Factory Setting: 110.0
	Thi	s paramete	r must be equal to or gr	eater than the Outpu	t Frequency Lower Limit (Pr.01.08).
	The	e Maximum	Output Frequency (Pr.0	01.00) is regarded as	100%.
	Out	tput Freque	ency Upper Limit value =	(Pr.01.00 * Pr.01.07	7)/100.
					nited by this setting. If the setting of
	frequency command is greater than Pr.01.07, the output frequency will be equal to or less than				
	Pr.0	01.07.	•	•	
	Wh	en enabling	g Pr.07.03 or Pr.10.00~	10.13, the output freq	quency of the AC motor drive may
	exc	eed the fre	quency command but it	is still limited by this	setting.
					(Fmax)) and Pr.01.08(Output
		quency Lov	`		


01.08	Output Fre	equency Lower Limit	Unit: %
	Settings	0.0 to 100.0%	Factory Setting: 0.0

- The Output Frequency Lower Limit value = (Pr.01.00 * Pr.01.08) /100.
- This setting will limit the min. output frequency of the AC motor drive. When the frequency command of the AC motor drive or the frequency calculated by feedback control is less than this setting, the output frequency of the AC motor drive will be limited by this setting.
- After starting running, the AC motor drive will accelerate from Pr.01.05 (Minimum Output Frequency (Fmin) (Motor 0)) to the setting frequency by V/f curve and won't be limited by this setting.
- The Upper/Lower Limits are to prevent operation errors and machine damage.
- If the Output Frequency Upper Limit is 50Hz and the Maximum Output Frequency is 60Hz, the Output Frequency will be limited to 50Hz.
- If the Output Frequency Lower Limit is 10Hz, and the Minimum Output Frequency (Pr.01.05) is set to 1.0Hz, then any Command Frequency between 1.0-10Hz will generate a 10Hz output from the drive. If the command frequency is less than 1.0Hz, drive will be in ready status without output.
- This parameter must be equal to or less than the Output Frequency Upper Limit (Pr.01.07).



01.09	∧ Accelera	ation Time 1 (Taccel 1)	Unit: second
01.10		ation Time 1 (Tdecel 1)	Unit: second
01.11	∧ Accelera	ation Time 2 (Taccel 2)	Unit: second
01.12		ation Time 2 (Tdecel 2)	Unit: second
	Settings	0.1 to 600.0 sec / 0.01 to 600.0 sec	Factory Setting: 10.0

- Acceleration/deceleration time 1 or 2 can be switched by setting the external terminals MI3~ MI12(MI7~MI12 are optional) to 7 (set Pr.04.05~Pr.04.08 to 7 or Pr.11.06~Pr.11.11 to 7). The factory settings are acceleration time 1.
- The Acceleration Time is used to determine the time required for the AC motor drive to ramp from 0 Hz to Maximum Output Frequency (Pr.01.00). The Deceleration Time is used to determine the time required for the AC motor drive to decelerate from the Maximum Output Frequency (Pr.01.00) down to 0 Hz.
- If the setting of the acceleration/deceleration time is too short, it may trigger the protection (Pr.06.01(Over-Current Stall Prevention during Accel) or Pr.06.00(Over-Voltage Stall Prevention)) and make the actual acceleration/deceleration time be larger than this setting.
- If the setting of the acceleration time is too short, it may cause over-current during acceleration and damage the motor or trigger the protection function.
- If the setting of the deceleration time is too short, it may cause over-current during deceleration or over voltage of the AC motor drive and damage the motor or trigger the protection function.
- It can use suitable brake resistor to decelerate the AC motor drive in short time and prevent internal over voltage. Refer to Appendix B for brake resistor.
- When enabling Pr.01.17(Acceleration S-Curve) and Pr.01.18(Deceleration S-Curve), the actual acceleration/deceleration time will be longer than the setting.
- Related parameters: Pr.01.16(Auto acceleration / deceleration (refer to Accel/Decel time setting)), Pr.01.17(Acceleration S-Curve), Pr.01.18(Deceleration S-Curve), Pr.04.05(Multifunction Input Terminal (MI3)), Pr.04.06(Multifunction Input Terminal (MI4)), Pr.04.07(Multifunction Input Terminal (MI5)) and Pr.04.08(Multifunction Input Terminal (MI6))




01.19 Accel/Decel Time Unit

Factory Setting: 0


Settings 0 Unit: 0.1 sec 1 Unit: 0.01 sec

- The Acceleration/Deceleration Time 1, 2, 3, 4 are selected according to the Multi-function Input Terminals Settings. See Pr.04.05 to Pr.04.08 for more details.
- In the diagram shown below, the Acceleration/Deceleration Time of the AC motor drive is the time between 0 Hz to Maximum Output Frequency (Pr.01.00). Suppose the Maximum Output Frequency is 60 Hz, Minimum Output Frequency (Pr.01.05) is 1.0 Hz, and Acceleration/Deceleration Time is 10 seconds. The actual time for the AC motor drive to accelerate from start-up to 60 Hz and to decelerate from 60Hz to 1.0Hz is in this case 9.83 seconds. ((60-1) * 10/60=9.83secs).



01.13	✓ Jog Acce	leration Time	Unit: second
	Settings	0.1 to 600.0/0.01 to 600.0 sec	Factory Setting: 1.0
01.14	✓ Jog Dece	eleration Time	Unit: second
	Settings	0.1 to 600.0/0.01 to 600.0 sec	Factory Setting: 1.0
01.15	✓ Jog Frequence	uency	Unit: Hz
	Settings	0.10 to 600.00Hz (Japanese version: 0.10 to 599.00 Hz)	Factory Setting: 6.00

- Only external terminal JOG (MI3 to MI12) can be used. Please set one of MI3~MI12 (MI7~MI12 are optional) to 8 for JOG operation. When the Jog command is "ON", the AC motor drive will accelerate from Minimum Output Frequency (Pr.01.05) to Jog Frequency (Pr.01.15). When the Jog command is "OFF", the AC motor drive will decelerate from Jog Frequency to zero.
- The used Accel/Decel time is set by the Jog Accel/Decel time (Pr.01.13, Pr.01.14).
- Before using the JOG command, the drive must be stopped first. And during Jog operation, other operation commands are not accepted, except commands via the FORWARD, REVERSE and STOP keys on the digital keypad.




01.16 ✓ Auto-Acceleration / Deceleration

Factory Setting: 0

		r actory octung.
Settings	0	Linear acceleration / deceleration
	1	Auto acceleration, linear Deceleration.
	2	Linear acceleration, auto Deceleration.
	3	Auto acceleration / deceleration (set by load)
	4	Auto acceleration / deceleration (set by Accel/Decel Time setting)
	5	Linear Accel. controlled by current, linear Decel.
	6	Linear Accel. controlled by current, auto Decel.

Linear acceleration/deceleration: the acceleration/deceleration that acts according to the acceleration/deceleration time set by Pr.01.09~01.12.

- With Auto acceleration / deceleration it is possible to reduce vibration and shocks during starting/stopping the load.
- When Pr.01.16 is set to 3 Auto acceleration / deceleration (set by load): During Auto acceleration the torque is automatically measured and the drive will accelerate to the set frequency with the fastest acceleration time and the smoothest starting current. During Auto deceleration, regenerative energy is measured and the motor is smoothly stopped with the fastest deceleration time.
- When this parameter is set to 4 Auto acceleration / deceleration (set by Accel/Decel Time setting): the actual accel/decel time will be equal to or more than parameter Pr.01.09 ~Pr.01.12.
- When this parameter is set to 5(Linear Accel. controlled by current, linear Decel.)/6(Linear Accel. controlled by current, auto Decel.): the current value when the drive performs overcurrent stall prevention can be kept within the setting of stall prevention level. For example, if the setting of stall prevention level is 100%, it will perform deceleration as the current exceeds 100% during operation and keep the current around 100%. Besides, it will perform deceleration no matter over-current occurs during deceleration or constant speed. (The present over-current stall prevention during acceleration is used to keep the output frequency and prevent from the drive overload (OL).
- When this parameter is set to 5(Linear Accel. controlled by current, linear Decel.): the drive will perform the linear deceleration by the setting of deceleration time. When this parameter is set to 6 (Linear Accel. controlled by current, auto Decel.), the drive stop the motor by the fastest deceleration time after auto-distinguish load regenerative energy.



- Auto acceleration/deceleration makes the complicated processes of tuning unnecessary. It makes operation efficient and saves energy by acceleration without stall and deceleration without brake resistor.
- In applications with brake resistor or brake unit, the deceleration time is the shortest. It is NOT recommended to use Auto deceleration function, or it will extend the deceleration time.
- Related parameters: Pr.01.09(Accel Time 1), Pr.01.10(Decel Time 1), Pr.01.11(Accel Time 2) and Pr.01.12(Decel Time 2).


01.17	Acceleration S-Curve	Unit: second
01.18	Deceleration S-Curve	Unit: second
_		Factory Setting: 0.0/0.00

Factory Setting: 0.0/0.00

Settings 0.0 S-curve disabled 0.1 to 10.0/0.01 to 10.00 S-curve enabled (10.0/10.00 is the smoothest)

- This parameter is used to ensure smooth acceleration and deceleration via S-curve. The S-curve is disabled when set to 0.0 and enabled when set to 0.1 to 10.0/0.01 to 10.00. Setting 0.1/0.01 gives the quickest and setting 10.0/10.00 the longest and smoothest S-curve. The AC motor drive will not follow the Accel/Decel Times in Pr.01.09 to Pr.01.12.
- The diagram below shows that the original setting of the Accel/Decel Time is only for reference when the S-curve is enabled. The actual Accel/Decel Time depends on the selected S-curve (0.1 to 10.0).

The total Accel. Time=Pr.01.09 + Pr.01.17 or Pr.01.11 + Pr.01.17 The total Decel. Time=Pr.01.10 + Pr.01.18 or Pr.01.12 + Pr.01.18




Acceleration/deceleration Characteristics

Related parameters: Pr.01.09(Accel Time 1), Pr.01.10(Decel Time 1), Pr.01.11(Accel Time 2) and Pr.01.12(Decel Time 2).

01.20	Delay Time at 0Hz for Simple Position	Unit: second
01.21	Delay Time at 10Hz for Simple Position	Unit: second
01.22	Delay Time at 20Hz for Simple Position	Unit: second
01.23	Delay Time at 30Hz for Simple Position	Unit: second
01.24	Delay Time at 40Hz for Simple Position	Unit: second
01.25	Delay Time at 50Hz for Simple Position	Unit: second
	Settings 0.00 to 600.00 sec	Factory Setting: 0.00

- This simple position function is calculated by the measure of operation distance. When the multi-function input terminal is set to 25 and it is ON, it will start to decelerate after getting the delay time from Pr.01.20 to Pr.01.25 and get the final position.
- This is simple position function NOT the precision position function.



$$S = n \times \left(\frac{t_x + (t_x + t_2)}{2}\right)$$

$$n = f \times \frac{120}{p}$$

S: operation distance

n: rotation speed(revolution/second)

tx: delay time (sec)


t2: deceleration time(sec)

n: rotation speed(revolution/second)

P: pole number of motor

f: operation frequency

Assume that the radius of the 4-pole motor is r and rotation speed is n (rpm).




Example 1:

Assume that motor speed is 50Hz, the delay time at 50Hz is 2 sec (Pr.01.25=2) and the deceleration time from 50Hz to 0Hz is 10 seconds.

The rotation speed n = 120 X 50 /4 (rpm/min) = 25 rpm/sec

The revolution numbers = $(25 \times (2+12))/2 = 175$ (revolutions)



Therefore, the distance = revolution numbers X circumference = 175 X 2π r It also means that the motor will stop to the original position after 175 circles.


Example 2:

Assume that motor speed is 1.5Hz, the delay time at 10Hz is 10 sec (Pr.01.21=10) and the deceleration time from 60Hz to 0Hz is 40 seconds.

The delay time at 1.5Hz is 1.5 sec and the deceleration from 1.5Hz to 0Hz is 1 sec.

The rotation speed $n = 120 \times 1.5 / 4 \text{ (rpm/min)} = 1.5/2 \text{ rpm/sec} = 0.75 \text{ rpm/sec}$

The revolution numbers = (1.5/2X (1.5+2.5))/2 = 1.5 (revolutions)



Therefore, the distance = revolution numbers X circumference = 1.5 X 2π r It also means that the motor will stop after running 1.5 circles.

	01.26	Maximum Vol	Unit: Hz	
		Settings	0.10 to 600.0Hz	Factory Setting: 60.00
			(Japanese version: 0.10 to 599.00 Hz)	
I	01.27	Maximum Ou	tput Voltage (Vmax) (Motor 1)	Unit: V
		Cottings 115	\//220\/ aprice_0_1 to 255_0\/	Factory Sotting: 220.0

Settings 115V/230V series 0.1 to 255.0V

460V series 0.1 to 510.0V	Factory Setting: 440.0
01.28 Mid-Point Frequency (Fmid) (Motor 1)	Unit: Hz
Settings 0.10 to 600.00Hz (Japanese version: 0.10 to 599.00 Hz)	Factory Setting: 1.50
01.29 Mid-Point Voltage (Vmid) (Motor 1)	Unit: V
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0
460V series 0.1 to 510.0V	Factory Setting: 20.0
01.30 Minimum Output Frequency (Fmin) (Motor 1)	Unit: Hz
Settings 0.10 to 600.00Hz (Japanese version: 0.10 to 599.00 Hz)	Factory Setting: 1.50
01.31 Minimum Output Voltage (Vmin) (Motor 1)	Unit: V
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0
460V series 0.1 to 510.0V	Factory Setting: 20.0
01.32 Maximum Voltage Frequency (Fbase) (Motor 2)	Unit: Hz
Settings 0.10 to 600.0Hz (Japanese version: 0.10 to 599.00 Hz)	Factory Setting: 60.00
01.33 Maximum Output Voltage (Vmax) (Motor 2)	Unit: V
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 220.0
460V series 0.1 to 510.0V	Factory Setting: 440.0
01.34 Mid-Point Frequency (Fmid) (Motor 2)	Unit: Hz
Settings 0.10 to 600.00Hz (Japanese version: 0.10 to 599.00 Hz)	Factory Setting: 1.50
01.35 Mid-Point Voltage (Vmid) (Motor 2)	Unit: V
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0
460V series 0.1 to 510.0V	Factory Setting: 20.0
01.36 Minimum Output Frequency (Fmin) (Motor 2)	Unit: Hz
Settings 0.10 to 600.00Hz (Japanese version: 0.10 to 599.00 Hz)	Factory Setting: 1.50
01.37 Minimum Output Voltage (Vmin) (Motor 2)	Unit: V
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0
460V series 0.1 to 510.0V	Factory Setting: 20.0
01.38 Maximum Voltage Frequency (Fbase) (Motor 3)	Unit: Hz
Settings 0.10 to 600.0Hz	Factory Setting: 60.00
01.39 Maximum Output Voltage (Vmax) (Motor 3)	Unit: V
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 220.0
460V series 0.1 to 510.0V	Factory Setting: 440.0

Unit: Hz
Factory Setting: 1.50
Unit: V
Factory Setting: 10.0
Factory Setting: 20.0
Unit: Hz
Factory Setting: 1.50
Unit: V
Factory Setting: 10.0
Factory Setting: 20.0

- The V/f curve of motor 0 to motor 3 can be selected by setting the multi-function input terminals MI3~MI6 (Pr.04.05 to Pr.04.08) to 27 and 28. To set the voltage and frequency for each motor, please refer to Pr.01.01~01.06 for motor 0 (factory setting), Pr.01.26~01.31 for motor 1, Pr.01.32~01.37 for motor 2 and Pr.01.38~01.43 for motor 3.
- Related parameters: Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))

Group 2: Operation Method Parameters

02.	⊘ Source of	of First	Master Frequency Command
			Factory Setting: 1
02.	⊘ Source o	of Seco	nd Master Frequency Command
	<u> </u>		Factory Setting: 0
	Settings	0	Digital keypad UP/DOWN keys or Multi-function Inputs UP/DOWN. Last used frequency saved. (Digital keypad is optional)
		1	0 to +10V from AVI
		2	4 to 20mA from ACI or 0 to +10V from AVI2
		3	RS-485 (RJ-45)/USB communication
		4	Digital keypad potentiometer
	The factory set to Appendix B Setting 2: use a AVI, AVI2 is infor 4 to 20mA a voltage signal. When the 3 rd s diagram, the so setting(Pr.02.0 When the AC r PR.02.09 is on the source of the source of frequentime. Related paramalinput Terminal	tting for for deta the ACI dicated analog (AVI2) witch o ource o 0) can't motor d ly valid ne frequency con- eters: F (MI4)),	the Master Frequency Command Source of the AC motor drive. master frequency command is 1. (digital keypad is optional, please refeals.) I/AVI switch on the AC motor drive to select ACI or AVI2. When setting to the setting to the ACI/AVI switch on the AC motor drive. Switch to ACI current signal (ACI) (Pr.04.19 should be set to 0) and AVI for analog (Pr.04.19 should be set to 1). In the upper-right corner is set to be ON as shown in the following of first master frequency command (Pr.02.00) will force setting to 2. This to be changed till the 3 rd switch is set to be OFF. Tive is controlled by external terminal, please refer to Pr.02.05 for details when one of Pr.04.05~04.08 is set to 22. When setting 22 is activated, using using the setting of Pr.02.09. The factory setting of the ommand is the first frequency command. Only one of the source of first mand and second master frequency command can be enable at one Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Pr.04.07(Multi-function Input Terminal (MI5)), Pr.04.08(Multi-function and Pr.04.19 (ACI/AVI2 Selection)
02.0	✓ Source o	f First (Operation Command
			Factory Setting: 1
	Settings	0	Digital keypad (Digital keypad is optional)
		1	External terminals. Keypad STOP/RESET enabled.
		2	External terminals. Keypad STOP/RESET disabled.
		3	RS-485 (RJ-45)/USB communication. Keypad STOP/RESET enabled.
		4	RS-485 (RJ-45)/USB communication. Keypad STOP/RESET

The factory setting for source of first operation command is 1. (digital keypad is optional.)

disabled.

When the AC motor drive is controlled by external terminal, please refer to Pr.02.05/Pr.04.04 for details.

02.10

Factory Setting: 0

Settings 0 First Master Frequency Command Only

1 First Master Frequency + Second Master Frequency

2 First Master Frequency - Second Master Frequency


- It can be used to add or subtract the first frequency set in Pr.02.00 and the second frequency set in Pr.02.09 to meet the customers' application. For example, if the master frequency is the first frequency, speed source, controlled by ACI (DC 4~20mA) and the second frequency, press source, is controlled by AVI(DC 0~+10V). These two frequencies can be added or subtracted by Pr.02.10.
- Related parameters: Pr.02.00(Source of First Master Frequency Command) and Pr.02.09(Source of Second Frequency Command).

02.02 Stop Method

Factory Setting: 0

Settings 0 STOP: ramp to stop E.F.: coast to stop
1 STOP: coast to stop E.F.: coast to stop
2 STOP: ramp to stop E.F.: ramp to stop
3 STOP: coast to stop E.F.: ramp to stop

When the 2nd switch on the upper-right corner is set to be ON as shown in the following diagram, the motor stop method (Pr.02.02) will force setting to 1. This setting (Pr.02.02) can't be changed till the 2nd switch is set to be OFF.



- E.F. is external fault. It can be triggered by setting one of Pr.04.05~04.08 to 14. When the AC motor drive receives the trigger, it will stop output immediately and display EF on the keypad. The motor won't run till the fault is cleared (enter "RESET).
- The parameter determines how the motor is stopped when the AC motor drive receives a valid stop command or detects External Fault.

Ramp: the AC motor drive decelerates to Minimum Output Frequency (Pr.01.05)

according to the deceleration time(Pr.01.10 and Pr.01.12) and then stops.

Coast: the AC motor drive stops the output instantly upon command, and the motor


free runs until it comes to a complete standstill.

The motor stop method is usually determined by the characteristics of the motor load and how frequently it is stopped.


- (1) It is recommended to use "ramp to stop" for safety of personnel or to prevent material from being wasted in applications where the motor has to stop after the drive is stopped. The deceleration time has to be set accordingly.
- (2) If motor free running is allowed or the load inertia is large, it is recommended to select "coast to stop". For example: blowers, punching machines, centrifuges and pumps.
- Related parameters: Pr.01.10(Decel Time 1), Pr.01.12(Decel Time 2), Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr. 04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))



The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.



ramp to stop and free run to stop



02.03 PWM Carrier Frequency Selections

Unit: Hz

115V/230V/460V Series			
Power	0.25 to 15hp (0.2kW to 22kW)		
Setting Range	1 to 15 kHz		
Factory Setting	8 kHz		

This parameter determines the PWM carrier frequency of the AC motor drive.

	Carrier Frequency	Acoustic Noise	Electromagnetic Noise or leakage current	Heat Dissipation	Current Wave
	1kHz	Significant	Minimal ↑	Minimal ↑	Minimal †
	8kHz				
-	15kHz	↓ Minimal	↓ Significant	↓ Significant	Significant

- From the table, we see that the PWM carrier frequency has a significant influence on the electromagnetic noise, AC motor drive heat dissipation, and motor acoustic noise.
- The PWM carrier frequency will be decreased automatically by heat sink temperature and output current of the AC motor drive. It is used as a necessary precaution to prevent the AC motor drive from overheating and thus extends IGBT's life. If the user wants to fix carrier within the rated range and won't change by the change of the surrounding temperature and frequently load. Please refer to Pr.02.18 for Selection of Carrier Modulation.
- Related parameters: Pr.02.18(Selection of Carrier Modulation) and Pr.03.08(Fan Control).

Motor Direction Control

Factory Setting: 0

Settings 0 Forward/Reverse operation enabled

1 Reverse operation disabled

2 Forward operation disabled


This parameter is used to disable one direction of rotation of the AC motor drive direction of rotation to prevent damage due to operation errors.

The motor direction also can be limited by setting one of Pr.04.05~04.08 to 21.

Related parameters: Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr. 04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))


Rotating direction of the motor

Rotating forward command from the motor drive



Clockwiseyl

Rotating reversely command from the motor drive



Counter-clockwisely

The source of Power-On command and Running command modifies the operating

control of the VFD

Settings Factory Setting: 1

0: Start running when Power is on.

1: Don't run when Power is on

2: When the source of the command changes, VFD's operation remains the same.

3: When the source of the command changes, VFD's operation follows the new command.

4: The motor drive can start to run at power on or after reset.

When the source of command is a 2-wire external terminal, the operating command changes as the external terminal's status changes.

This parameter determines the response of the drive upon power on and operation command source is changed.


Pr.02.05	Start lockout (Run when power is ON)	Operation status when operation command source is changed
0	Disable (AC motor drive will run)	Keep previous status
1	Enable (AC motor drive doesn't run)	Keep previous status
2	Disable (AC motor drive will run)	Change according to the new operation command source

3	Enable (AC motor drive doesn't run)	Change according to the new operation command source
4	Disable (AC motor drive will run)	Changes as the external terminal's status changes

When the operation command source is from external terminal and operation command is ON (NPN mode: MI1/MI2-DCM=closed, PNP mode: MI1/MI2+24V=closed, please refer to chapter 2 wiring for details), the AC motor drive will operate according to Pr.02.05 after power is applied. <For terminals MI1 and MI2 only>

Setting #4 is an external terminal control setting when the motor drive restarts after an instantaneous power failure. When the motor drive has an instantaneous power failure, the DC bus will decrease to LV. If a command is sent from the host computer while the DC bus is at LV and the operating command is still conductive trigger, the motor drive can be restarted.


- 1. When Pr.02.05 is set to 0 or 2 or 4, AC motor drive will run immediately.
- When Pr.02.05 is set to 1 or 3, AC motor drive will remain stopped until operation command is received after previous operation command is cancelled.



- When the operation command source isn't from the external terminals, independently from whether the AC motor drive runs or stops, the AC motor drive will operate according to Pr.02.05 if the two conditions below are both met.
 - 1. When operation command source is changed to external terminal (Pr.02.01=1 or 2)
 - 2. The status of terminal and AC motor drive is different.

And the operation of the AC motor drive will be:

- 1. When setting 0 or 1, the status of AC motor drive is not changed by the terminal status.
- 2. When setting 2 or 3 or 4, the status of AC motor drive is changed by the terminal status.



- When Pr.02.05 is set to 1 or 3, it does not guarantee that the motor will never run under this condition. It is possible the motor may be set in motion by a malfunctioning switch.
- Related parameters: Pr.02.01(Source of First Operation Command)


02.0	Loss of AC	Loss of ACI Signal (4-20mA)		
			Factory Setting:	
	Settings	0	Decelerate to 0Hz	
		1	Coast to stop and display "AErr"	
		2	Continue operation by the last frequency command	
	This serves at a		sing a the halo view where AOI is lost	

- This parameter determines the behavior when ACI is lost.
- When setting to 1, it will display warning message "AErr" on the keypad(optional) in case of loss of ACI signal and execute the setting. The AC motor drive will stop outputting immediately, the motor will free run to stop. Please press "RESET" key to clear it.
- When setting 0 or 2, it will not display warning message "AErr" on the keypad(optional) in case of loss of ACI signal and execute the setting. If it is set to 0, the motor will decelerate to 0Hz by the setting of deceleration time (Pr.01.10/Pr.01.12). If it is set to 2, the motor will continue to run. For these two settings, the warning message will stop blinking when ACI signal is recovered. Please press "RESET" key to clear it.
- Related parameters: Pr.01.10(Decel Time 1) and Pr.01.12(Decel Time 2)


02.07	Up/Down I	Mode	
			Factory Setting: 0
	Settings	0	By digital keypad up/down keys mode
		1	Based on Accel/Decel Time acc. to Pr.01.09 to 01.12
		2	Constant speed (acc. to Pr. 02.08)
		3	Pulse input unit (acc. to Pr. 02.08)
	ia naramata	r dotorm	ince the increase/degreese of the master frequency when energed via

This parameter determines the increase/decrease of the master frequency when operated via the Multi-function Inputs when Pr.04.05~Pr.04.08 are set to 10 (Up command) or 11 (Down command).


When Pr.02.07 is set to 0, it uses the external terminals UP/DOWN key to increase/decrease the frequency (F) as shown at the right of the following figure. Its function is the same as the UP/DOWN key on the digital keypad. In this mode, it also can use UP/DOWN key on the keypad to control.




When Pr.02.07 is set to 1: increase/decrease the frequency by acceleration/deceleration settings(Pr.01.09~01.12). It is valid only when the AC motor drive is running.



When Pr.02.07 is set to 2: use multi-function input terminal ON/OFF to increase/decrease the frequency by Pr.02.08.



When Pr.02.07 is set to 3: increase/decrease the frequency by Pr.02.08 (unit: pulse input). Every ON after OFF is regarded as a input pulse.



Related parameters: Pr.02.08(Accel/Decel Rate of Change of UP/DOWN Operation with Constant Speed), Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)), Pr.04.08(Multi-function Input Terminal (MI6))

02.08	Accel/Dece Constant S	el Rate of Change of UP/DOWN Operation with Speed	Unit: Hz/2ms
	Settings	0.01~10.00 Hz/2ms	Factory Setting: 0.01

This parameter determinates the constant speed When Pr.02.08 is set to 2 or 3.

02.	.11	Frequency Command	Unit: Hz
	Settings	0.00 to 600.00Hz (Japanese version: 0.00 to 599.00 Hz)	Factory Setting: 60.00
	•	r can be used to set frequency command or reneters: Pr.02.12 (Communication Frequency Communication Fr	• • • • • • • • • • • • • • • • • • • •
02.	12 ⊮ Commur	nication Frequency Command	Unit: Hz
	Settings	0.00 to 600.00Hz (Japanese version: 0.00 to 599.00 Hz)	Factory Setting: 60.00
	command.	r can be used to set frequency command or re parameter for remote control via communication	, ,
02.	The Select	tions for Saving Keypad or Communication Fre	equency Command

This parameter is used to save keypad or RS-485 frequency command.

Settings

0

1

2

Save Keypad & Communication Frequency

Save Communication Frequency only (Not for VFD*E*C model)

Save Keypad Frequency only

Factory Setting: 0

Chapter 4 Parameters Setting 0: After the AC motor drive is power off, save keypad and communication frequency in the AC motor drive. Setting 1: After the AC motor drive is power off, only save keypad frequency in the AC motor drive and won't save communication frequency. Setting 2: After the AC motor drive is power off, only save communication frequency in the AC motor drive and won't save keypad frequency. The keypad or communication frequency only can be saved when Pr. 02.00/Pr.02.09=0 (the source of frequency is from keypad) or Pr.02.00/Pr.02.09=3(the source of frequency is from communication). Related parameters: Pr.02.00(Source of First Master Frequency Command) and Pr.02.09(Source of Second Frequency Command).

02.14	Initial Freq	uency	Selection (for keypad & RS485/USB)	
				Factory Setting: 0
	Settings	0	By Current Freq Command	
		1	By Zero Freq Command	
		2	Refer to Pr02-25 to set up	
02.15	Initial Freq	uency	Set point (for keypad & RS485/USB)	Unit: Hz
	Settings		0 ~ 600.00Hz canese version: 0.00 to 599.00 Hz)	Factory Setting: 60.00
,	When setting F When setting F	Pr.02.1	e used to determinate the frequency at stop: 4 to 0: the initial frequency will be current frequency will be 0. 4 to 1: the initial frequency will be 0. 4 to 2: the initial frequency will be Pr.02.15.	uency.

02.16 Display the Master Freq Command Source

Settings Read Only

Factory display: 1

You can read the master frequency command source by this parameter.

Display Value	Bit	Function
1	Bit0=1	Master Freq Command Source by First Freq Source (Pr.02.00).
2 Bit1=1		Master Freq Command Source by Second Freq Source (Pr.02.09).
4	Bit2=1	Master Freq Command Source by Multi-input function
8 Bit3=1		Master Freq Command Source by PLC Freq command (NOT for VFD*E*C models)

When it displays 4, it means that the master frequency command source is from multi-input function. Thus, when Pr.04.05~04.08 are set to 1(Multi-Step speed command 1), 2(Multi-Step

speed command 2), 3(Multi-Step speed command 3), 4(Multi-Step speed command 4), 8(Jog Operation), 10(Up: Increment master frequency) and 11(Down: Decrement master frequency), it displays 4 in Pr.02.16.

Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)), Pr.04.08(Multi-function Input Terminal (MI6))

02.17 Display the Operation Command Source

Settings Read Only

Factory display: 4

You can read the operation source by this parameter.

Display Value	Bit	Function
1	1 Bit0=1 Operation Command Source by Digital Keypad	
2	Bit1=1	Operation Command Source by RS485 communication
4	Bit2=1	Operation Command Source by External Terminal
8 Bit3=1 Operation Command Source by Mu		Operation Command Source by Multi-input function
16	Bit4=1	Operation Command Source by PLC Operation Command (NOT for VFD*E*C models)
32	Bit5=1	Operation Command Source by CANopen Communication Interface

- When it displays 8, it means that the operation command source is from multi-input function. Thus, when Pr.04.05~04.08 are set to 8(Jog Operation), 18(Operation command selection (external terminals)), 19(Operation command selection(keypad)), 20(Operation command selection (communication)) and 21(FWD/REV command), it will display 8 in Pr.02.17.
- Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)), Pr.04.08(Multi-function Input Terminal (MI6))

02.18

Selection for Carrier Modulation

Factory Setting: 0


Settings

- 0 By carrier modulation of load current and temperature
- 1 By carrier modulation of load current
- Setting 0: The PWM carrier frequency (Fc) will be decreased automatically by heat sink temperature and output current of the AC motor drive. Please refer to the following figure for the decreasing the PWM carrier frequency. It is used as a necessary precaution to prevent the AC motor drive from overheating and thus extends IGBT's life. Example for 460V models: Assume the carrier frequency to be 15kHz, the ambient temperature is 35 degrees C with a single AC motor drive(mounting method A). If the output current exceeds 80% * rated current, the AC motor drive will decrease the carrier frequency automatically according to the following figure. If output current is 100% * rated current, the carrier frequency will decrease from 15kHz to 12kHz.


Mounting method

Method A


Frame A




Frame B & C




Method B Frame A




Frame B & C




The relation between rated current and carrier frequency





- Setting 1: to prevent the AC motor drive from overheating and thus extends IGBT's life and also prevent carrier change and motor noise due to surrounding temperature and frequently load change, it needs to use this setting. Please refer to the following figure for the selection of carrier frequency and rated current. For example, when carrier frequency should be kept in 15Hz, the rated current of the AC motor drive must be 65%. That means the rated current for over load is 150% * 65% =97.5%. Thus, the rated current should be within the range of the following figure to keep the carrier frequency at a fix frequency.
- Related parameter: Pr.02.03 (PWM Carrier Frequency Selections)



02.19	Selection	of Zero	speed control mode
			Factory Setting: 0
	Settings	0	Enter standby mode when zero speed
		1	Run DC brake when zero speed(the max. output voltage *0.05)

Group 3: Output Function Parameters

03.00 Multi-function Output Relay (RA1, RB1, RC1)

Factory Setting: 8

03.01 Multi-function Output Terminal MO1


Factory Setting: 1

Settings	Function	Description
0	No Function	
1	AC Drive Operational	Active when the drive is ready or RUN command is "ON".
2	Master Frequency (F) Attained	Active when the output frequency(H) of AC motor drive reaches the output frequency(F) setting.
3	Zero Speed	Active when Command Frequency is lower than the Minimum Output Frequency.
4	Over-Torque Detection(OL2)	Active as long as over-torque is detected. (Refer to Pr.06.03 ~ Pr.06.05)
5	Baseblock (B.B.) Indication	Active when the output of the AC motor drive is shut off during baseblock. Base block can be forced by Multi-function input (setting 09).
6	Low-Voltage Indication	Active when low voltage (Lv) is detected.
7	Operation Mode Indication	Active when operation command is controlled by external terminal.
8	Fault Indication	Active when the drive detects abnormal conditions (except Lv and bb) occurs, the contact will be "closed" (eg.:oc, ov, oH, oL, oL1, EF, cF3, HPF, ocA, ocd, ocn, GFF).
9	Desired Frequency 1 Attained	Active when the desired frequency 1(Pr.03.02) is attained.
10	Terminal Count Value Attained	Active when the internal counter reaches Terminal Count Value.
11	Preliminary Count Value Attained	Active when the internal counter reaches Preliminary Count Value.

Chapter 4 i	Parameters	
Settings	Function	Description
12	Over Voltage Stall supervision	Active when the Over Voltage Stall function(Pr.06.00) operating
13	Over Current Stall supervision	Active when the Over Current Stall function(Pr.06.01, Pr.06.02) operating
14	IGBT Overheat Warning	When IGBT overheats, it will signal to prevent OH turn off the drive. When it is higher than 85°C (185°F), it will be ON. When it is Lower than 80°C (180°F), it will be OFF.
15	Over Voltage supervision	Active when the DC-BUS voltage exceeds level
16	PID supervision	Active when the PID feedback signal is abnormal (Refer to Pr.10.12 and Pr.13.)
17	Forward command	Active when the direction command is FWD
18	Reverse command	Active when the direction command is REV
19	Zero Speed Output Signal	Active when the drive is standby or stop
20	Communication Warning (FbE,Cexx, AoL2, AUE, SAvE)	Active when there is a Communication Warning
21	Brake Control (Desired Frequency Attained)	Active when output frequency ≥Pr.03.11. Deactivated when output frequency ≤Pr.03.12 after STOP command.
22	Drive Ready	Active when the drive is on and no abnormality detected.
23	Desired Frequency 2 Attained	Active when the desired frequency 1(Pr.03.14) is attained.
24	Function of Output Frequency Control Multi- output terminal ON/OFF	Active when the drive output frequency is higher than 03-11 level, the terminal is closed; Active when the output frequency is less than 03-12, the terminal is opened.

03.02	Desired Frequency 1 Attained Unit: 0.			
03.14	Desired From	equency 2 Attained	Unit: 0.01	
	Settings	0.00 to 600.00 Hz (Japanese version: 0.00 to 599.00 Hz)	Factory Setting: 0.00	

- If a multi-function output terminal is set to function as Desired Frequency Attained 1(Pr.03.00 to Pr.03.01=09), then the output will be activated when the output frequency reaches Pr.03.02 setting.
- If a multi-function output terminal is set to function as Desired Frequency Attained 2(Pr.03.00 to Pr.03.01=23), then the output will be activated when the output frequency reaches Pr.03.14 setting.
- Related parameters: Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)) and Pr.03.01(Multi-function Output Terminal MO1)



output timing chart of multiple function terminals(Pr.03.00/Pr.03.01) when setting to frequency attained or zero speed indication



When the output frequency reaches the setting frequency, the detection ranges for the multi-function output terminals are: ±2Hz (from OFF to ON) and ±4Hz (from ON to OFF). The detection range for the output frequency reaches the desired frequency is -2Hz.

03.03				
			Factory Setting: 0	
	Settings	0	Analog Frequency Meter (0 to Maximum Output Frequency)	
		1	Analog Current Meter (0 to 250% of rated AC motor drive current)	

This parameter sets the function of the AFM output 0~+10VDC (ACM is common). Refer to Pr.03.04 for applications.

Related parameters: Pr.01.00(Maximum Output Frequency (Fmax)) and Pr.03.04(Analog Output Gain)

03.04	∧ Analog C	Output Gain	Unit: %
	Settings	1 to 200%	Factory Setting: 100

- This parameter sets the voltage range of the analog output signal AFM.
- When Pr.03.03 is set to 0, the analog output voltage is directly proportional to the output frequency of the AC motor drive. With Pr.03.04 set to 100%, the Maximum Output Frequency (Pr.01.00) of the AC motor drive corresponds to +10VDC on the AFM output.
- Similarly, if Pr.03.03 is set to 1, the analog output voltage is directly proportional to the output current of the AC drive. With Pr.03.04 set to 100%, then 2.5 times the rated current corresponds to +10VDC on the AFM output.



Any type of voltmeter can be used. If the meter reads full scale at a voltage less than 10V, Pr. 03.04 should be set using the following formula:

Pr. 03.04 = ((meter full scale voltage)/10) x 100%

For Example: When using the meter with full scale of 5 volts, adjust Pr.03.04 to 50%. If Pr.03.03 is set to 0, then 5VDC will correspond to Maximum Output Frequency.


03.	05 Terminal Cour	nt Value	
	Settings	0 to 9999	Factory Setting: 0
	•		ue of the internal counter. To increase the internal counter,
	Upon completion	of counting, the	e set to 12. It can be used in the counter control application. specified output terminal will be activated. (Pr.03.00 to ue will be reset after reaching the setting of Pr.03.05)
	Related paramete function Output Te	ers: Pr.03.00(Mu erminal MO1), F minal (MI4)), Pr	Iti-function Output Relay (RA1, RB1, RC1)), Pr.03.01(Multi- Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi- .04.07(Multi-function Input Terminal (MI5)) and



When the display shows c555, the drive has counted 555 times. If display shows c555•, it means that real counter value is between 5,550 and 5,559.

03.06 Preliminary Count Value					
	Settings	0 to 9999	Factory Setting: 0		
	When the counterminal will be		this value, the corresponding multi-function output		
	one of Pr.04.05		internal counter. To increase the internal counter, 12. Upon completion of counting, the specified output 03.01 set to 11).		
	It can be used a	as an indication for the AC	motor drive run in low speed to stop.		
	•	•	on Output Relay (RA1, RB1, RC1)), Pr.03.01(Multi-		
	•	,.	Multi-function Input Terminal (MI3)), Pr.04.06(Multi-		
	•	, ,,,	ulti-function Input Terminal (MI5)) and		
	Pr.04.08(Multi-f	unction Input Terminal (MI	6)		

Example: The timing diagram for Pr.03.05=5 and Pr.03.06=3



03.07

EF Active when Terminal Count Value Attained

Factory Setting: 0

Factory Setting: 0

Settings 0 Terminal count value attained, no EF display

1 Terminal count value attained, EF active

The E.F. is external fault. It needs to set one of Pr.04.05~Pr.04.08 to 14 to active the terminal. If this parameter is set to 1 and the desired value of counter is attained, the AC drive will treat it as a fault. The drive will stop and show the "EF" message on the display. If this parameter is set to 0 and the desired value of counter is attained, the AC drive will continue run.

It is used for choosing stop the AC motor drive or not when the desired value of counter is attained.



The digital keypad is optional. When using without the keypad, the "FAULT" LED will be ON when there is fault message or warning indication set by external terminals.

03.08	Fan	Control
03.00	ı aıı	COLLIGO

Settings

0

Fan always ON

1 1 minute after AC motor drive stops, fan will be OFF

2 Fan ON when AC motor drive runs, fan OFF when AC motor drive stops

3 Fan ON when preliminary heatsink temperature attained

This parameter determines the operation mode of the cooling fan.

Setting 0: fan will be ON after the AC motor drive is power on.

Setting 1: fan runs when the AC motor drive runs and 1 minute after the AC motor drive stops, fan will stop.

Setting 2: fan runs when the AC motor drive runs and stops when the AC motor drive stops.

Setting 3: fan will auto detect the temperature of heatsink and operate by the temperature. When heatsink temperature is higher than 60°C, fan will run and the fan will stop once the heatsink temperature is lower than 40°C.

03.09

The Digital Output Used by PLC (NOT for VFD*E*C models)

Settings Read Only

Factory display: 0

Bit0=1: RLY used by PLC

Bit1=1: MO1 used by PLC

Bit2=1: MO2/RA2 used by PLC

Bit3=1: MO3/RA3 used by PLC


Bit4=1: MO4/RA4 used by PLC

Bit5=1: MO5/RA5 used by PLC


Bit6=1: MO6/RA6 used by PLC

Bit7=1: MO7/RA7 used by PLC

- The equivalent 8-bit is used to display the status (used or not used) of each digital output. The value that Pr.03.09 displays is the result after converting 8-bit binary into decimal value.
- For standard AC motor drive, it only has 2-bit (bit0 and bit1). When extension card is installed, the number of the digital output terminals will increase according to the extension card. The maximum number of the digital output terminals is shown as follows.



For example: when Pr.03.09 is set to 3 (decimal) = 00000011 (binary) that indicates Relay1 and MO1 are used by PLC. (Pr.03.09= $2^0+2^1=3$)



03.10 The Analog Output Used by PLC (NOT for VFD*E*C models)


Settings Read Only Factory display: 0

Bit0=1: AFM used by PLC

Bit1=1: AO1 used by PLC

Bit2=1: AO2 used by PLC


The equivalent 1-bit is used to display the status (used or not used) of each analog output. The value that Pr.03.10 displays is the result after converting 1-bit binary into decimal value.



For Example:


If Pr.03.10 displays 1, it means that AFM is used by PLC.

03.	11 Brake Rele	ease Frequency	Unit: Hz				
	Settings	0.00 to 20.0Hz	Factory Setting: 0.00				
03.	12 Brake Eng	age Frequency	Unit: Hz				
	Settings	0.00 to 20.0Hz	Factory Setting: 0.00				
	These two parameters are used to set control of mechanical brake via the output terminals						
	(Relay or MO1) by setting Pr.03.00~03.01.					
	When Pr.03.00~03.01 is set to 21, the multi-function output terminal will be activated when the						
	output frequency reaches Pr.03.11. When the AC motor drive stops and the output frequency						
	reaches Pr.03	.12, this multi-function output terminal	will be activated.				
Related parameters: Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)) and							
	Pr.03.01(Multi-function Output Terminal MO1)						



Example:

When using Pr.03.11 and Pr.03.12 are used in life equipment as above figure. The timing figure is shown as follows. The DC brake is used before start-up and after stop. It can have high output torque at the beginning of start-up. The Brake Release Frequency (Pr.03.11) can be set by the requirement. The Brake Engage Frequency (Pr.03.12) can be set by requirement to be used when stopping near 0Hz to prevent vibration of counterforce for smooth operation.



- Pr.03.00~03.01 Multi-function Output Terminal:24 Function of Output Frequency Control Multi-output terminal ON/OFF : When output frequency is greater than Pr.03.11(Brake Release Frequency), this multi-function output terminal is conducted; When output frequency is less than Pr.03.11 (Brake Release Frequency), this multi-function output terminal is open circuit. Please note that when you select this function, Pr.03.11 MUST be greater than Pr.03.12, otherwise the multi-function output terminal is always in open circuit condition.
- Related parameters: 03.00 Multi-function Output (Relay) 03.01 Multi-function Output Terminal (MO1)

03.13 Display the Status of Multi-function Output Terminals

Settings Read Only Factory display: ##

Bit0: RLY Status

Bit1: MO1 Status

Bit2: MO2/RA2 Status

Bit3: MO3/RA3 Status

Bit4: MO4/RA4 Status

Bit5: MO5/RA5 Status


Bit6: MO6/RA6 Status

Bit7: MO7/RA7 Status

When all output external terminals aren't activated, Pr.03.13 will display 255 (11111111).

For standard AC motor drive (without extension card), the multi-function output terminals are

falling-edge triggered and Pr.03.13 will display 3 (11) for no action.



For Example:

If Pr.03.13 displays 2, it means Relay 1 is active.

The display value 2 =bit 1 X 2¹

When extension card is installed, the number of the multi-function output terminals will increase according to the extension card. The maximum number of the multi-function output

terminals is

shown as follows.


Group 4: Input Function Parameters

04.00				Unit: %
	Settings	0.0 t	o 200.0%	Factory Setting: 0.0
04.01		otentio	meter Bias Polarity	
				Factory Setting: 0
	Settings	0	Positive Bias	
		1	Negative Bias	
04.02		otentio	ometer Gain	Unit: %
	Settings	0.1 t	o 200.0%	Factory Setting: 100.0
04.03	Keypad Pot Enable/Disa		eter Negative Bias, Reverse Motion	
				Factory Setting: 0
	Settings	0	No Negative Bias Command	
		1	Negative Bias: REV Motion Enabled	
	Enable/Disa	o 0 1	No Negative Bias Command	

Pr.04.00~04.03 are used for those applications that use analog voltage signal to adjust the setting frequency. Please refer to the following examples for the details of keypad potentiometer (optional, 0~10V or ±10V).

Example 1: Standard application


This is the most used setting. The user only needs to set Pr.02.00 to 04. The frequency command comes from keypad potentiometer.



Example 2: Use of bias


This example shows the influence of changing the bias. When the input is 0V the output frequency is 10 Hz. At mid-point a potentiometer will give 40 Hz. Once the Maximum Output Frequency is reached, any further increase of the potentiometer or signal will not increase the output frequency. (To use the full potentiometer range, please refer to Example 3.) The value of external input voltage/current 0-8.33V corresponds to the setting frequency 10-60Hz. Thus, the center of the keypad potentiometer is

40Hz and the value of external input voltage/current 8.33~10V corresponds to the setting frequency 60Hz. Please refer to example 3 for this part.




Example 3: Use of bias and gain for use of full range

This example also shows a popular method. The whole scale of the potentiometer can be used as desired. In addition to signals of 0 to 10V, the popular voltage signals also include signals of 0 to 5V, or any value under 10V. Regarding the setting, please refer to the following examples.




Example 4: Use of 0-5V potentiometer range via gain adjustment

This example shows a potentiometer range of 0 to 5 Volts. Instead of adjusting gain as example below, you can set Pr. 01.00 to 120Hz to achieve the same results.




Example 5: Use of negative bias in noisy environment

In this example, a 1V negative bias is used. In noisy environments it is advantageous to use negative bias to provide a noise margin (1V in this example).




Example 6: Use of negative bias in noisy environment and gain adjustment to use full potentiometer range

In this example, a negative bias is used to provide a noise margin. Also a potentiometer frequency gain is used to allow the Maximum Output Frequency to be reached.



Example 7: Use of 0-10V potentiometer signal to run motor in FWD and REV direction

In this example, the input is programmed to run a motor in both forward and reverse direction. The motor will be idle when the potentiometer position is at mid-point of its scale. Using the settings in this example disables the external FWD and REV controls.



Pr.01.00=60Hz--Max. output Freq.

Potentiometer

Pr.04.00 =50.0%--Bias adjustment

Pr.04.01 =1--Negative bias Pr.04.02 =200%--Input gain


Pr.04.03 =1--Negative bias: REV motion enabled

Gain:(10V/5V)*100%=200%

Bias adjustment:((60Hz/60Hz)/(Gain/100%))*100%=200%

Example 8: Use negative slope

In this example, the use of negative slope is shown. Negative slopes are used in applications for control of pressure, temperature or flow. The sensor that is connected to the input generates a large signal (10V) at high pressure or flow. With negative slope settings, the AC motor drive will slow stop the motor. With these settings the AC motor drive will always run in only one direction (reverse). This can only be changed by exchanging 2 wires to the motor.



Pr.01.00=60Hz--Max. output Freq.

Potentiometer

Pr.04.00 =100%--Bias adjustment

Pr.04.01 =0--Positive bias

Pr.04.02 = 100% -- Input gain

Pr.04.03 =1--Negative bias: REV motion enabled

Gain:(10V/10V)*100%=100%


Bias adjustment:((60Hz/60Hz)/(Gain/100%))*100%=100%


04.11	Minimum A	AVI Voltage	Unit: V
	Settings	0.0 to 10.0V	Factory Setting: 0.0
04.12	Minimum A	VI Frequency (percentage of Pr.01.00)	Unit: %
	Settings	0.0 to 100.0%	Factory Setting: 0.0
04.13	Maximum /	AVI Voltage	Unit: V
	Settings	0.0 to 10.0V	Factory Setting: 10.0
04.14	Maximum /	AVI Frequency (percentage of Pr. 01.00)	Unit: %
	Settings	0.0 to 100.0%	Factory Setting: 100.0
04.15	Minimum A	ACI Current	Unit: mA
	Settings	0.0 to 20.0mA	Factory Setting: 4.0
04.16	Minimum A	ACI Frequency (percentage of Pr. 01.00)	Unit: %
	Settings	0.0 to 100.0%	Factory Setting: 0.0
_			
04.17	Maximum /	ACI Current	Unit: mA
	Settings	0.0 to 20.0mA	Factory Setting: 20.0

04.18	Maximum A	ACI Fre	equency (percentage of Pr. 01.00)	Unit: %
	Settings	0.0	to 100.0%	Factory Setting: 100.0
04.19	ACI Termir	nal Mod	le Selection	
				Factory Setting: 0
	Settings	0	ACI	
		1	AVI2	
04.20	Minimum A	VI2 Vo	Itage	Unit: V

04.20	Minimum A	VI2 Voltage	Unit: V
	Settings	0.0 to 10.0V	Factory Setting: 0.0
04.21	Minimum A	VI2 Frequency (percentage of Pr.1-00)	Unit: %
	Settings	0.0 to 100.0%	Factory Setting: 0.0
04.22	Maximum A	AVI2 Voltage	Unit: V
	Settings	0.0 to 10.0V	Factory Setting: 10.0
04.23	Maximum A	AVI2 Frequency (percentage of Pr.1-00)	Unit: %
	Settings	0.0 to 100.0%	Factory Setting: 100.0

- Please note the ACI/AVI switch on the AC motor drive. Switch to ACI for 4 to 20mA analog current signal (ACI) (Pr.04.19 should be set to 0) and AVI for analog voltage signal (AVI2) (Pr.04.19 should be set to 1). When ACi/AVI switch is not set by Pr.04.19, the keypad (optional) will display fault code "AErr" and needs to press "RESET" to clear it.
- The above parameters are used to set the analog input reference values. The min and max frequencies are based on Pr.01.00 (during open-loop control) as shown in the following.





Multi-function Input Terminal (MI1, MI2) 2-wire/ 3-wire Operation Control Modes


Factory Setting: 0

Settings 0 2-wire: FWD/STOP, REV/STOP

04.04

1 2-wire: FWD/REV, RUN/STOP

2 3-wire Operation



e <u>r 4 Paral</u>	illeters	External Terminal
	04.04	External Terminal
2	3-wire	STOP RUN MI1:("CLOSE":RUN) MI3:("OPEN":STOP) MI2:("OPEN": FWD) ("CLOSE": REV) DCM VFD-E

04.05	Multi-function Input Terminal (MI3)	
		Factory Setting: 1
04.06	Multi-function Input Terminal (MI4)	
		Factory Setting: 2
04.07	Multi-function Input Terminal (MI5)	
		Factory Setting: 3
04.08	Multi-function Input Terminal (MI6)	
		Factory Setting: 4

Settings	Function	Description
0	No Function	Any unused terminals should be programmed to 0 to insure they have no effect on operation.
1	Multi-Step Speed Command 1	These four inputs select the multi-speed defined by Pr.05.00 to
2	Multi-Step Speed Command 2	Pr.05.14 as shown in the diagram at the end of this table.
3	Multi-Step Speed Command 3	NOTE: Pr.05.00 to Pr.05.14 can also be used to control output speed by programming the AC motor drive's internal PLC function. There are 17 step speed frequencies (including
4	Multi-Step Speed Command 4	Master Frequency and Jog Frequency) to select for application.
5	External Reset	The External Reset has the same function as the Reset key on the Digital keypad. After faults such as O.H., O.C. and O.V. are cleared this input can be used to reset the drive.

Settings	Function	Description	
6	Accel/Decel Inhibit	When the command is active, acceleration and deceleration is stopped and the AC motor drive maintains a constant speed. Frequency setting frequency accel. inhibit decel. inhibit actual operation frequency decel. inhibit actual operation frequency operation ON ON ON ON ON OFF	
7	Accel/Decel Time Selection Command	Used to select the one of 2 Accel/Decel Times (Pr.01.09 to Pr.01.12). Frequency setting frequency 01.09 01.11 01.09 01.12 01.12 MIx-GND ON ON ON OFF	
8	Jog Operation Control	Parameter value 08 programs one of the Multi-function Input Terminals MI3 ~ MI6 (Pr.04.05~Pr.04.08) for Jog control. NOTE: Programming for Jog operation by 08 can only be done while the motor is stopped. (Refer to parameter Pr.01.13~Pr.01.15) 01.15 Jog frequency 01.05 Min. output frequency Jog accel. time 01.13 ON OFF	


Settings	Function	Description		
9	External Base Block (Refer to Pr. 08.06)	Parameter value 09 programs a Multi-function Input Terminals for external Base Block control. NOTE: When a Base-Block signal is received, the AC motor drive will block all output and the motor will free run. When base block control is deactivated, the AC drive will start its speed search function and synchronize with the motor speed, and then accelerate to Master Frequency. external base block output Speed search starts with last frequency command output voltage Speed search starts with last frequency command output voltage		
10	UP: Increase Master Frequency	Increase/decrease the Master Frequency each time an input is received or continuously when the input stays active. When both		
11	DOWN: Decrease Master Frequency	inputs are active at the same time, the Master Frequency increase/decrease is halted. Please refer to Pr.02.07, 02.08. This function is also called "motor potentiometer".		
12	Counter Trigger	Parameter value 12 programs one of the Multi-function Input Terminals MI3~MI6 (Pr.04.05~Pr.04.08) to increment the AC drive's internal counter. When an input is received, the counter is incremented by 1.		
13	Counter Reset	When active, the counter is reset and inhibited. To enable counting the input should be OFF. Refer to Pr.03.05 and 03.06.		

Settings	Function	Description		
14	External Fault	Parameter value 14 programs one of the Multi-function Input Terminals MI3~MI6 (Pr.04.05~Pr.04.08) to be External Fault (E.F.) inputs. voltage frequency setting frequency NIx-GND ON OFF ON OPF OPEration command		
15	PID function disabled	When an input ON with this setting is ON, the PID function will be disabled.		
16	Output Shutoff Stop	AC motor drive will stop output and the motor free run if one of these settings is enabled. If the status of terminal is changed, AC motor drive will restart from 0Hz. Voltage frequency setting frequency ON OFF ON Operation ON command		
17	Parameter lock enable	When this setting is enabled, all parameters will be locked and write parameters is disabled.		

Settings	Function	Description	
18	Operation Command Selection (Pr.02.01 setting/external terminals)	ON: Operation command via Ext. Terminals OFF: Operation command via Pr.02.01 setting When the settings 18, 19 and 20 are ON at the same time, the priority should be setting 18 > setting19 > setting20.	
19	Operation Command Selection (Pr 02.01 setting/Digital Keypad)	ON: Operation command via Digital Keypad OFF: Operation command via Pr.02.01 setting When the settings 18, 19 and 20 are ON at the same time, the priority should be setting 18 > setting19 > setting20.	
20	Operation Command Selection (Pr 02.01 setting/ Communication)	ON: Operation command via Communication OFF: Operation command via Pr.02.01 setting When the settings 18, 19 and 20 are ON at the same time, the priority should be setting 18 > setting19 > setting20.	
21	Forward/Reverse	This function has top priority to set the direction for running (If "Pr.02.04=0")	
22	Source of second frequency command enabled	Used to select the first/second frequency command source. Refer to Pr.02.00 and 02.09. ON: 2 nd Frequency command source OFF: 1 st Frequency command source	
23	Run/Stop PLC Program (PLC1) (NOT for VFD*E*C models)	ON: Run PLC Program OFF: Stop PLC Program When AC motor drive is in STOP mode and this function is enabled, it will display PLC1 in the PLC page and execute PLC program. When this function is disabled, it will display PLC0 in the PLC page and stop executing PLC program. The motor will be stopped by Pr.02.02. When operation command source is external terminal, the keypad cannot be used to change PLC status. And this function will be invalid when the AC Motor drive is in PLC2 status.	

Settings	Function	Description
23	Quick Stop (ONLY for VFD*E*C models)	It is only valid when Pr.02.01 is set to 5 in VFD*E*C models.
24	Download/Execute/ Monitor PLC Program (PLC2) (NOT for VFD*E*C models)	When AC motor drive is in STOP mode and this function is enabled, it will display PLC2 in the PLC page and you can download/execute/monitor PLC. When this function is disabled, it will display PLC0 in the PLC page and stop executing PLC program. The motor will be stopped by Pr.02.02. When operation command source is external terminal, the keypad cannot be used to change PLC status. And this function will be invalid when the AC Motor drive is in PLC1 status.
25	Simple position function	This function should be used with Pr.01.20~Pr.01.25 for simple position. Refer to Pr.01.25 for details.
26	OOB (Out of Balance Detection)	The OOB (Out Of Balance Detection) function can be used with PLC for washing machine. When this setting is enabled, it will get $\Delta\theta$ value from the settings of Pr.08.21 and Pr.08.22. PLC or host controller will decide the motor speed by this t $\Delta\theta$ value (Pr.08.23)
27	Motor selection (bit 0)	When this setting is enabled, it can be used for motor selection (Pr. 01.01~01.06, 01.26~01.43, 07.18~07.38, 07.00~07.06).
28	Motor selection (bit 1)	For example: MI1=27, MI2=28 When MI1 and MI2 are OFF, it selects motor 0. When MI1 is ON and MI2 is OFF, it selects motor 1. When MI1 is OFF and MI2 is ON, it selects motor 2. When MI1 and MI2 are ON, it selects motor 3.

Multi-Step Speed




M16 = 4MI5 = 3MI4=2MI3 = 1OFF OFF OFF OFF Master frequency 1st speed OFF **OFF OFF** ON 2nd speed OFF **OFF OFF** ON 3rd speed ON **OFF OFF** ON 4th speed OFF ON **OFF OFF** 5th speed OFF OFF ON ON 6th speed OFF ON ON OFF 7th speed **OFF** ON ON ON 8th speed **OFF** ON **OFF OFF** 9th speed ON OFF **OFF** ON 10th speed ON OFF ON **OFF** 11th speed ON OFF ON ON 12th speed OFF ON ON **OFF** 13th speed **OFF** ON ON ON 14th speed ON ON ON **OFF** 15th speed ON ON ON ON

04.09


Multi-function Input Contact Selection

Settings 0 to 4095 Factory Setting: 0

- This parameter can be used to set the status of multi-function terminals (MI1~MI6 (N.O./N.C.) for standard AC motor drive).
- The MI1~MI3 setting will be invalid when the operation command source is external terminal (2/3wire).




The Setting method: It needs to convert binary number (6-bit) to decimal number for input. For example: if setting MI3, MI5, MI6 to be N.C. and MI1, MI2, MI4 to be N.O. The setting value Pr.04.09 should be bit5X2⁵+bit4X2⁴+bit2X2²= 1X2⁵+1X2⁴+1X2²= 32+16+4=52 as shown in the following.



The setting value
=
$$bit5x2^5 + bit4x2^4 + bit2x2^2$$

= $1x2^5 + 1x2^4 + 1x2^2$
= $32 + 16 + 4 = 52$
Setting 04.09




04.10	Digital Terminal Input Debouncing Time				Unit: 2ms
	Settings	1 to 20			Factory Setting: 1
\sim	: :			 	


- This parameter is used to set the response time of digital input terminals MI1~MI6.
- This parameter is to delay the signals on digital input terminals. 1 unit is 2 msec, 2 units are 4 msec, etc. The delay time is to debounce noisy signals that could cause the digital terminals to malfunction.
- The AC motor drive will check the status of multi-function input terminals every 2ms. It will only confirm the command and change the status when the input terminals status is changed. Thus, the delay time from command input to execution is 2msec+ (Pr.04.10+1) X 2ms. Suppose that Pr.04.10 is set to 4, the delay time will be 12ms.


Settings	Read Only	Factory display: 0
Display	Bit0=1: MI1 used by PLC	
	Bit1=1: MI2 used by PLC	
	Bit2=1: MI3 used by PLC	
	Bit3=1: MI4 used by PLC	
	Bit4=1: MI5 used by PLC	
	Bit5=1: MI6 used by PLC	
	Bit6=1: MI7 used by PLC	
	Bit7=1: MI8 used by PLC	
	Bit8=1: MI9 used by PLC	
	Bit9=1: MI10 used by PLC	
	Bit10=1: MI11 used by PLC	
	Bit11=1: MI12 used by PLC	

For standard AC motor drive (without extension card), the equivalent 6-bit is used to display the status (used or not used) of each digital input. The value for Pr.04.24 to display is the result after converting 6-bit binary into decimal value.



For example: when Pr.04.24 is set to 52 (decimal) = 110100 (binary) that indicates MI3, MI5 and MI6 are used by PLC.





04.25 The Analog Input Used by PLC (NOT for VFD*E*C models)

Settings Read Only Factory display: 0


Display Bit0=1: AVI used by PLC

Bit1=1: ACI/AVI2 used by PLC

Bit2=1: Al1 used by PLC

Bit3=1: AI2 used by PLC

The equivalent 2-bit is used to display the status(used or not used) of each analog input. The value for Pr.04.25 to display is the result after converting 2-bit binary into decimal value.



04.26 Display the Status of Multi-function Input Terminal

Settings Read Only Factory display: ##

Display Bit0: MI1 Status

Bit1: MI2 Status

Bit2: MI3 Status

Bit3: MI4 Status

Bit4: MI5 Status

Bit5: MI6 Status

Bit6: MI7 Status

Bit7: MI8 Status


Bit8: MI9 Status

Bit9: MI10 Status

Bit10: MI11 Status

Bit11: MI12 Status


The multi-function input terminals are falling-edge triggered. For standard AC motor drive (without extension card), there are MI1 to MI6 and Pr.04.26 will display 63 (111111) for no action.




For Example:

If Pr.04.26 displays 52, it means MI1, MI2 and MI4 are active.

The display value $52 = 32 + 16 + 4 = 1 \times 2^5 + 1 \times 2^4 + 1 \times 2^2 = bit 6 \times 2^5 + bit 5 \times 2^4 + bit 3 \times 2^2$







04.27 Internal/External Multi-function Input Terminals Selection


Settings 0 to 4095 Factory Setting: 0

- This parameter is used to select the terminals to be internal terminal or external terminal. You can activate internal terminals by Pr.04.28. A terminal cannot be both internal terminal and external terminal at the same time.
- For standard AC motor drive (without extension card), the multi-function input terminals are MI1 to MI6 as shown in the following.




- The Setting method is convert binary number to decimal number for input.
- For example: if setting MI3, MI5, MI6 to be internal terminals and MI1, MI2, MI4 to be external terminals. The setting value should be bit5X2⁵+bit4X2⁴+bit2X2²= 1X2⁵+1X2⁴+1X2²= 32+16+4=52 as shown in the following.







04.28 MInternal Terminal Status Settings 0 to 4095 Factory Setting: 0

- This parameter is used to set the internal terminal action via keypad(optional), communication or PLC.
- For standard AC motor drive (without extension card), the multi-function input terminals are MI1 to MI6 as shown in the following.



For example, if setting MI3, MI5 and MI6 to be ON, Pr.04.28 should be set to bit5 $X2^5$ +bit4 $X2^4$ +bit2 $X2^2$ = 1 $X2^5$ +1 $X2^4$ +1 $X2^2$ = 32+16+4=52 as shown in the following.





ACI Filter Time

Settings $0 \sim 9999 \ (*2ms)$ Factory Setting: 50

Group 5: Multi-step Speeds Parameters


-			
05.00		Unit: Hz	
05.01		Unit: Hz	
05.02		Unit: Hz	
05.03		Unit: Hz	
05.04		Unit: Hz	
05.05		Unit: Hz	
05.06		Unit: Hz	
05.07		Unit: Hz	
05.08		Unit: Hz	
05.09		Unit: Hz	
05.10		Unit: Hz	
05.11		Unit: Hz	
05.12			
05.13			
05.14			
	Settings 0.00 to 600.00Hz (Japanese version: 0.00	Factory Setting: 0.00 to 599.00 Hz)	

- The Multi-function Input Terminals (refer to setting 1~4 of Pr.04.05 to 04.08) are used to select one of the AC motor drive Multi-step speeds(max. 15 speeds). The speeds (frequencies) are determined by Pr.05.00 to 05.14 as shown in the following.
- The operation time of multi-step speeds can be set by PLC program.
- The run/stop command can be controlled by the external terminal/digital keypad/communication via Pr.02.01.
- Each one of multi-step speeds can be set within 0.0~600.00Hz (Japanese version: 0.00 to 599.00 Hz) during operation.
- These parameters can be applied in small machinery, food processing machinery, washing equipment to control the operation procedure. It can be used instead of traditional circuit, such as relay, switch or counter.
- Explanation for the timing diagram for multi-step speeds and external terminals The Related parameter settings are:
 - 1. Pr.05.00~05.14: setting multi-step speeds (to set the frequency of each step speed)
 - 2. Pr.04.05~04.08: setting multi-function input terminals (multi-step speed 1~4)
 - 3. The repeat operation setting of 1st-15th step speed frequency: can use PLC program to control. Please refer to Appendix D How to use PLC function for details.
 - 4. The operation direction setting of 1st-15th step speed frequency: can use PLC program to control. Please refer to Appendix D How to use PLC function for details.
 - 5. The operation time setting of 1st-15th step speed frequency: can use PLC program to control. Please refer to Appendix D How to use PLC function for details. Operations:

Once the AC motor drive receives "RUN" command, it will operate by parameters settings and PLC program till the 15th step speed frequency is completed.

If it is repeat operation by PLC program, the AC motor drive will operate by the settings from Pr.05.00→Pr.05.01→....→ Pr.05.14→Pr.05.00→Pr.05.01.till the operation command is OFF.

Related parameters: Pr.01.15(Jog Frequency), Pr.01.07(Output Frequency Upper Limit), Pr.01.08(Output Frequency Lower Limit), Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))




MI5 = 3M16 = 4MI4=2MI3 = 1**OFF OFF** Master frequency OFF OFF 1st speed OFF OFF **OFF** ON 2nd speed **OFF** OFF ON OFF 3rd speed ON **OFF OFF** ON 4th speed OFF OFF OFF ON 5th speed **OFF** ON **OFF** ON 6th speed OFF **OFF** ON ON 7th speed **OFF** ON ON ON 8th speed OFF OFF ON **OFF** 9th speed ON **OFF OFF** ON 10th speed ON OFF ON **OFF** 11th speed ON **OFF** ON ON 12th speed ON **OFF** ON OFF 13th speed ON ON **OFF** ON 14th speed ON ON ON OFF 15th speed ON ON ON ON

Group 6: Protection Parameters

06.	.00 Over-Voltage Stal	l Prevention	Unit: V
	Settings 115V/230	OV series 330.0 to 410.0V	Factory Setting: 390.0
	460V ser	ries 660.0 to 820.0V	Factory Setting: 780.0
	0	Disable Over-voltage brake resistor)	Stall Prevention (with brake unit or
	During deceleration, the DC bus voltage may exceed its Maximum Allowable Value due to motor regeneration. When this function is enabled, the AC motor drive will not decelerate further and keep the output frequency constant until the voltage drops below the preset value again.		
	•	load, over-voltage stall preventi	on will not occur and the real

- With moderate inertia load, over-voltage stall prevention will not occur and the real deceleration time will be equal to the setting of deceleration time. The AC drive will automatically extend the deceleration time with high inertia loads. If the deceleration time is critical for the application, a brake resistor or brake unit should be used.
- When the function of over-voltage stall prevention is activated, the deceleration time of the AC motor drive will be larger than the setting.
- When the deceleration time is obstruction in the application, it is not suitable to use this function. The solution are:
 - 1. moderate increase the deceleration time
 - 2. used with a brake resistor (refer to appendix B for details) to consume the regenerative energy by heat.
- Related parameters: Pr.01.10(Decel Time 1), Pr.01.12(Decel Time 2), Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)) and Pr.03.01(Multi-function Output Terminal MO1)



06.01


Over-Current Stall Prevention during Acceleration

Unit: %

Settings 20 to 250% Factory Setting: 170

0: disable


- A setting of 100% is equal to the Rated Output Current of the drive.
- During acceleration, the AC drive output current may increase abruptly and exceed the value specified by Pr.06.01 due to rapid acceleration or excessive load on the motor. When this function is enabled, the AC drive will stop accelerating and keep the output frequency constant until the current drops below the maximum value.
- When it stalls due to the small motor power or operate with factory setting, please decrease the setting of Pr.06.01.
- When the acceleration time is obstruction in the application, it is not suitable to use this function. The solution are:
 - 1. moderate increase the acceleration time
 - 2. setting Pr.01.16 (Auto acceleration / deceleration (refer to Accel/Decel time setting)) to 1, 3 or 4.
- Related parameters: Pr.01.09(Accel Time 1), Pr.01.11(Accel Time 2), Pr.01.16(Auto acceleration / deceleration (refer to Accel/Decel time setting)), Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)), Pr.03.01(Multi-function Output Terminal MO1) and Pr.06.03(Over-Torque Detection Mode (OL2))



06.02	Over-curre	ent Stall Prevention during Operation	Unit: %
	Settings	20 to 250%	Factory Setting: 170
		0: disable	

- The over-current stall prevention during operation function is a protection. When the motor runs with constant speed, the AC motor drive will decrease the output frequency automatically when momentary overload.
- If the output current exceeds the setting specified in Pr.06.02 when the drive is operating, the drive will decrease its output frequency by Pr.01.10/Pr.01.12 to prevent the motor stall. If the output current is lower than (Pr.06.02 setting –rated current X 5%), the drive will accelerate again by Pr.01.09/Pr.01.11 to catch up with the set frequency command value.

Related parameter: Pr.06.03 Over-Torque Detection Mode (OL2)



over-current stall prevention during operation




Please do not set the over-current stall prevention to a small value to prevent over-low torque.


Factory Setting: 0

- Settings
- 0 Over-Torque detection disabled.
- Over-Torque detection enabled during constant speed operation.

 After over-torque is detected, keep running until OL1 or OL occurs.
- 2 Over-Torque detection enabled during constant speed operation. After over-torque is detected, stop running.
- 3 Over-Torque detection enabled during acceleration. After overtorque is detected, keep running until OL1 or OL occurs.
- 4 Over-Torque detection enabled during acceleration. After over-torque is detected, stop running.
- This parameter determines the operation mode of the drive after the over-torque (OL2)
- This parameter determines the operation mode of the drive after the over-torque (OL2) is detected via the following method:
 - 1. if the output current exceeds the over-torque detection level (Pr.06.04) and the detection time is longer than the setting of Pr.06.05 Over-Torque Detection Time, the warning message "OL2" is displayed on digital keypad (optional). It needs to press "RESET" to clear the warning message.
 - 2. If a Multi-function Output Terminal is set to over-torque detection (Pr.03.00~03.01=04), the output is on. Please refer to Pr.03.00~03.01 for details.
- Setting 1 or 2: it is used to detect with constant speed. For setting 2, it will free run to stop after over-torque is detected.
- Setting 3 or 4: it is used to detect during acceleration. For setting 4, it will free run to stop after over-torque is detected.
- Related parameters: Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)), Pr.03.01(Multi-function Output Terminal MO1), Pr.06.01(Over-Current Stall Prevention during Accel), Pr.06.02(Over-Current Stall Prevention during Operation) Pr.06.04(Over-Torque Detection Level) and Pr.06.05(Over-Torque Detection Time)

	, , , , , , , , , , , , , , , , , , ,					
06.	.04 / Over-Tor	que De	tection Level (OL2)	Unit: %		
	Settings	10 to	200%	Factory Setting: 150		
06.	.05 Over-Torqu	e Dete	ction Time (OL2)	Unit: second		
	Settings	0.1 t	o 60.0 sec	Factory Setting: 0.1		
	Pr.06.05 sets the The method to 1. when output 2. when over-to If a Multi-function	ne time detect curren orque ti on Outp	al to the Rated Output Current of the drive. for how long over-torque must be detected be over-torque is shown as follows: exceeds over-torque detection level (Pr.06.0 me exceeds over torque detection time (Pr.06 out Terminal is set to over-torque detection (P fer to Pr.03.00~03.01 for details.	 (4) (5.05)		
	For general mo	tor, the	output torque and output current of the AC motor dr	• •		
	Related parame	eters: F	r.03.00(Multi-function Output Relay (RA1, RE Output Terminal MO1)	31, RC1)) and		
06.	.06 Electronic T	Therma	Overload Relay Selection (OL1)			
				Factory Setting: 2		
	Settings	0	Operate with a Standard Motor (self-coole	d by fan)		
		1	Operate with a Special Motor (forced exter	nal cooling)		
		2	Operation disabled			
	This function is	used to	to set the operation selection of the electron o protect the motor from overloading or overh- erates in low frequency, overload is seldom happlication	eating. When the motor		
	When the rated it can use this p	l currer parame	t of motor is less than drive's or bad design of ter to limit the output current of the AC motor			
	overheating or damage. Setting 0: the electronic thermal relay is used for standard motor(heatsink is fixed on rotor shaft). When operating in low speed, the motor heat dissipation function will be bad. Thus, it					
	needs to decrease the action time of the electronic thermal relay to ensure the motor life. Setting 1: the electron thermal relay is used for special motor(heatsink uses independent power). The heat dissipation function has no direction relation with rotation speed. Thus, the electronic thermal relay is still held in low speed to ensure the motor load ability in low speed.					
	In the frequent protection due	power to this t	ON/OFF applications, it can't use this parame unction will be reset once the power is OFF. The motor when an AC motor drive is connected when a co	eter (even set to 0 or 1) for Thus, it needs to add the		
	Setting 0 or 1: v	when th rive wil	e electronic thermal relay protection is enable display "OL1" and free run to stop. It needs t	ed in low speed operation,		
	•	•	.06.07(Electronic Thermal Characteristic)			







When the standard motor operates in low speed with rated current, the motor overload protection will occur easily. Thus, please use the special motor when operates in low speed with rated current.


Refer to Appendix C.3 How to choose a suitable motor for motor selection.

06.07	Electronic	Thermal Characteristic	Unit: second
	Settings	30 to 600 sec	Factory Setting: 60

- The parameter determines the time required for activating the I²t electronic thermal protection function by the output frequency/current of the AC motor drive and operation time to prevent motor from overheating.
- The electronic thermal overload relay acts by Pr.06.06 setting:
 - 1. Pr.06.06 is set to 0(Operate with a Standard Motor (self-cooled by fan)): when the output current is greater than (Pr.07.00 Motor Rated Current (Motor 0)X (the corresponding motor rated current % of motor rated frequency in standard motor figure in Pr.06.06) X150%), the AC motor drive will start to count time. When accumulated time exceeds Pr.06.07(Electronic Thermal Characteristic) setting, the electronic thermal overload relay protection (OL1) will be ON.
 - 2. Pr.06.06 is set to 1(Operate with a Special Motor (forced external cooling)): when the output current is greater than (Pr.07.00 Motor Rated Current (Motor 0)X (the corresponding motor rated current % of motor rated frequency in special motor figure in Pr.06.06) X150%), the AC motor drive will start to count time. When accumulated time exceeds Pr.06.07(Electronic Thermal Characteristic) setting, the electronic thermal overload relay protection (OL1) will be ON.
- The actual action time of electronic thermal characteristic will be adjusted by the output current of the AC motor drive (motor load rate %). For large current, it needs short time to activate the I²t electronic thermal protection function. For small current, it needs long time to activate the I²t electronic thermal protection function as shown in the following figure.
- Related parameters: Pr.06.06(Electronic Thermal Overload Relay Selection) and Pr,07.00(Motor Rated Current (Motor 0))



Please refer to Pr06-06 Electronic Thermal Relay Selection for <motor cooling curve with shaft-fixed fan diagram> and <motor cooling curve with independent fan diagram>.



06.08	Present Fault Record			
06.09	Second Most Recent Fault Record			
06.10	Third Most Recent Fault Record			
06.11	Fourth Most Recent Fault Record			
06.12	Fifth Most Recent Fault Record			

Factory Setting: 0

		r dotory commis
Readings	0	No fault
	1	Over-current (oc)
	2	Over-voltage (ov)
	3	IGBT Overheat (oH1)
	4	Reserved
	5	Overload(oL)
	6	Overload (oL1)
	7	Motor Overload (oL2)
	8	External Fault (EF)
	9	Current exceeds 2 times rated current during accel.(ocA)
	10	Current exceeds 2 times rated current during decel.(ocd)
	11	Current exceeds 2 times rated current during steady state operation (ocn)
	12	Ground fault (GFF)
	13	Reserved
	14	Phase-loss (PHL)
	15	Reserved
	16	Auto accel/decel failure (CFA)
	17	Software/password protection (codE)
	18	Power Board CPU WRITE Failure (cF1.0)

Chapter 4 Parameters		
•	19	Power Board CPU READ Failure (cF2.0)
2	20	CC, OC Hardware protection failure (HPF1)
2	21	OV Hardware protection failure (HPF2)
2	22	GFF Hardware protection failure (HPF3)
2	23	OC Hardware protection failure (HPF4)
2	24	U-phase error (cF3.0)
2	25	V-phase error (cF3.1)
2	26	W-phase error (cF3.2)
2	27	DCBUS error (cF3.3)
2	28	IGBT Overheat (cF3.4)
	29	Reserved
3	30	Control Board CPU WRITE failure (cF1.1)
3	31	Contrsol Board CPU READ failure (cF2.1)
3	32	ACI signal error (AErr)
3	33	Reserved
3	34	Motor PTC overheat protection (PtC1)
3	35	PG feedback signal error (PGEr)
3	36-39	Reserved
4	40	Communication time-out error of control board and power board

In Pr.06.08 to Pr.06.12 the five most recent faults that occurred, are stored. After removing the cause of the fault, use the reset command to reset the drive.

W phase output phase loss (oPHL3)

ACL (Abnormal Communication Loop)

U phase output phase loss (oPHL1) V phase output phase loss (oPHL2)

(CP10)

dEb error

41

42

66

67

68

06.13	3 Action for detected Output Phase Loss (OPHL)					
				Factory Setting: 3		
	Settings	0	Warn and keep operation			
		1	Warn and ramp to stop			
		2	Warn and coast to stop			
		3	No warning			

06.14	Deceleration	Time of Output Phase Loss	Unit: second
	Settings	0.0 ~120.0 seconds	Factory Setting: 0.5

06.15	Detected Cu	ırrent Bandwidth	Unit: %
	Settings	2 ~100.0 %	Factory Setting: 2

06.16	Detected Do	C Brake Time of Output Phase Loss	Unit: second
	Settings	0.0 ~120.0 seconds	Factory Setting: 0.1

Set Pr.06.13~06.16 can detect the driver output is disconnected or not.

Open this function may cause misjudgment due to load or starting voltage is too small, here we can extend the detection time appropriately (Pr.06.14&Pr.06.16) or set Pr.06.15 value smaller.

Group 7: Motor Parameters

	Motor Date		1 l:1. A
07.		ed Current (Motor 0)	Unit: A
	Settings	30% FLA to 120% FLA	Factory Setting: FLA
	(Motor Current with Motor Cur AC Drive Curre	ng formula to calculate the percentage AC Drive Current) x 100% Trent=Motor rated current in A on type Tent=Rated current of AC drive in A (se	shield
	Example: Supp 4.2A. The rang Pr.07.00 is set	e that user can set is from 1.3A(4.2X3	OHP(1.5kW) is 4.2A with the factory setting 30%) to 5.0A(4.2X120%). But when to set Pr.07.01 to be less than 30% FLA
	Pr.07.00 and P mode (Pr.00.10		
	The full-load cu		urrent of the AC motor drive and should be
	Related param Pr.06.06(Electi Characteristic)	neters: Pr.00.01(Rated Current Display ronic Thermal Overload Relay Selection , Pr.07.01(Motor No-Load Current (Mo PG) (Motor 0)) and Pr.07.06(Motor Ra	y of the AC motor drive), on), Pr.06.07(Electronic Thermal otor 0)), Pr.07.03(Slip Compensation
07.	01 Motor No-lo	oad Current (Motor 0)	Unit: A
	Settings	0% FLA to 99% FLA	Factory Setting: 0.4*FLA
	current by the in AC motor drive Example: Supple 4.2A. The motor This parameter Compensation of the motor not after unloading The setting val Related parameter and the setting value and value	motor nameplate. The factory setting I is (refer to Pr.00.01 Rated Current Dispose that the rated current of 460V/2.00 r no-load current is 1.7A(4.2X40%) at must be set if the "Electronic Therma" (Pr.07.03 and Pr.07.06) functions are load current can't be read from the nay and read it from the digital keypad (oue must be less than Pr.07.00 (Motor	Ohp(1.5kW) is 4.2A with factory setting and it should set Pr.07.01 to 1.7. all Overload Relay" (Pr.06.06) or "Slip e selected. ameplate, operating the AC motor drive optional, refer to Appendix B for details). Rated Current).
07.	•	r Rated Slip (Motor 0)) Compensation (Motor 0)	
07.			Eastery Cattings 0.0
	Settings	0.0 to 10.0	Factory Setting: 0.0
	impedance of s will be too large motor is insuffi	stator windings when motor load is lar e and output torque is insufficient due cient and insufficient air-gap magnetic	rive output voltage will be absorbed by the ge. In this circumstance, the output current to the motor voltage at inductance end of c field. Using this parameter, it will auto ration with the air-gap magnetic field is
	In V/f control m torque in low s can be set for t	peed due to less AC impedance and o	decreasing frequency. It will cause lower constant DC resistor. Thus, this parameter ut to obtain a higher torque in low speed. tor.

Chapter 4 Parameters This parameter is only used for V/f control mode. Related parameters: Pr.00.10(Control Method) and Pr.07.08(Torque Compensation Time Constant). 07.03 ✓ Slip Compensation (Used without PG) (Motor 0) 0.00 to 10.00 Factory Setting: 0.00 Settings When the induction motor generates the electromagnetic torque, it needs the necessary slip. But the slip can be ignored when it needs only 2-3% slip in higher speed. When the drive operates, the slip and synchronous frequency are in reverse proportion. That is, the slip will be increased with the decreasing synchronous frequency. The slip affects the motor speed seriously in low speed because the motor may stop and can't run with load when the synchronous frequency is too low. While driving an asynchronous motor, increasing the load on the AC motor drive will cause an increase in slip and decrease in speed. This parameter may be used to compensate the slip by increasing the output frequency. When the output current of the AC motor drive is bigger than the motor no-load current (Pr.07.01), the AC drive will adjust its output frequency according to this parameter. When Pr.00.10 is set from V/f mode to vector mode, this parameter will be set to 1.00 automatically. When Pr.00.10 is set from vector mode to V/f mode, this parameter will be set to 0.00. Please using this function after load is added and acceleration with gradual increasing compensation. That is, add the output frequency with Pr.07.06(Motor Rated Slip (Motor 0)) X Pr.07.03(Slip Compensation (Used without PG) (Motor 0)) on the output frequency

07.04 Motor Parameters Auto Tuning

Factory Setting: 0

Settings 0 Disable

1 Auto Tuning R1 (motor doesn't run)

2 Auto Tuning R1 + No-load Test (with running motor)

- Start Auto Tuning by pressing RUN key after this parameter is set to 1 or 2. When setting to 1, it will only auto detect R1 value and Pr.07.01 must be input manually. When set to 2, the AC motor drive should be unloaded and the values of Pr.07.01 and Pr.07.05 will be set automatically.
- The steps for AUTO-Tuning are:
 - Make sure that all the parameters are set to factory settings and the motor wiring is correct.
 - 2. Make sure the motor has no-load before executing auto-tuning and the shaft is not connected to any belt or gear motor.
 - 3. Fill in Pr.01.01, Pr.01.02, Pr.07.00, Pr.07.04 and Pr.07.06 with correct values.
 - 4. After Pr.07.04 is set to 2, the AC motor drive will execute auto-tuning immediately after receiving a "RUN" command. (Note: The motor will run!). The total auto tune time will be 15 seconds + Pr.01.09 + Pr.01.10. Higher power drives need longer Accel/Decel time (factory setting is recommended). After executing Auto-tune, Pr.07.04 is set to 0.

- 5. After executing, please check if there are values filled in Pr.07.01 and Pr.07.05. If not, please press RUN key after setting Pr.07.04 again.
- 6. Then you can set Pr.00.10 to 1 and set other parameters according to your application requirement.
- Related parameters: Pr.01.01(Maximum Voltage Frequency (Fbase) (Motor 0)), Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr.07.00(Motor Rated Current (Motor 0)), Pr.07.01(Motor No-Load Current (Motor 0)), Pr.07.05(Motor Line-to-line Resistance R1 (Motor 0)) and Pr.07.06(Motor Rated Slip (Motor 0))



- 1. In vector control mode it is not recommended to have motors run in parallel.
- 2. It is not recommended to use vector control mode if motor rated power exceeds the rated power of the AC motor drive.

07	Motor Line-to-line Resistance R1 (Motor 0)	Unit: mΩ
	Settings 0 to 65535 m Ω	Factory Setting: 0
	The motor auto tune procedure will set this parameter. The user mawithout using Pr.07.04.	ay also set this parameter
07	Motor Rated Slip (Motor 0)	Unit: Hz
	Settings 0.00 to 20.00Hz	Factory Setting: 3.00
	It can be used to set the motor rated slip. Users need to input the a the nameplate of the motor.	ctual rated rpm shown on
Ф	Refer to the rated rpm and the number of poles on the nameplate of following equation to calculate the rated slip. Rated Slip (Hz) = F_{base} (Pr.01.01 base frequency) – (rated rpm x more Example: Assume that the rated frequency of the motor is 60Hz with is 1650rpm. The rated slip calculated by the formula should be 60Hz This parameter has relation with Pr.07.03(Slip Compensation (Used get the best slip compensation effect, it needs to input the correct states.)	otor pole/120) h 4 poles and the rated rpm z-(1650X4/120)=5Hz. d without PG) (Motor 0)). To
	may cause the invalid function and even damage the motor and dri Related parameter: Pr.07.03(Slip Compensation (Used without PG)	ve.
07	Slip Compensation Limit	Unit: %
	Settings 0 to 250%	Factory Setting: 200
	This parameter sets the upper limit of the compensation frequency	(the percentage of

This parameter sets the upper limit of the compensation frequency (the percentage of Pr.07.06).

Example: when Pr.07.06=5Hz and Pr.07.07=150%, the upper limit of the compensation frequency is 7.5Hz. Therefore, for a 50Hz motor, the max. output is 57.5Hz.

- If the motor speed is lower than the target speed and the speed isn't changed after adjusting Pr.07.03 setting, it may reach the upper limit of the compensation frequency and need to increase Pr.07.07 setting.
- Related parameters: Pr.07.03(Slip Compensation (Used without PG) (Motor 0)) and Pr.07.06(Motor Rated Slip (Motor 0))

07	Torque Co	mpensa	ation Time Constant	Unit: second		
	Settings	0.01	~10.00 sec	Factory Setting: 0.30		
	It is usually applied in those heavy load applications which the motor current is changed frequently. The current is changed for the current compensation to increase the output torque Because the frequent current change will cause the machine vibration, it can increase Pr.07. setting to solve this problem at this moment.					
07	3.09 Slip Comp	ensatio	n Time Constant	Unit: second		
	Settings	0.05	~10.00 sec	Factory Setting: 0.20		
	frequently. The Because the fr	speed equent		n the motor speed is changed ation to reach the synchronous speed ne vibration, it can increase Pr.07.09		
	•		its (set Pr.07.08 and Pr.07.09 to 10) ration. Please set by your application	give slow response; too short values		
07	Accumulat	ve Mot	or Operation Time (Min.)			
	Settings	0		Factory Display: ##		
	Displays	0~1	439			
07	.11 Accumulat	ve Mot	or Operation Time (Day)			
	Settings	0		Factory Display: ##		
	Displays	0 ~6	5535			
			are used to record the motor opera			
	•	Pr.07.11	s less than 1 minute is not recorded to 0, it will reset the accumulative r	motor operation time and the record		
07	Motor PTC	Overh	eat Protection			
				Factory Setting: 0		
	Settings	0	Disable			
		1	Enable			
07	.14 Motor PTC	Overh	eat Protection Level	Unit: V		
	Settings	0.1	10.0V	Factory Setting: 2.4		
	fan will be lowe	er. To p	ning at low frequency for a long tim revent overheating, it needs to have tor and connect its output signal to t	e a Positive Temperature Coefficient		
	When the sour disable the fun	ction of	• • •	•		

can be enable at one time.


- If temperature exceeds the setting level, motor will be coast to stop and displayed. When the temperature decreases below the level of (Pr.07.15-Pr.07.16) and
 - stops blinking, you can press RESET key to clear the fault.
- Pr.07.14 (overheat protection level) must exceed Pr.07.15 (overheat warning level).
- The PTC uses the AVI-input and is connected via resistor-divider as shown below.

The voltage between +10V to ACM: lies within 10.4V~11.2V.

The impedance for AVI is around $47k\Omega$.

Recommended value for resistor-divider R1 is $1\sim10$ k Ω .

Please contact your motor dealer for the curve of temperature and resistance value for PTC.



Refer to following calculation for protection level and warning level.

Protection level

 $Pr.07.14 = V_{+10} * (R_{PTC1} / 47 K) / [R1 + (R_{PTC1} / 47 K)]$

Warning level

 $Pr.07.16 = V_{+10} * (R_{PTC2}//47K) / [R1 + (R_{PTC2}//47K)]$

Definition:

V+10: voltage between +10V-ACM, Range 10.4~11.2VDC

RPTC1: motor PTC overheat protection level. Corresponding voltage level set in Pr.07.14,

RPTC2: motor PTC overheat warning level. Corresponding voltage level set in Pr.07.15,


47k Ω: is AVI input impedance, R1: resistor-divider (recommended value: $1\sim20$ k Ω)

Take the standard PTC thermistor as example: if protection level is $1330\,\Omega$, the voltage between +10V-ACM is 10.5V and resistor-divider R1 is $4.4k\,\Omega$. Refer to following calculation for Pr.07.14 setting.

1330//47000=(1330*47000)/(1330+47000)=1293.4

10.5*1293.4/(4400+1293.4)=2.38(V) = 2.4(V)

Therefore, Pr.07.14 should be set to 2.4.



Related parameters: Pr.02.00(Source of First Master Frequency Command), Pr.02.09(Source of Second Frequency Command), Pr.07.13(Input Debouncing Time of the PTC Protection), Pr.07.15(Motor PTC Overheat Warning Level), Pr.07.16(Motor PTC Overheat Reset Delta Level) and Pr.07.17(Treatment of the Motor PTC Overheat)

	·				
07.	15 Motor PTC	Overh	eat Warning Level		Unit: V
	Settings	0.1	~10.0V		Factory Setting: 1.2
07.	Motor PTC	Overh	eat Reset Delta Leve	el	Unit: V
	Settings	0.1	~5.0V		Factory Setting: 0.6
07.	17 Treatment	of the	motor PTC Overheat		
					Factory Setting: 0
	Settings	0	Warn and RAMP to	o stop	
		1	Warn and COAST	to stop	
		2	Warn and keep rur	nning	
	If temperature exceeds the motor PTC overheat warning level (Pr.07.15), the drive will act				
	according to P	r 07 17	and display	on the keynad	
	Setting Pr.07.1	7 to 0:	When the motor PT0	C overheat protection	on is activated, it will display
	PHIP	the die	rital kaypad and the r	notor will stop to OL	Hz by Pr.01.10/Pr.01.12 setting.
	Setting Pr.07.1	ເກຍ ຜເເ :17 to 1	When the motor PT	C overheat protection	on is activated, it will display
	on the digital keypad and the motor will free run to stop. Setting Pr.07.17 to 2: When the motor PTC overheat protection is activated, it will display				
		7 (0 2.	William the motor i in	o vernear protection	or io dolivated, it will diopidy
			gital keypad and the r		
	If the temperat	ure de	creases below the re	sult (Pr.07.15 minus	s Pr.07.16), the warning display
	PE[2 wil	l disap	pear.		

NOTE

The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.

07.13	Input Debo	uncing Time of the PTC Protection	Unit: 2ms
·	Settings	0~9999 (is 0-19998ms)	Factory Setting: 100
	This parameter are 4 msec, etc	r is to delay the signals on PTC analog inpoc.	ut terminals. 1 unit is 2 msec, 2 units
07.18	Motor Rate	d Current (Motor 1)	Unit: A
07.18	Motor Rate Settings	d Current (Motor 1) 30% FLA to 120% FLA	Unit: A Factory Setting: FLA

Cilapiei	4 Faranneters		
	Settings	0% FLA to 90% FLA	Factory Setting: 0.4*FLA
07.00	ν Τ	2 (14.4.4)	
07.20	•	Compensation (Motor 1)	
	Settings	0.0 to 10.0	Factory Setting: 0.0
07.21	✓ Slip Con	npensation (Used without PG) (Motor 1)	
	Settings	0.00 to 10.00	Factory Setting: 0.00
07.22	Motor Line	-to-line Resistance R1 (Motor 1)	Unit: mΩ
	Settings	0 to 65535 mΩ	Factory Setting: 0
07.23	Motor Rate	ed Slip (Motor 1)	Unit: Hz
	Settings	0.00 to 20.00Hz	Factory Setting: 3.00
07.24	Motor Pole	Number (Motor 1)	
	Settings	2 to 10	Factory Setting: 4
07.25	Motor Rate	ed Current (Motor 2)	Unit: A
	Settings	30% FLA to 120% FLA	Factory Setting: FLA
07.26	Motor No-le	oad Current (Motor 2)	Unit: A
	Settings	0% FLA to 90% FLA	Factory Setting: 0.4*FLA
07.27		Compensation (Motor 2)	
	Settings	0.0 to 10.0	Factory Setting: 0.0
07.28	⊮ Slip Con	npensation (Used without PG) (Motor 2)	
	Settings	0.00 to 10.00	Factory Setting: 0.00
07.29	Motor Line	-to-line Resistance R1 (Motor 2)	Unit: mΩ
	Settings	0 to 65535 mΩ	Factory Setting: 0
07.30	Motor Rate	ed Slip (Motor 2)	Unit: Hz
	Settings	0.00 to 20.00Hz	Factory Setting: 3.00
07.31	Motor Pole	Number (Motor 2)	
	Settings	2 to 10	Factory Setting: 4
07.32	Motor Rate	ed Current (Motor 3)	Unit: A
	Settings	30% FLA to 120% FLA	Factory Setting: FLA
07.33	Motor No-le	oad Current (Motor 3)	Unit: A
	Settings	0% FLA to 90% FLA	Factory Setting: 0.4*FLA
07.34	★Torque (Compensation (Motor 3)	
	Settings	0.0 to 10.0	Factory Setting: 0.0
07.35	⊮Slip Con	npensation (Used without PG) (Motor 3)	
	Settings	0.00 to 10.00	Factory Setting: 0.00
-			

		I control of the cont	
07.36	Motor Line	e-to-line Resistance R1 (Motor 3)	Unit: mΩ
	Settings	0 to 65535 m Ω	Factory Setting: 0
07.37	Motor Rate	ed Slip (Motor 3)	Unit: Hz
	Settings	0.00 to 20.00Hz	Factory Setting: 3.00
07.38	Motor Pole	e Number (Motor 3)	
	Settings	2 to 10	Factory Setting: 4

The motor 0 to motor 3 can be selected by setting the multi-function input terminals MI3~MI6 (Pr.04.05 to Pr.04.08) to 27 and 28.

Group 8: Special Parameters

08.00	DC Brake	Current Level	Unit: %
	Settings	0 to 100%	Factory Setting: 0

- This parameter sets the level of DC Brake Current output to the motor during start-up and stopping. When setting DC Brake Current, the Rated Current (Pr.00.01) is regarded as 100%. It is recommended to start with a low DC Brake Current Level and then increase until proper holding torque has been achieved.
- Related parameters: Pr.08.01(DC Brake Time during Start-up) and Pr.08.02(DC Brake Time during Stopping)

08.01	DC Brake 1	Γime during Start-up	Unit: second
	Settings	0.0 to 60.0 sec	Factory Setting: 0.0


- The motor may keep running due to external factor or itself inertia. The over current may damage the motor or activate the drive's protection when running the drive suddenly. This parameter can output a DC current with a torque to force the motor to stop for a stable start.
- This parameter determines the duration of the DC Brake current after a RUN command. When the time has elapsed, the AC motor drive will start accelerating from the Minimum Frequency (Pr.01.05). The DC brake is invalid when Pr.08.01 is set to 0.

08.02	DC Brake 7	Time during Stopping	Unit: second
	Settings	0.0 to 60.0 sec	Factory Setting: 0.0

- The motor may keep running due to external factor or itself inertia and can't stop by requirement. This parameter can output a DC current with a torque to force the motor to stop after the drive stops outputting to ensure the motor is stop.
- This parameter determines the duration of the DC Brake current during stopping. If stopping with DC Brake is desired, Pr.02.02 Stop Method must be set to 0 or 2 for Ramp to Stop. The DC brake is invalid when Pr.08.02 is set to 0.0.
- Related parameters: Pr.02.02(Stop Method) and Pr.08.03(Start-Point for DC Brake)

08.03	Start-Point	for DC Brake	Unit: Hz
	Settings	0.00 to 600.00Hz (Japanese version: 0.00 to 599.00 Hz)	Factory Setting: 0.00

This parameter determines the frequency when DC Brake will begin during deceleration.



DC Brake Time

	fans and pump position before	ng Start- s. Under setting i					
	in position, suc	h as cra may als	ing is used to shorten the stopping time and also to hold a stopped load nes and cutting machines. For high inertia loads, a brake resistor for o be needed for fast decelerations. Refer to appendix B for the sistors.				
08.	04 Momentary	Power I	Loss Operation Selection				
			Factory Setting: 0				
	Settings	0	Operation stops (coast to stop) after momentary power loss.				
		1	Operation continues after momentary power loss, speed search starts with the Last Frequency.				
		2	Operation continues after momentary power loss, speed search starts with the minimum frequency.				
	This parameter momentary por		nes the operation mode when the AC motor drive restarts from a				
	•		o the AC motor drive may be off temporarily with unknown factors. This he drive after momentary power loss.				
	accelerate to the speed are synchave a large in	ne maste chronous ertia and	operate by the last frequency before momentary power loss. It will be frequency after the drive output frequency and the motor rotor's it is recommended to use this setting for those motor loads which it small resistance to save time by restarting without waiting the flywhee as machinery equipment with a large-inertia flywheel.				
	Setting 2: the of frequency after	Irive will the driv	operate by the min. frequency. It will accelerate to the master e output frequency and motor rotor speed are synchronous. It is nis setting for those motor loads which have a small inertia and large				
	When using wi		ard, the speed search will start with the actual motor speed detected by				
		the drive and accelerate to the setting frequency (setting 1 and 2 are invalid at this moment). Related parameters: Pr.08.05(Maximum Allowable Power Loss Time), Pr.08.07(Baseblock					

08.05	Maximum A	Allowable Power Loss Time	Unit: second
	Settings	0.1 to 20.0 sec	Factory Setting: 2.0

Time for Speed Search (BB)) and Pr.08.08(Current Limit for Speed Search)

- If the duration of a power loss is less than this parameter setting, the AC motor drive will act by Pr.08.04 setting. If it exceeds the Maximum Allowable Power Loss Time, the AC motor drive output is then turned off (coast stop).
- The selected operation after power loss in Pr.08.04 is only executed when the maximum allowable power loss time is ≤20 seconds and the AC motor drive displays "Lu". But if the AC motor drive is powered off due to overload, even if the maximum allowable power loss time is ≤20 seconds, the operation mode as set in Pr.08.04 is not executed. In that case it starts up normally.

08.06 Base Block Speed Search

Factory Setting: 1

- Settings 0 Disable
 - Speed search starts with last frequency
 - 2 Speed search starts with minimum output frequency (Pr.01.05)
- This parameter determines the AC motor drive restart method after External Base Block is enabled(one of Pr.04.05~04.08 is set to 9).
- The speed search actions between Pr.08.04 and Pr.08.06 are the same.
- The priority of Pr.08.06 is higher than Pr.08.04. That is, Pr.08.04 will be invalid after Pr.08.06 is set and the speed search will act by Pr.08.06.
- Related parameters: Pr.08.07(Baseblock Time for Speed Search (BB)), Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))




Fig 1:B.B. Speed Search with Last Frequency Downward Timing Chart





Fig 2: B.B. Speed Search with Min. Output Frequency Upward Timing Chart

08.07	Baseblock	Time for Speed Search (BB)	Unit: second
	Settings	0.1 to 5.0 sec	Factory Setting: 0.5

- When momentary power loss is detected, the AC motor drive will block its output and then wait for a specified period of time (determined by Pr.08.07, called Base-Block Time) before resuming operation. This parameter should be set at a value to ensure that any residual regeneration voltage from the motor on the output has disappeared before the drive is activated again.
- This parameter also determines the waiting time before resuming operation after External Baseblock and Auto Restart after Fault (Pr.08.15).
- When using a PG card with PG (encoder), speed search will begin at the actual PG (encoder) feedback speed.

80.80	Current Lim	it for Speed Search	Unit: %
	Settings	30 to 200%	Factory Setting: 150

- lt limits the drive output current during speed search.
- When executing speed search, the V/f curve will be by the setting in the group 01.
- The level of speed search will affect the speed synchronization time. The larger setting is set and the faster it will reach the speed synchronization. But too large setting may cause overload.
- When Pr.08.04 is set to 1: When the speed searches downward, the output frequency starts with the master frequency. The output voltage and output current will be increased from 0. When the output current reaches Pr.08.08 setting, the output frequency continuous searches downward. When the output frequency, output voltage and V/f setting frequency are the same, it will be regarded as the synchronization reached and accelerate to the master frequency by V/f curve.
- When Pr.08.04 is set to 2: When the speed searches upward, it will accelerate by V/f curve.




Momentary Power Loss Operation

08.09	Skip Frequency 1 Upper Limit	Unit: Hz				
08.10	Skip Frequency 1 Lower Limit	Unit: Hz				
08.11	Skip Frequency 2 Upper Limit	Unit: Hz				
08.12	Skip Frequency 2 Lower Limit	Unit: Hz				
08.13	Skip Frequency 3 Upper Limit					
08.14	Skip Frequency 3 Lower Limit					
	Settings 0.00 to 600.00Hz	Factory Setting: 0.00				

(Japanese version: 0.00 to 599.00 Hz)

- These parameters are used to set the frequencies that are inhibited to operate. This function can be used to prevent the resonance generated from the original frequency of the machines. It keeps the drive from running at the resonance frequency of machinery or load system or other inhibition frequency. There are three frequency areas can be set.
- These parameters set the Skip Frequencies. It will cause the AC motor drive never to remain within these frequency ranges with continuous frequency output. These six parameters should be set as follows $Pr.08.09 \ge Pr.08.10 \ge Pr.08.11 \ge Pr.08.12 \ge Pr.08.13 \ge Pr.08.14$. When it is set to 0.0. the skip frequency is invalid.
- The frequency command (F) can be set within the range of skip frequency. At this moment, the output frequency (H) will be less than the lower limit of skip frequency.
- When the drive accelerates/decelerates, the output frequency will pass the range of skip frequency.



08.	.15 Auto Resta	art After Fault	
	Settings	0 to 10	Factory Setting: 0
		0 Disable	
	•	over-current OC or over-voltage OV fault occurs, the AC molecular automatically up to 10 times.	otor drive can be
	Setting this par occurred.	rameter to 0 will disable automatic reset/restart operation a	after any fault has

When enabled, the AC motor drive will restart with speed search, which starts at the frequency before the fault. To set the waiting time before restart after a fault, please set Pr. 08.07 Base Block Time for Speed Search.

- When the fault times exceeds Pr.08.15 setting, the drive will refuse to restart and the user needs to press "RESET" for continuous operation.
- Related parameter: Pr.08.16 (Auto Reset Time at Restart after Fault)

08.16	Auto Rese	t Time at Restart after Fault	Unit: second			
	Settings	0.1 to 6000 sec	Factory Setting: 60.0			

- This parameter is used to set the auto reset time at restart after fault. After restarting for fault, if there is no fault for over Pr.08.16 setting from the restart for the previous fault, the auto reset times for restart after fault will be reset to Pr.08.15 setting..
- This parameter should be used in conjunction with Pr.08.15. For example: If Pr.08.15 is set to 10 and Pr.08.16 is set to 600s (10 min), and if there is no


fault for over 600 seconds from the restart for the previous fault, the auto reset times for restart after fault will be reset to 10.

Related parameter: Pr.08.15(Auto Restart After Fault)

08.17 Automatic Energy-saving

Factory Setting: 0

- Settings 0 Energy-saving operation disabled
 - 1 Energy-saving operation enabled
- When Pr.08.17 is set to 1, the acceleration and deceleration will operate with full voltage. During constant speed operation, it will auto calculate the best voltage value by the load power for the load. This function is not suitable for the ever-changing load or near full-load during operation.
- The max. energy saving is in the stable load output. At this moment, the output voltage is almost 70% of the rated voltage.



08.18 Automatic Voltage Regulation (AVR)

Factory Setting: 0

- Settings 0 AVR function enabled
 - 1 AVR function disabled
 - 2 AVR function disabled for deceleration
 - 3 AVR function disabled for stop
- The rated voltage of the motor is usually 230V/200VAC 50Hz/60Hz and the input voltage of the AC motor drive may vary between 180V to 264 VAC 50Hz/60Hz. Therefore, when the AC motor drive is used without AVR function, the output voltage will be the same as the input voltage. When the motor runs at voltages exceeding the rated voltage with 12% 20%, its lifetime will be shorter and it can be damaged due to higher temperature, failing insulation and unstable torque output.
- AVR function automatically regulates the AC motor drive output voltage to the Maximum Output Voltage (Pr.01.02). For instance, if Pr.01.02 is set at 200 VAC and the input voltage is at 200V to 264VAC, then the Maximum Output Voltage will automatically be reduced to a maximum of 200VAC.

Chapte Cha	DC-bus voltage Setting 1: when voltage. The ou current. Setting 2: the d to low speed. Setting 3: the d When the moto 2 with auto acc	AVR function is enabled, the drive will calculate. The output voltage won't be changed by DC a AVR function is disabled, the drive will calculate at put voltage will be changed by DC bus voltage rive will disable the AVR during deceleration, so the will disable the AVR function at stop to according ramps to stop, the deceleration time is longe eleration/deceleration, the deceleration will be eter: Pr.01.16(Auto acceleration / deceleration	bus voltage. ate the output voltage by DC-bus e. It may cause insufficient/over such as operated from high speed celerate the brake. r. When setting this parameter to quicker.
08.	Software Bi (the Action	rake Level Level of the Brake resistor)	Unit: V
-	Settings	115/230V series: 370.0 to 430.0V	Factory Setting: 380.0
		460V series: 740.0 to 860.0V	Factory Setting: 760.0
Q Q 08 .	choose the suit information of the This parameter VFD004E11A/2 chopper for white	sets the DC-bus voltage at which the brake chable brake resistor to have the best deceleration he brake resistor. Will be invalid for Frame A models (VFD002E-21A/23A/43A, VFD007E21A/23A/43A and VFD ich BUE brake unit must be used.	on. Refer to appendix B for the 11A/21A/23A,
00.	Settings	0.0~5.0	Footony Cottings 0.0
	In V/f control m or torque comp The drift curren vibration. It is re this situation gr The drift curren	ode, the drift current may cause slight motor vensation. It can be ignored if this slight vibration will occur in a specific zone of the motor and ecommended to use this parameter(the recom	on doesn't affect the application. it will cause serious motor mended value is 2.0) to improve
08.	OOB Samp	ling Time	Unit: second
	Settings	0.1 to 120.0 sec	Factory Setting: 1.0
08.	Number of	OOB Sampling Times	
	Settings	0.00 to 32	Factory Setting: 20
08.	OOB Avera	ge Sampling Angle	
	Settings	Read-only	Factory Setting: #.#
	When multi-fun	Of Balance Detection) function can be used w ction input terminal is enabled (MI=26), it will gr.08.22. PLC or the host controller will decide t	get Δθ value from the settings of


The OOB (Out Of Balance Detection) function can be used with PLC for washing machine. When multi-function input terminal is enabled (MI=26), it will get $\Delta\theta$ value from the settings of Pr.08.21 and Pr.08.22. PLC or the host controller will decide the motor speed by this t $\Delta\theta$ value (Pr.08.23). When $\Delta\theta$ value is large, it means unbalanced load. At this moment, it needs to lower the frequency command by PLC or the host controller. On the other hand, it can be high-speed operation.

Related parameters: Pr.04.05(Multi-function Input Terminal (MI3)), 04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))

			tion	DEB Funct	08.24
Factory Setting: 0					
	ole	Disable	0	Settings	
	е	Enable	1		
Unit: second			n Time	DEB Retur	08.25
Factory Setting: 0		5 sec	0~2	Settings	

- The DEB (Deceleration Energy Backup) function is the AC motor drive decelerates to stop after momentary power loss. When the momentary power loss occurs, this function can be used for the motor to decelerate to 0 speed with deceleration stop method. When the power is on again, motor will run again after DEB return time. (for high-speed axis application)
- Related parameter: Pr.08.04(Momentary Power Loss Operation Selection)

 Status 1: Insufficient power supply due to momentary power-loss/unstable
 - Status 1: Insufficient power supply due to momentary power-loss/unstable power (due to low voltage)/sudden heavy-load





When Pr.08.24 is set to 0, the AC motor drive will be stopped and won't re-start at the power-on again.


Note1: 230Vac models LV+30V => Soft Start relay on level

LV+30V+14V => DEB return time calculate level

460Vac models LV+60V => Soft Start relay on level

LV+60V+28V => DEB return time calculate level

Status 2: unexpected power off, such as momentary power loss



08.	26 Speed Sea	arch du	ring Start-up
			Factory Setting: 0
	Settings	0	Disable
		1	Enable
	inertia will take need to wait fo PG card and e speed that is d When using the and Pr.13.01 a when using this Please make s	a long r the m ncoder etected is para ire set. s parai	ed for starting and stopping a motor with high inertia. A motor with high time to stop completely. By setting this parameter, the user does not notor to come to a complete stop before restarting the AC motor drive. If is used on the drive and motor, then the speed search will start from the by the encoder and accelerate quickly to the setting frequency. The meter with PG feedback control, this function will be enabled as Pr.13.00 It has no relation with Pr.00.10. Pr.08-04 and Pr.08-06 will be disabled meter with PG feedback control. 13.00 to Pr.13.02 are set correctly. An incorrect setting may cause the need limit and permanent damage to the motor and machine can occur.
08.	.27	earch	Frequency during Start-up
	<u> </u>		Factory Setting: 0
	Settings	0	Setting Frequency
		1	Maximum Operation Frequency (Pr.01.00)
	This paramete	r deter	mines the start value of the speed search frequency.
08.	Output Vol	tage Li	mit Unit: %

This parameter sets the limit for actual output voltage. For constant torque applications, sets this parameter to high value can lower the load current.

Factory Setting: 100

Settings

80~150%

08.29

✓ Special Bit Control Parameter

Factory Setting: 0

Settings Bit0=1,cancel internal frequency command filter

In order to let frequency command gently, drive can use frequency command filter but the response will be slow. If you want the fast response you can set Bit0=1(cancel internal frequency command filter).

Group 9: Communication Parameters

There is a built-in RS-485 serial interface, marked RJ-45 near to the control terminals. The pins are defined below:

RS-485 (NOT for VFD*E*C models)
8←1 Serial interface
1: Reserved 2: EV 3: GND
4: SG- 5: SG+ 6: Reserved
7: Reserved 8: Reserved

The pins definition for VFD*E*C models, please refer to chapter E.1.2.

Each VFD-E AC motor drive has a pre-assigned communication address specified by Pr.09.00. The RS485 master then controls each AC motor drive according to its communication address.

09	.00	nication	Address	
	Settings	1 to	254	Factory Setting: 1
	address for thi	s drive	s controlled by RS-485 serial commonust be set via this parameter. And solutions different and unique.	
09	.01 // Transmi	ssion S	peed	
				Factory Setting: 1
	Settings	0	Baud rate 4800 bps (bits / second	d)
		1	Baud rate 9600 bps	
		2	Baud rate 19200 bps	
		3	Baud rate 38400 bps	
	This paramete etc.) and AC n		d to set the transmission speed betwive.	veen the RS485 master (PLC, PC,
09	.02 // Transmi	ssion F	ault Treatment	
				Factory Setting: 3
	Settings	0	Warn and keep operating	
		1	Warn and RAMP to stop	
		2	Warn and COAST to stop	
		3	No warning and keep operating	
	Setting 0: whe digital keypad communication Setting 1: whe digital keypad press "RESET Setting 2: Whe digital keypad clear the warn Setting 3: Whe	n transi and the n is nori n transi and the in transi and the ing mes	mission errors occur, it will display wa motor will stop by the deceleration t ar the warning message. mission errors occur, it will display w motor will free run to stop immediate	arning message "cEXX" on the g message can be cleared after the arning message "cEXX" on the time (Pr.01.10/01.12). It needs to earning message "cEXX" on the tely. It needs to press "RESET" to

See list of error messages below (see section 3.6 in Pr.09.04)



The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.

09.03		Detection	n	Unit: second
	Settings	0.0 to	120.0 sec	Factory Setting: 0.0
		0.0	Disable	

If Pr.09.03 is not equal to 0.0, Pr.09.02=0~2, and there is no communication on the bus during the Time Out detection period (set by Pr.09.03), "cE10" will be shown on the keypad.

09.04		ation P	rotocol	
				Factory Setting: 0
	Settings	0	Modbus ASCII mode, protocol <7,N,2>	r dotory dotting. o
	J	1	Modbus ASCII mode, protocol <7,E,1>	
		2	Modbus ASCII mode, protocol <7,0,1>	
		3	Modbus RTU mode, protocol <8,N,2>	
		4	Modbus RTU mode, protocol <8,E,1>	
		5	Modbus RTU mode, protocol <8,O,1>	
		6	Modbus RTU mode, protocol <8,N,1>	
		7	Modbus RTU mode, protocol <8,E,2>	
		8	Modbus RTU mode, protocol <8,0,2>	
		9	Modbus ASCII mode, protocol <7,N,1>	
		10	Modbus ASCII mode, protocol <7,E,2>	
		11	Modbus ASCII mode, protocol <7,O,2>	

1. Control by PC or PLC

★ A VFD-E can be set up to communicate in Modbus networks using one of the following modes: ASCII (American Standard Code for Information Interchange) or RTU (Remote Terminal Unit). Users can select the desired mode along with the serial port communication protocol in Pr.09.04.

★Code Description:

The CPU will be about 1 second delay when using communication reset. Therefore, there is at least 1 second delay time in master station.

ASCII mode:

Each 8-bit data is the combination of two ASCII characters. For example, a 1-byte data:

64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

Character	' 0'	'1'	'2'	' 3'	'4 '	' 5'	' 6'	'7'
ASCII code	30H	31H	32H	33H	34H	35H	36H	37H
Character	'8'	' 9'	'A'	'B'	·С'	'D'	'Ε'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H


RTU mode:

Each 8-bit data is the combination of two 4-bit hexadecimal characters. For example, 64


Hex.

2. Data Format

10-bit character frame (For ASCII):



11-bit character frame (For RTU):



3. Communication Protocol

3.1 Communication Data Frame:

ASCII mode:

STX	Start character ':' (3AH)	
Address Hi	Communication address:	
Address Lo	8-bit address consists of 2 ASCII codes	
Function Hi	Command code:	
Function Lo	8-bit command consists of 2 ASCII codes	
DATA (n-1) to DATA 0	Contents of data: Nx8-bit data consist of 2n ASCII codes n<=20, maximum of 40 ASCII codes	

LRC CHK Hi	LRC check sum:
LRC CHK Lo	8-bit check sum consists of 2 ASCII codes
END Hi	End characters:
END Lo	END1= CR (0DH), END0= LF(0AH)

RTU mode:

START	A silent interval of more than 10 ms	
Address	Communication address: 8-bit address	
Function	Command code: 8-bit command	
DATA (n-1) to DATA 0	Contents of data: n×8-bit data, n<=40 (20 x 16-bit data)	
CRC CHK Low	CRC check sum:	
CRC CHK High	16-bit check sum consists of 2 8-bit characters	
END	A silent interval of more than 10 ms	

3.2 Address (Communication Address)

Valid communication addresses are in the range of 0 to 254. A communication address equal to 0, means broadcast to all AC drives (AMD). In this case, the AMD will not reply any message to the master device.

00H: broadcast to all AC drives 01H: AC drive of address 01

0FH: AC drive of address 15

10H: AC drive of address 16

:

FEH: AC drive of address 254

For example, communication to AMD with address 16 decimal (10H):

ASCII mode: Address='1','0' => '1'=31H, '0'=30H

RTU mode: Address=10H

3.3 Function (Function code) and DATA (data characters)

The format of data characters depends on the function code.

03H: read data from register 06H: write single register

08H: loop detection

10H: write multiple registers

The available function codes and examples for VFD-E are described as follows:

(1) 03H: multi read, read data from registers.

Example: reading continuous 2 data from register address 2102H, AMD address is 01H. ASCII mode:

Command message:

STX	.,
Address	' 0'
	'1'
Function	'0'
	'3'
Starting data address	'2'
	'1'
	·O'
	'2'
Number of data (count by word)	' 0'
	'0'
	'0'
	'2'
LRC Check	'D'
	'7'
END	CR
END	LF

RTU mode:

Command message:

Address	01H
Function	03H
Starting data	21H
address	02H
Number of data	00H
(count by word)	02H
CRC CHK Low	6FH
CRC CHK High	F7H

Response message:

STX	6.7
317	
Address	'0'
	'1'
Function	'0'
	'3'
Number of data	·0'
(Count by byte)	'4 '
Contant of stanting	'1 '
Content of starting address	'7'
2102H	'7'
21020	' 0'
	·O'
Content of address 2103H	·O'
	·0'
	' 0'
LRC Check	'7'
	'1'
END	CR
	LF

rtooponoo moodago.	
Address	01H
Function	03H
Number of data (count by byte)	04H
Content of address	17H
2102H	70H
Content of address	00H
2103H	00H
CRC CHK Low	FEH
CRC CHK High	5CH

(2) 06H: single write, write single data to register. Example: writing data 6000(1770H) to register 0100H. AMD address is 01H.

ASCII mode:

Command message:

STX	.,
Address	·0'
	'1'
Function	·0'
	·6'
Data address	·O'
	'1'
	·O'
	·0'
	'1'
Data content	'7'
Data content	'7'
	' 0'
LRC Check	'7'
	'1'
END	CR
	LF

Response message:

STX	·.·
Address	'0'
Address	'1'
Function	'0'
	'6'
Data address	'0'
	'1'
Data address	'0'
	'0'
	'1'
Data content	'7 '
Data content	'7 '
	'0'
LRC Check	'7'
	'1'
END	CR
EIND	LF

RTU mode:

Command message:

Address	01H
Function	06H
Data address	01H
Data address	00H
Data content	17H
Data Content	70H
CRC CHK Low	EEH
CRC CHK High	1FH

Address	01H
Function	06H
Data address	01H
Dala address	00H
Data content	17H
Data Content	70H
CRC CHK Low	EEH
CRC CHK High	1FH

(3) 08H: loop detection

This command is used to detect if the communication between master device (PC or PLC) and AC motor drive is normal. The AC motor drive will send the received message to the master device.

ASCII mode:

Command message:

STX	· . ·
Address	·0'
	'1'
Function	·0'
	'8'
Data address	·O'
	·O'
	'0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	' 0'
END	CR
	LF

Response message:

STX	.,
Addross	'0'
Address	'1'
Function	'0'
Function	'8'
	'0'
Data address	'0'
Data address	'0'
	'0'
	'1'
Data content	'7 '
Data content	'7 '
	'0'
LRC Check	'7 '
LKC Check	'0'
END	CR
END	LF

RTU mode:

Command message:

Address	01H
Function	08H
Data address	00H
Data address	00H
Data content	17H
Data content	70H
CRC CHK Low	EEH
CRC CHK High	1FH

Address	01H
Function	08H
Data address	00H
Data address	00H
Data content	17H
Data content	70H
CRC CHK Low	EEH
CRC CHK High	1FH

(4) 10H: write multiple registers (write multiple data to registers) Example: Set the multi-step speed,

Pr.05.00=50.00 (1388H), Pr.05.01=40.00 (0FA0H). AC drive address is 01H.

ASCII Mode:

Command message:

Communa message.				
STX	· . ·			
Address 1	' 0'			
Address 0	'1'			
Function 1	'1'			
Function 0	'0'			
	'0'			
Starting data	' 5'			
address	'0'			
	' 0'			
	' 0'			
Number of data	'0'			
(count by word)	'0'			
	'2'			
Number of data	' 0'			
(count by byte)	'4'			
	'1'			
The first data	'3'			
content	'8 '			
	'8 '			
	' 0'			
The second data	'F'			
content	'A'			
	' 0'			
LRC Check	' 9'			
LKC CHECK	'A'			
END	CR			
	LF			

Response message:

STX	· . ·
Address 1	'0'
Address 0	'1'
Function 1	'1'
Function 0	'0'
	' 0'
Starting data	' 5'
address	' 0'
	'0'
	' 0'
Number of data (count by word)	' 0'
	' 0'
	'2'
LDC Charle	'E'
LRC Check	'8'
END	CR
END	LF

RTU mode:

Command message:

Address	01H	
Function	10H	
Starting data	05H	
address	00H	
Number of data	00H'	
(count by word)	02H	
Number of data	04	
(count by byte)		
The first data	13H	
content	88H	
The second data	0FH	
content	A0H	
CRC Check Low	4DH	
CRC Check High	D9H	

rtespense messager				
Address	01H			
Function	10H			
Starting data address	05H			
	00H			
Number of data	00H			
(count by word)	02H			
CRC Check Low	41H			
CRC Check High	04H			

3.4 Check sum

ASCII mode:

LRC (Longitudinal Redundancy Check) is calculated by summing up, module 256, the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

For example, reading 1 word from address 0401H of the AC drive with address 01H.

STX	6.3 -
Address 1	' 0'
Address 0	'1'
Function 1	' 0'
Function 0	'3'
	' 0'
Starting data address	'4'
Starting data address	' 0'
	'1'
	' 0'
Number of data	' 0'
Number of data	' 0'
	'1'
LRC Check 1	'F'
LRC Check 0	'6 '
END 1	CR
END 0	LF

01H+03H+04H+01H+00H+01H=0AH, the 2's-complement negation of 0AH is <u>F6</u>H. RTU mode:

Address	01H
Function	03H
Starting data address	21H
	02H
Number of data	00H
(count by word)	02H
CRC CHK Low	6FH
CRC CHK High	F7H

CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFFH.

Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.

Step 3: Examine the LSB of CRC register.

Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right with MSB zero filling, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right with MSB zero filling, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.

Step 5: Repeat step 3 and 4 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed.

Step 6: Repeat step 2 to 5 for the next 8-bit byte of the command message. Continue doing this until all bytes have been processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.

The following is an example of CRC generation using C language. The function takes two arguments:

```
Unsigned char* data ← a pointer to the message buffer
Unsigned char length ← the quantity of bytes in the message buffer
The function returns the CRC value as a type of unsigned integer.
Unsigned int crc_chk(unsigned char* data, unsigned char length){
  int j;
  unsigned int reg_crc=0xFFFF;
  while(length--){
    reg_crc ^= *data++;
    for(j=0;j<8;j++){
        if(reg_crc & 0x01){ /* LSB(b0)=1 */
            reg_crc=(reg_crc>>1) ^ 0xA001;
        }else{
        reg_crc=reg_crc >>1;
        }
    }
    return reg_crc;
}
```

3.5 Address list

The contents of available addresses are shown as below:

Content	Address	Function		
AC drive Parameters	GGnnH	GG means parameter group, nn means parameter number, for example, the address of Pr 04.01 is 0401H. Refer to chapter 5 for the function of each parameter. When reading parameter by command code 03H, only one parameter can be read at one time.		
	Command	Bit 0-1	00B: No function 01B: Stop 10B: Run 11B: Jog + Run	
		Bit 2-3	Reserved	
Write only 2000H	Bit 4-5	00B: No function 01B: FWD 10B: REV 11B: Change direction		
		Bit 6-7	00B: Comm. forced 1st accel/decel 01B: Comm. forced 2nd accel/decel	

Address			
	Function		
	Bit 8-15	Reserved	
2001H	Frequency command		
		1: EF (external fault) on	
2002H	Bit 1	1: Reset	
	Bit 2-15	Reserved	
	Error code:		
2100H	0: No error occurred		
	1: Over-current (oc)		
	2: Over-volt	tage (ov)	
	3: IGBT Ov	erheat (oH1)	
	4: Reserved	d	
	5: Overload	l (oL)	
	6: Overload1 (oL1) 7: Overload2 (oL2) 8: External fault (EF) 9: Current exceeds 2 times rated current during accel (ocA) 10: Current exceeds 2 times rated current during decel (ocd) Current exceeds 2 times rated current during decel (ocd) 11: Current exceeds 2 times rated current during steady state operation (ocn)		
	12: Ground	f Fault (GFF)	
	13: Low vol	tage (Lv)	
	14: PHL (Pl	nase-Loss)	
2100H	15: Externa	l Base Block (bb)	
	16: Auto ac	cel/decel failure (cFA)	
	17: Softwar	e protection enabled (codE)	
	18: Power E	Board CPU WRITE failure (CF1.0)	
	19: Power E	Board CPU READ failure (CF2.0)	
	20: CC, OC	Hardware protection failure (HPF1)	
	21: OV Har	dware protection failure (HPF2)	
	2002H	Bit 0 2002H	

Content	Address	Function			
		22: GFF Hardware protection failure (HPF3)			
		23: OC Hardware protection failure (HPF4)			
		24: U-phase error (cF3.0)			
		25: V-phas	se error (cF3.1)		
		26: W-pha	se error (cF3.2)		
		27: DCBU	S error (cF3.3)		
		28: IGBT (Overheat (cF3.4)		
		29: Reserv	ved .		
		30: Contro	l Board CPU WRITE failure (cF1.1)		
		31: Contro	l Board CPU WRITE failure (cF2.1)		
		32: ACI sig	gnal error (AErr)		
		33: Reserv	33: Reserved		
		34: Motor PTC overheat protection (PtC1) 35: PG feedback signal error (PGEr) 36~39: Reserved 40: Communication time-out error of control board and power board (CP10) 41: dEb error			
		42: ACL (Abnormal Communication Loop)			
		66: U pha	se output phase loss (oPHL1)		
		67: V phase output phase loss (oPHL2)			
		68: W phase output phase loss (oPHL3)			
		Status of A	AC drive		
			00B: RUN LED is off, STOP LED is on (The AC motor Drive stops)		
	2101H	101H Bit 0-1	Bit 0-1		01B: RUN LED blinks, STOP LED is on (When AC motor drive decelerates to stop)
					BIT U-1
			11B: RUN LED is on, STOP LED is off (When AC motor drive runs)		

arameters				
Content	t Address	Function		
		Bit 2	1: JOG command	
		Bit 3-4	00B: FWD LED is on, REV LED is off (When AC motor drive runs forward)	
			01B: FWD LED is on, REV LED blinks (When AC motor drive runs from reverse to forward)	
			10B: FWD LED blinks, REV LED is on (When AC motor drive runs from forward to reverse)	
			11B: FWD LED is off, REV LED is on (When AC motor drive runs reverse)	
		Bit 5-7	Reserved	
		Bit 8	Master frequency Controlled by communication interface	
		Bit 9	1: Master frequency controlled by analog signal	
		Bit 10	Operation command controlled by communication interface	
		Bit 11-15	Reserved	
	2102H	Frequency command (F)		
	2103H	Output free	quency (H)	
	2104H	Output cur	rent (AXXX.X)	
	2105H	Reserved		
	2106H	Reserved		
	2107H	Reserved		
	2108H	DC-BUS Voltage (UXXX.X)		
2109H 210AH 2116H 2117H		Output voltage (EXXX.X)		
		Display temperature of IGBT (°C)		
		User defined (Low word)		
		User defined (High word)		

Note: 2116H is number display of Pr.00.04. High byte of 2117H is number of decimal places of 2116H. Low byte of 2117H is ASCII code of alphabet display of Pr.00.04. 3.6 Exception response:

The AC motor drive is expected to return a normal response after receiving command messages from the master device. The following depicts the conditions when no normal response is replied to the master device.

The AC motor drive does not receive the messages due to a communication error; thus, the AC motor drive has no response. The master device will eventually process a timeout condition.

The AC motor drive receives the messages without a communication error, but cannot handle them. An exception response will be returned to the master device and an error message "CExx" will be displayed on the keypad of AC motor drive. The xx of "CExx" is a decimal code equal to the exception code that is described below.

In the exception response, the most significant bit of the original command code is set to 1, and an exception code which explains the condition that caused the exception is returned.

Example of an exception response of command code 06H and exception code 02H:

ASCII mode:

STX	.,
Address Low	'0'
Address High	'1'
Function Low	'8'
Function High	'6'
Evention and	'0'
Exception code	'2'
LRC CHK Low	'7'
LRC CHK High	'7'
END 1	CR
END 0	LF

RTU mode:

Address	01H
Function	86H
Exception code	02H
CRC CHK Low	СЗН
CRC CHK High	A1H

The explanation of exception codes:

Exception code	Explanation
01	Illegal function code: The function code received in the command message is not available for the AC motor drive.
02	Illegal data address: The data address received in the command message is not available for the AC motor drive.
03	Illegal data value: The data value received in the command message is not available for the AC drive.
04	Slave device failure: The AC motor drive is unable to perform the requested action.

Exception code	Explanation	
10	Communication time-out: If Pr.09.03 is not equal to 0.0, Pr.09.02=0~2, and there is no communication on the bus during the Time Out detection period (set by Pr.09.03), "cE10" will be shown on the keypad.	

3.7 Communication program of PC: The following is a simple example of how to write a communication program for Modbus ASCII mode on a PC in C language. #include<stdio.h> #include<dos.h> #include<conio.h> #include<process.h> #define PORT 0x03F8 /* the address of COM1 */ /* the address offset value relative to COM1 */ #define THR 0x0000 #define RDR 0x0000 #define BRDL 0x0000 #define IER 0x0001 #define BRDH 0x0001 #define LCR 0x0003 #define MCR 0x0004 #define LSR 0x0005 #define MSR 0x0006 unsigned char rdat[60]; /* read 2 data from address 2102H of AC drive with address 1 */ unsigned char tdat[60]={':','0','1','0','3','2','1','0','2', '0','0','0','2','D','7','\r','\n'}; void main(){ int i; outportb(PORT+MCR,0x08); /* interrupt enable */ outportb(PORT+IER,0x01); /* interrupt as data in */ outportb(PORT+LCR,(inportb(PORT+LCR) | 0x80)); /* the BRDL/BRDH can be access as LCR.b7==1 */ /* set baudrate=9600, 12=115200/9600*/ outportb(PORT+BRDL.12): outportb(PORT+BRDH,0x00): /* set protocol, <7,N,2>=06H, <7,E,1>=1AH, outportb(PORT+LCR,0x06); <7.O.1>=0AH, <8.N.2>=07H, <8.E.1>=1BH, <8.O.1>=0BH */ for(i=0:i <= 16:i++)while(!(inportb(PORT+LSR) & 0x20)); /* wait until THR empty */ outportb(PORT+THR,tdat[i]); /* send data to THR */ } i=0; while(!kbhit()){ if(inportb(PORT+LSR) & 0x01){ /* b0==1, read data ready */ rdat[i++]=inportb(PORT+RDR); /* read data form RDR */ } } } Reserved 09.05 Reserved 09.06 09.07 Unit: 2ms Settings $0 \sim 200 (400 \text{msec})$ Factory Setting: 1 This parameter is the response delay time after AC drive receives communication command as shown in the following. 1 unit = 2 msec. RS485 BUS PC or PLC command Response Message of AC Drive

Response Delay Time

Pr 09 07

Handling time

of AC drive

Max.: 6msec

09.08

Factory Setting: 2

- Settings 0 Baud rate 4800 bps
 - 1 Baud rate 9600 bps
 - 2 Baud rate 19200 bps
 - 3 Baud rate 38400 bps
 - 4 Baud rate 57600 bps
- This parameter is used to set the transmission speed for USB card.

09.09

Factory Setting: 1

- Settings 0 Modbus ASCII mode, protocol <7,N,2>
 - 1 Modbus ASCII mode, protocol <7,E,1>
 - 2 Modbus ASCII mode, protocol <7,O,1>
 - 3 Modbus RTU mode, protocol <8,N,2>
 - 4 Modbus RTU mode, protocol <8,E,1>
 - 5 Modbus RTU mode, protocol <8,O,1>
 - 6 Modbus RTU mode, protocol <8,N,1>
 - 7 Modbus RTU mode, protocol <8,E,2>
 - 8 Modbus RTU mode, protocol <8,0,2>
 - 9 Modbus ASCII mode, protocol <7,N,1>
 - 10 Modbus ASCII mode, protocol <7,E,2>
 - 11 Modbus ASCII mode, protocol <7,0,2>

09.10 ✓ Transmission Fault Treatment for USB Card

Factory Setting: 0

- Settings 0 Warn and keep operating
 - 1 Warn and RAMP to stop
 - 2 Warn and COAST to stop
 - 3 No warning and keep operating
- This parameter is set to how to react when transmission errors occurs.
- Setting 0: when transmission errors occur, it will display warning message "cEXX" on the digital keypad and the motor will keep running. The warning message can be cleared after the communication is normal.
- Setting 1: when transmission errors occur, it will display warning message "cEXX" on the digital keypad and the motor will stop by the deceleration time (Pr.01.10/01.12). It needs to press "RESET" to clear the warning message.
- Setting 2: When transmission errors occur, it will display warning message "cEXX" on the digital keypad and the motor will free run to stop immediately. It needs to press "RESET" to clear the warning message.

- Setting 3: When transmission errors occur, it won't display any warning message on the digital keypad and the motor will still keep running.
- See list of error messages below (see section 3.6 in Pr.09.04)



The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.


09.11		Detecti	on for USB Card	Unit: second
	Settings	0.0 to	o 120.0 sec	Factory Setting: 0.0
		0.0	Disable	
09.12	COM port f	or PLC	Communication (NOT for VFD*E*C models)	
				Factory Setting: 0
	Settings	0	RS485	
		1	USB card	

Group 10: PID Control

- A. Common applications for PID control
- 1. Flow control: A flow sensor is used to feedback the flow data and perform accurate flow control.
- 2. Pressure control: A pressure sensor is used to feedback the pressure data and perform precise pressure control.
- 3. Air volume control: An air volume sensor is used to feedback the air volume data to have excellent air volume regulation.
- 4. Temperature control: A thermocouple or thermistor is used to feedback temperature data for comfortable temperature control.
- 5. Speed control: A speed sensor or encoder is used to feedback motor shaft speed or input another machines speed as a target value for closed loop speed control of master-slave operation.

Pr.10.00 sets the PID setpoint source (target value). PID control operates with the feedback signal as set by Pr.10.01 either 0~+10V voltage or 4-20mA current.

B. PID control loop:



 K_p : Proportional gain(P) T_i : Integral time(I) T_d : Derivative control(D) S: Operator


C. Concept of PID control

- 1. Proportional gain(P): the output is proportional to input. With only proportional gain control, there will always be a steady-state error.
- 2. Integral time(I): the controller output is proportional to the integral of the controller input. To eliminate the steady-state error, an "integral part" needs to be added to the controller. The integral time decides the relation between integral part and error. The integral part will be increased by time even if the error is small. It gradually increases the controller output to eliminate the error until it is 0.

In this way a system can be stable without steady-state error by proportional gain control and integral time control.

- 3. Differential control (D): the controller output is proportional to the differential of the controller input. During elimination of the error, oscillation or instability may occur. The differential control can be used to suppress these effects by acting before the error. That is, when the error is near 0, the differential control should be 0. Proportional gain (P) + differential control (D) can be used to improve the system state during PID adjustment.
- D. When PID control is used in a constant pressure pump feedback application:

Set the application's constant pressure value (bar) to be the setpoint of PID control. The pressure sensor will send the actual value as PID feedback value. After comparing the PID setpoint and PID feedback, there will be an error. Thus, the PID controller needs to calculate the output by using proportional gain(P), integral time(I) and differential time(D) to control the pump. It controls the drive to have different pump speed and achieves constant pressure control by using a 4-20mA signal corresponding to 0-10 bar as feedback to the drive.



- 1. Pr.00.04 is set to 5 (Display PID analog feedback signal value (b) (%))
- 2. Pr.01.09 Acceleration Time will be set as required
- 3. Pr.01.10 Deceleration Time will be set as required
- 4. Pr.02.01=1 to operate from the digital keypad
- 5. Pr.10.00=1, the setpoint is controlled by the digital keypad
- 6. Pr.10.01=3(Negative PID feedback from external terminal ACI (4 ~ 20mA)/ AVI2 (0 ~ +10VDC))
- 7. Pr.10.01-10.17 will be set as required
- 7.1 When there is no vibration in the system, increase Pr.10.02(Proportional Gain (P))
- 7.2 When there is no vibration in the system, reduce Pr.10.03(Integral Time (I))
- 7.3 When there is no vibration in the system, increase Pr.10.04(Differential Time(D))
- 8. Refer to Pr.10.00-10.17 for PID parameters settings.

Ľ	r	1	n	n
•				

PID Set Point Selection

Factory Setting: 0

Cattinana	^	Disable
Settings	U	Disable

- 1 Digital keypad UP/DOWN keys
- 2 AVI 0 ~ +10VDC
- 3 ACI 4 ~ 20mA / AVI2 0 ~ +10VDC
- 4 PID set point (Pr.10.11)

10.01 Input Terminal for PID Feedback

Factory Setting: 0

- Settings 0 **Positive** PID feedback from external terminal AVI (0 ~ +10VDC).
 - 1 **Negative** PID feedback from external terminal AVI (0 \sim +10VDC).
 - Positive PID feedback from external terminal ACI (4 ~ 20mA)/ AVI2 (0 ~ +10VDC).
 - Negative PID feedback from external terminal ACI $(4 \sim 20\text{mA})$ / AVI2 $(0 \sim +10\text{VDC})$.
- Note that the measured variable (feedback) controls the output frequency (Hz).
- When Pr.10.00=2 or 3, the set point (Master Frequency) for PID control is obtained from the AVI or ACI/AVI2 external terminal (0 to +10V or 4-20mA) or from multi-step speed. When Pr.10.00=1, the set point is obtained from the keypad.
- When Pr.10.01=1 or 3 (Negative feedback): Error (Err) = setpoin(SP) feedback(FB). When the feedback will be increased by the increasing output frequency, please use this setting.
- When Pr.10.01= to 0 or 2 (Positive feedback): Error (Err) = feedback(FB)- setpoint(SP) When the feedback will be decreased by the increasing output frequency, please use this setting.
- Select input terminal accordingly. Make sure this parameter setting does not conflict with the setting for Pr.10.00 (Master Frequency).
- Related parameters: Pr.00.04 Content of Multi-function Display (set to 5 Display PID analog feedback signal value (b) (%)), Pr. 10.11(Source of PID Set point) and Pr.04.19(ACI/AVI2 Selection)

10.11 ✓ Source of PID Set point

Unit: Hz

Settings 0.00 to 600.00Hz

Factory Setting: 0.00

(Japanese version: 0.00 to 599.00 Hz)

This parameter is used in conjunction with Pr.10.00 set 4 to input a set point in Hz.

10.02

Settings 0.0 to 10.0

Factory Setting: 1.0

It is used to eliminate the system error. It is usually used to decrease the error and get the faster response speed. But if setting too large value in Pr.10.02, it may cause the system oscillation and instability.

Chap		the faster response it will g	o decide the responds speed. The larger va et. The smaller value is set in Pr.10.02, the s	
	If the other two	gains (I and D) are set to ze	ero, proportional control is the only one effect e (I)) and Pr.10.04(Differential Control (D))	ctive.
10.	03	Fime (I)	Unit: s	second
	Settings	0.00 to 100.0 sec	Factory Setting	g: 1.00
		0.00 Disable		
	doesn't stop we integral time is oscillation to m integral control This parameter will have small integral time is	orking until error is 0. The integral actions as the stronger integral actions as a stable system. At this is often used with other two is used to set the integral to gain of I controller, the slow short, it will have large gain	he error during stable system. The integral egral is acted by the integral time. The sma ion will be. It is helpful to reduce overshoot moment, the decreasing error will be slow. controls to become PI controller or PID conne of I controller. When the integral time is er response and bad external control. When of I controller, the faster response and rapid	ller and The itroller. long, it i the
	external contro	l. ral time is too small, it may (eause system oscillation	
	When it is set t	o 0.0, the integral function is	disabled.	
	Related param	eter: Pr.10.05(Upper Bound	for Integral Control)	
10.	⊘ Different	al Control (D)	Unit: s	second
	Settings	0.00 to 1.00 sec	Factory Setting	g: 0.00
	preview the chaimprove system adjustment time. Please note that shows the chaim Therefore, the two controllers. This parameter change. The standard decrease the object of the system oscillate. The differential	ange of error. So the different state. With the suitable differential can too large differential will can ge and the output of the differential control can't be used to make a PD controller or Forcan be used to set the gain uitable differential time can rescillation and have a stable ion.	of D controller to decide the response of ereduce the overshoot of P and I controller to system. But too long differential time may call of error and can't reduce the interference	error to horten e. ferential n other rror ause
10.	05 Upper Bou	ınd for Integral Control		Unit: %
	Settings	0 to 100 %	Factory Settin	ng: 100
	This parameter	defines an upper bound or	imit for the integral gain (I) and therefore lin	nits the


- Master Frequency. The formula is: Integral upper bound = Maximum Output Frequency (Pr.01.00) x (Pr.10.05).

 Too large integral value will make the slow response due to sudden load change. In this way, it
- may cause motor stall or machine damage.
 Related parameter: Pr.01.00(Maximum Output Frequency (Fmax))

10	.06 Primary Delay Filter Time	Unit: second
	Settings 0.0 to 2.5 sec	Factory Setting: 0.0
	It is used to set the time that required for the low-pass filter of Pl setting, it may affect the drive's response speed.	D output. Increasing the
	The frequency output of PID controller will filter after primary del change of the frequency output. The longer primary delay filter t time it will be.	

The unsuitable primary delay filter time may cause system oscillation.

PID control can be used for speed, pressure and flow control. It needs to use with the relevant equipment of sensor feedback for PID control. Refer to the following for the closed-loop control diagram.



10.07 PID Output Frequency Limit Unit: %

Settings 0 to 110 % Factory Setting: 100

- This parameter defines the percentage of output frequency limit during the PID control. The formula is Output Frequency Limit = Maximum Output Frequency (Pr.01.00) X Pr.10.07 %. This parameter will limit the Maximum Output Frequency. An overall limit for the output frequency can be set in Pr.01.07.
- Related parameter: Pr.01.00(Maximum Output Frequency (Fmax))


10.08 PID Feedback Signal Detection Time		Unit: second		
		Settings	0.0 to d 3600 sec	Factory Setting: 60.0
	wa	•		e PID feedback must be abnormal before a odified according to the system feedback
	If t	his paramete	er is set to 0.0, the system would	not detect any abnormality signal.
			eive PID feedback signal over Pr. se refer to Pr.10.09 for the fault tr	10.08 setting, the feedback signal fault will eatment.
	Re	elated param	eter: Pr.10.09(Treatment of the E	rroneous PID Feedback Signals)


10.	09 Treatment	of the E	rroneous Feedback Signals (for PID fee	edback error)
				Factory Setting: 0
	Settings	0	Warning and RAMP to stop	
		1	Warning and COAST to stop	
		2	Warning and keep operating	
	AC motor drive according to Pr		when the feedback signals (analog PID	feedback) are abnormal
	Setting Pr.10.0	9 to 0: V motor	When the feedback signal fault occurs, i will stop to 0Hz by Pr.01.10/Pr.01.12 se	. ,
	Setting Pr.10.0	9 to 1: \	When the feedback signal fault occurs, i will free run to stop. It needs to press "F	
	Setting Pr.10.0	motor	When the feedback signal fault occurs, will keep running. The warning messag	
	Related parame	eters" P	r.10.00(PID Set Point Selection), Pr.10 ID Offset Level) and Pr.10.13(Detection	
	NOTE			
The c	digital keypad is o	ptional	Please refer to Appendix B for details.	When using without this optional
keypa	ad, the FAULT LE	ED will b	be ON once there is error messages or	warning messages from the
exter	nal terminals.			
10.	Gain Over t	he PID	Detection Value	
	Settings	0.0 to	o 10.0	Factory Setting: 1.0
	This parameter	will affe	nent over the feedback detection value. ect Pr.00.04(setting 5) directly. That is F I value (b) (%)= PID detection value X 0	Pr.00.04(setting 5) Display PID
			r.00.04(Content of Multi-function Displa	y) and Pr.10.01(Input Terminal
10.	PID Offset	Level		Unit: %
	Settings	1.0 to	50.0%	Factory Setting: 10.0
	This parameter	is used	I to set max. allowable value of PID erro	or.
10.	13 Detection T	ime of I	PID Offset	Unit: second
	Settings	0.1 to	o 300.0 sec	Factory Setting: 5.0
				-

This parameter is used to set detection of the offset between set point and feedback.

Chap	when the offset is higher than the setting of Pr.10.12 for a time exceeding the setting of Pr.10.13, PID feedback signal fault occurs and operates by the treatment set in Pr.10.09. Related parameters: Pr.10.00(PID Set Point Selection), Pr.10.01(Input Terminal for PID Feedback), Pr.10.09(Treatment of the Erroneous PID Feedback Signals) and Pr.10.12(PID Offset Level)			
10	.17 Minimum P	ID Out	out Frequency Selection	
	-			Factory Setting: 0
	Settings	0	By PID control	
		1	By Minimum output frequency (Pr.01	.05)
	This is the source selection of minimum output frequency when control is by PID. The output of the AC motor drive will refer to this parameter setting. When this parameter is set to 0, the output frequency will output by the calculation of PID. When this parameter is set to 1 and Pr.01.08 is not set to 0, the output frequency=Pr.01.08 setting. Otherwise, the output frequency=Pr.01.05 setting. Related parameters: Pr.01.05(Minimum Output Frequency (Fmin) (Motor 0)) and Pr.01.08(Output Frequency Lower Limit)			
10	.14 Sleep/Wak	e Up D	etection Time	Unit: second
	Settings	0.0 t	o 6550 sec	Factory Setting: 0.0
	If PID frequency is less than the sleep frequency when the drive starts running, the drive will be in sleep mode immediately and won't limit by this parameter. Related parameters: Pr.10.15(Sleep Frequency) and Pr.10.16(Wakeup Frequency)			
10	Sleep Frequency			Unit: Hz
	Settings	0.00	to Fmax Hz	Factory Setting: 0.00
	This parameter set the frequency for the AC motor drive to be in sleep mode. The AC motor drive will stop outputting after being sleep mode, but PID controller keep operating.			
10	.16 Wakeup Fr	equenc	у	Unit: Hz
	Settings	0.00	to Fmax Hz	Factory Setting: 0.00
		is use	d to set the wakeup frequency to restart	the AC motor drive after sleep
	mode. The wake up fr	egueno	y must be higher than sleep frequency.	
	When the actual output frequency \leq Pr.10.15 and the time exceeds the setting of Pr.10.14, the AC motor drive will be in sleep mode and the motor will decelerate to stop by Pr.01.10/01.12 setting.			
		•	ency command > Pr.10.16 and the time	exceeds the setting of Pr.10.14,
	the AC motor drive will restart. When the AC motor drive is in sleep mode, frequency command is still calculated by PID. When frequency reaches wake up frequency, AC motor drive will accelerate from Pr.01.05			

minimum frequency following the V/f curve.






When Pr. 01.05min. output frequency ≤ PID frequency (H) ≤ Pr.01.08 lower bound of frequency and sleep function is enabled (output frequency (H) < Pr.10.15 sleep frequency and time > Pr.10.14 detection time), frequency will be 0 (in sleep mode). If sleep function is disabled, output frequency(H) = Pr.01.08 lower bound frequency.



The common adjustments of PID control are shown as follows:


Example 1: how to have stable control as soon as possible?

Please shorten Pr.10.03 (Integral Time (I)) setting and increase Pr,10.04(Differential Control (D)) setting.



Example 2: How to suppress the oscillation of the wave with long cycle?


If it is oscillation when the wave cycle is longer than integral time, it needs to increase Pr.10.03 setting to suppress the oscillation.



Example 3: How to suppress the oscillation of the wave with short cycle?

When the cycle of oscillation is short and almost equal Differential time setting, it needs to shorten the differential time setting to suppress the oscillation. If Differential time(I) = 0.0, it can not suppress the oscillation. Please reduce Pr.10.02 setting or increase Pr.10.06 setting.

Response



Group 11: Multi-function Input/Output Parameters for Extension Card

11.00	Multi-function Output Terminal MO2/RA2	
11.01	Multi-function Output Terminal MO3/RA3	
11.02	Multi-function Output Terminal MO4/RA4	
11.03	Multi-function Output Terminal MO5/RA5	
11.04	Multi-function Output Terminal MO6/RA6	
11.05	Multi-function Output Terminal MO7/RA7	
	Settings 0 to 24 Fac	tory Setting: 0

- Please make sure that the extension card is installed on the AC motor drive correctly, the extension card will be detected automatically thus the Pr. Group 11 will be displayed, and you can set the parameters. If there is no extension card installation, the parameters only can display and set Pr. Group 0 ~ Group 10. See Appendix B for details.
- Please refer to Pr.03.01 function table for Multi-function output terminal function settings.
- Please set the parameters according to the terminal name on the extension card.

11.06	Multi-function Input Terminal (MI7)				
11.07	Multi-function Input Terminal (MI8)				
11.08	Multi-function Input Terminal (MI9)				
11.09	Multi-function Input Terminal (MI10)				
11.10	Multi-function Input Terminal (MI11)				
11.11	Multi-function Input Terminal (MI12)				
	Settings 0 to 28	Factory Setting: 0			

Refer to the table below Pr.04.08 for setting the multifunction input terminals.

Set the corresponding parameter according to the terminal labeled on the extension card.

Group 12: Analog Input/Output Parameters for Extension Card

Make sure that the extension card is installed on the AC motor drive correctly before using group 12 parameters. See Appendix B for details.

12.00 Al1 Function Selection

Factory Setting: 0

Settings 0 Disabled

- 1 Source of the 1st frequency
- 2 Source of the 2nd frequency
- 3 PID Set Point (PID enable)
- 4 Positive PID feedback
- 5 Negative PID feedback


12.01 Al1 Analog Signal Mode

Factory Setting: 1

Settings 0 ACI2 analog current (0.0 ~ 20.0mA)

1 AVI3 analog voltage (0.0 ~ 10.0V)

Besides parameters settings, the voltage/current mode should be used with the switch.



12.02	Min. AVI3 In	put Voltage	Unit: V
	Settings	0.0 to 10.0V	Factory Setting: 0.0


12.03	Min. AVI3	Scale Percentage	Unit: %
	Settings	0.0 to 100.0%	Factory Setting: 0.0

12.04	Max. AVI3	Input Voltage	Unit: V
	Settings	0.0 to 10.0V	Factory Setting: 10.0

Chapter -	4 Parameters
-----------	--------------

12.05 Max. AVI3	Scale I	Percentage	Unit: %
Settings	0.0	to 100.0%	Factory Setting: 100.0
12.06 Min. ACI2	Input C	urrent	Unit: mA
Settings	0.0	to 20.0mA	Factory Setting: 4.0
12.07 Min. ACI2	Scale F	Percentage	Unit: %
Settings	0.0	to 100.0%	Factory Setting: 0.0
12.08 Max. ACI2	2 Input C	Current	Unit: mA
Settings	0.0	to 20.0mA	Factory Setting: 20.0
12.09 Max. ACI2	2 Scale	Percentage	Unit: %
Settings	0.0	to 100.0%	Factory Setting: 100.0
12.10 Al2 Functi	on Sele	ction	
			Factory Setting: 0
Settings	0	Disabled	
	1	Source of the 1st frequency	
	2	Source of the 2nd frequency	
	3	PID Set Point (PID enable)	
	4	Positive PID feedback	
	5	Negative PID feedback	
12.11 Al2 Analog	g Signal	Mode	
			Factory Setting: 1
Settings	0	ACI3 analog current (0.0 ~ 20.0mA)	
	1	AVI4 analog voltage (0.0 ~ 10.0V)	

Besides parameters settings, the voltage/current mode should be used with the switch.



Unit: V	nput Voltage	12.12 Min. AVI4 I
Factory Setting: 0.0	0.0 to 10.0V	Settings
Unit: %	Scale Percentage	12.13 Min. AVI4 S
Factory Setting: 0.0	0.0 to 100.0%	Settings
Unit: V	Input Voltage	12.14 Max. AVI4
Factory Setting: 10.0	0.0 to 10.0V	Settings
 Unit: %	Scale Percentage	12.15 Max. AVI4
Factory Setting: 100.0	0.0 to 100.0%	Settings
 Unit: mA	Input Current	12.16 Min. ACI3 I
Factory Setting: 4.0	0.0 to 20.0mA	Settings
Unit: %	Scale Percentage	12.17 Min. ACI3 S
Factory Setting: 0.0	0.0 to 100.0%	Settings
Unit: mA	Input Current	12.18 Max. ACI3
Factory Setting: 20.0	0.0 to 20.0mA	Settings

12.19	Max. ACI3	Scale Percentage	Unit: %
	Settings	0.0 to 100.0%	Factory Setting: 100.0

12.20 AO1 Terminal Analog Signal Mode


Factory Setting: 0

Settings 0 AVO1

1 ACO1 (analog current 0.0 to 20.0mA)

2 ACO1 (analog current 4.0 to 20.0mA)

Besides parameter setting, the voltage/current mode should be used with the switch.



12.21 AO1 Analog Output Signal

Factory Setting: 0

Settings 0 Analog Frequency

1 Analog Current (0 to 250% rated current)

This parameter is used to choose analog frequency (0-+10Vdc) or analog current (4-20mA) to correspond to the AC motor drive's output frequency or current.

12.22 AO1 Analog Output Gain Unit: %

Settings 1 to 200% Factory Setting: 100

- This parameter is used to set the analog output voltage range.
- When Pr.12.21 is set to 0, analog output voltage corresponds to the AC motor drive's output frequency. When Pr.12.22 is set to 100, the max. output frequency (Pr.01.00) setting corresponds to the AFM output (+10VDC or 20mA)
- When Pr.12.21 is set to 1, analog output voltage corresponds to the AC motor drive's output current. When Pr.12.22 is set to 100, the 2.5 X rated current corresponds to the AFM output (+10VDC or 20mA)

NOTE

If the scale of the voltmeter is less than 10V, refer to following formula to set Pr.12.22:

Pr.12.22 = [(full scale voltage)/10]*100%.

Example: When using voltmeter with full scale (5V), Pr.12.22 should be set to 5/10*100%=50%. If

Pr.12.21 is set to 0, the output voltage will correspond to the max. output frequency.

12.23 AO2Terminal Analog Signal Mode


Factory Setting: 0

Settings 0 AVO2

1 ACO2 (analog current 0.0 to 20.0mA)

2 ACO2 (analog current 4.0 to 20.0mA)

Besides parameter setting, the voltage/current mode should be used with the switch.



12.24 AO2 Analog Output Signal

Factory Setting: 0

Settings 0 Analog Frequency

1 Analog Current (0 to 250% rated current)

12.25 AO2 Analog Output Gain

Unit: %

Settings 1 to 200%

Factory Setting: 100

Setting method for the AO2 is the same as the AO1.

12.26 AUI Analog Input Selection

Factory Setting: 0

Settings 0 No function

1 Source of the 1st frequency

2 Source of the 2nd frequency

12.27 AUI Analog Input Bias

Unit: %

Settings 0.00 to 200.00%

Factory Setting: 0.00

12.28	AUI Bias P	olarity		
				Factory Setting: 0
	Settings	0	Positive bias	
		1	Negative bias	
12.29	 ∕ AUI Ana	log Gaiı	n	Unit: %
	Settings	1 to	200%	Factory Setting: 100
12.30	AUI Negati	ve Bias	, Reverse Motion Enable/Disable	
				Factory Setting: 0
	Settings	0	No AUI Negative Bias Command	
		1	Negative Bias: REV Motion Enabled	
		2	Negative Bias: REV Motion Disabled	
12.31	AUI Analog	g Input I	Delay	Unit: 2ms
	Settings	0 to	9999	Factory Setting: 50

In a noisy environment, it is advantageous to use negative bias to provide a noise margin. It is recommended NOT to use less than 1V to set the operation frequency.

Pr.12-26 to Pr.12-31 can be used to set the frequency command by adjusting analog input voltage -10V to +10V. Refer to Pr.04-00 to 04-03 for details.

Group 13: PG function Parameters for Extension Card

Pulse generator card (PG card) is mainly applied in the detection components of speed control or position control. It usually makes a closed-loop speed control system with encoder. The AC motor drive is used with encoder and PG card to have a complete speed control and position detection system.

Please make sure that the extension card is installed on the AC motor drive correctly before using group 12 parameters. See Appendix B for details.

13.0	PG Input		
			Factory Setting: 0
	Settings	0	Disable PG
		1	Single phase
		2	Forward/Counterclockwise rotation
		3	Reverse/Clockwise rotation
	output, the enc output A and B of A and B puls motor rotation of PG card receiv AC motor drive Setting 0: disab	oder ou pulse s es as ti direction es A ar for spe ble PG t	
	Setting 2: both phase as show Setting 3: both phase as show	for spe n in the for spe n in the	ed control but can't distinguish motor rotation direction. ed control and distinguish motor rotation direction. A phase leads B e following diagram and motor is forward running. ed control and distinguish motor rotation direction. B phase leads A e following diagram and motor is reverse running. 1.13.01(PG Pulse Range)



When receiving a forward command, motor will rotate in counterclockwise direction (see from output side).



When receiving a reverse command, motor will rotate in clockwise direction (see from output side).



When encoder rotates in clockwise direction (see from input side). At this moment, A phase leads B phase.

13.01	PG Pulse R	ange	
	Settings	1 to 20000	Factory Setting: 600

- A Pulse Generator (PG) is used as a sensor that provides a feedback signal of the motor speed. This parameter defines the number of pulses for each cycle of the PG control.
- This parameter setting is the resolution of encoder. With the higher resolution, the speed control will be more precise.


13.02	Motor Pole	Number (Motor 0)	Unit: 1
	Settings	2 to 10	Factory Setting: 4

The pole number should be even (can't be odd).

13.03	⊮ Proportion	onal Gain (P)	Unit: 0.01
	Settings	0.0 to 10.0	Factory Setting: 1.0

- This parameter is used to set the gain (P) when using PG for the closed-loop speed control.
- The proportional gain is mainly used to eliminate the error. The large proportional gain(P) will get the faster response to decrease the error. Too large proportional gain will cause large overshoot and oscillation and decrease the stable.
- This parameter can be used to set the proportional gain (P) to decide the response speed. With large proportional gain, it will get faster response. Too large proportional gain may cause system oscillation. With small proportional gain, it will get slower response.

13.	.04 ✓ Integral Gain (I)	Unit: 0.01
	Settings 0.00 to 100.00 sec	Factory Setting: 1.00
	0.00 Disable	, , , , , , , , , , , , , , , , , , ,
	The integral controller is used to eliminate the error during sta doesn't stop working until error is 0. The integral is acted by the integral time is set, the stronger integral action will be. It is hell oscillation to make a stable system. At this moment, the decrease integral control is often used with other two controls to become	ne integral time. The smaller pful to reduce overshoot and easing error will be slow. The
	This parameter is used to set the integral time of I controller. Will have small gain of I controller, the slower response and basintegral time is short, it will have large gain of I controller, the fexternal control.	When the integral time is long, it ad external control. When the
	When the integral time is too small, it may cause system oscill When it is set to 0.0, the integral function is disabled.	lation.
13	.05 Speed Control Output Frequency Limit	Unit: Hz
	Settings 0.00 to 100.00Hz	Factory Setting: 10.00
	This parameter is used to limit the max. output frequency. From the following PG speed diagram, output frequency (H) = speed detection value via PG feedback. With the speed change change will be sent to drive via PG card to change the output can be used to decrease the speed change of motor load.	ge of motor load, the speed
13	.06 ✓ Speed Feedback Display Filter	Unit: 2ms
	Settings 0 to 9999 (*2ms)	Factory Setting: 500
	When Pr.0.04 is set to 14, its display will be updated regularly Pr.13.06.	. This update time is set by
	With the large setting in Pr.13.06, it can slow the response spedigital number on the digital keypad. Too large setting may can PG card.	
	Related parameter: Pr.00.04(Content of Multi-function Display	')
13	.09	Unit: 2ms
	Settings 0 to 9999 (*2ms)	Factory Setting: 16
	This parameter is the filter time from the speed feedback to th cause slow feedback response.	e PG card. Too large setting may



PG feedback speed control

13.0	7 ✓ Time for	Feedba	ack Signal Fault	Unit: second
	Settings	0.1 t	o 10.0 sec	Factory Setting: 1.0
		0.0	Disabled	
	warning (see F signal time. If this paramet	Pr.13.08 er is set) is given. It also can be	he PID feedback must be abnormal before a modified according to the system feedback d not detect any abnormality signal. Feedback Signal Fault)
13.0	№ Treatme	nt of the	Feedback Signal Fault	
				Factory Setting: 1
	Settings	0	Warn and RAMP to s	top
		1	Warn and COAST to	stop

- 2 Warn and keep operating

 AC motor drive action when the feedback signals (analog PID feedback or PG (encoder)
- feedback) are abnormal.

 Setting Pr.13.08 to 0: When the feedback signal fault occurs, it will display "PGEr" on the digital keypad and the stop to 0Hz by Pr.01.10/Pr.01.12 setting.
- Setting Pr.13.08 to 1: When the feedback signal fault occurs, it will display "PGEr" on the digital keypad and the motor will free run to stop.
- Setting Pr.13.08 to 2: When the feedback signal fault occurs, it will display "PGEr" on the digital keypad and the motor will keep running.
- It needs to press "RESET" to clear the warning message "PGEr" displayed on the keypad.



The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.

13.10	Source of the High-speed Counter (NOT for VFD*E*C models)						
				Factory Display: 0 (Read only)			
	Settings	0	PG card				
		1	PLC.				

This parameter reads the high-speed counter of the drive to use on PG card or PLC.

4.4 Different Parameters for VFD*E*C Models

The content of this instruction sheet may be revised without prior notice. Please consult our distributors or download the most updated version at http://www.delta.com.tw/industrialautomation

Software version for VFD*E*C is power board: V1.00 and control board: V2.00.

★: The parameter can be set during operation.

Group 0 User Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Parameter can be read/written		
		1: All parameters are read only		
00.00	Developed to Decet	6: Clear PLC program (NOT for VFD*E*C models)		
00.02	Parameter Reset	9: All parameters are reset to factory settings (50Hz, 230V/400V or 220V/380V depends on Pr.00.12)	0	
		10: All parameters are reset to factory settings (60Hz, 220V/440V)		
	Start-up Display Selection	0: Display the frequency command value (Fxxx)		
		1: Display the actual output frequency (Hxxx)		
₩ 00.03		2: Display the content of user-defined unit (Uxxx)	0	
		3: Multifunction display, see Pr.00.04		
		4: FWD/REV command		
		5: PLCx (PLC selections: PLC0/PLC1/PLC2) (NOT for VFD*E*C models)		
		0: Display the content of user-defined unit (Uxxx)		
		1: Display the counter value (c)		
₩ 00.04	Content of Multi-	2: Display PLC D1043 value (C) (NOT for VFD*E*C models)	0	
	function Display	3: Display DC-BUS voltage (u)		
		4: Display output voltage (E)		
		5: Display PID analog feedback signal value (b) (%)		

Parameter	Explanation	Settings	Factory Setting	Customer
		6: Output power factor angle (n)		
		7: Display output power (P)		
		8: Display the estimated value of torque as it relates to current (t)		
		9: Display AVI (I) (V)		
		10: Display ACI / AVI2 (i) (mA/V)		
		11: Display the temperature of IGBT (h) (°C)		
		12: Display AVI3/ACI2 level (I.)		
		13: Display AVI4/ACI3 level (i.)		
		14: Display PG speed in RPM (G)		
		15: Display motor number (M)		
		16: Display F*Pr.00.05		

Chapter 4 Parameters | Group 1 Basic Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
⊮ 01.09	Accel Time 1	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
⊮ 01.10	Decel Time 1	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
⊮ 01.11	Accel Time 2	0.1 to 600.0 / 0.01 to 600.0 sec	1.0	
⊮ 01.12	Decel Time 2	0.1 to 600.0 / 0.01 to 600.0 sec	1.0	

Group 2 Operation Method Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
№ 02.00	Source of First Master Frequency Command	O: Digital keypad UP/DOWN keys or Multifunction Inputs UP/DOWN. Last used frequency saved. 1: 0 to +10V from AVI 2: 4 to 20mA from ACI or 0 to +10V from AVI2 3: RS-485 (RJ-45)/USB communication 4: Digital keypad potentiometer 5: CANopen communication	5	
	Source of First	Digital keypad External terminals. Keypad STOP/RESET enabled. External terminals. Keypad STOP/RESET disabled.		
№ 02.01		 3: RS-485 (RJ-45)/USB communication. Keypad STOP/RESET enabled. 4: RS-485 (RJ-45)/USB communication. Keypad STOP/RESET disabled. 5: CANopen communication. Keypad STOP/RESET disabled. 	5	
№ 02.09	Source of Second Frequency Command	O: Digital keypad UP/DOWN keys or Multifunction Inputs UP/DOWN. Last used frequency saved. 1: 0 to +10V from AVI 2: 4 to 20mA from ACI or 0 to +10V from AVI2 3: RS-485 (RJ-45)/USB communication 4: Digital keypad potentiometer 5: CANopen communication	0	
02.16	Display the Master Freq Command Source	Read Only Bit0=1: by First Freq Source (Pr.02.00) Bit1=1: by Second Freq Source (Pr.02.09) Bit2=1: by Multi-input function Bit3=1: by PLC Freq command (NOT for VFD*E*C models)	##	

Parameter	Explanation	Settings	Factory Setting	Customer
02.17	Display the Operation Command Source	Read Only Bit0=1: by Digital Keypad Bit1=1: by RS485 communication Bit2=1: by External Terminal 2/3 wire mode Bit3=1: by Multi-input function Bit5=1: by CANopen communication	##	

Chapter 4 Parameters | Group 3 Output Function Parameters

Parameter	Explanation	Settings	Factory Setting Customer
03.09	Reserved		
03.10	Reserved		

Chapter 4 Parameters | Group 4 Input Function Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
04.05	Multi-function Input	0: No function	1	
	Terminal (MI3)	1: Multi-Step speed command 1		
		2: Multi-Step speed command 2		
04.06	Multi-function Input	3: Multi-Step speed command 3	2	
	Terminal (MI4)	4: Multi-Step speed command 4		
		5: External reset		
04.07	Multi-function Input	6: Accel/Decel inhibit	3	
	Terminal (MI5)	7: Accel/Decel time selection command		
		8: Jog Operation		
04.08	Multi-function Input	9: External base block	23	
	Terminal (MI6)	10: Up: Increment master frequency		
		11: Down: Decrement master frequency		
		12: Counter Trigger Signal		
		13: Counter reset		
		14: E.F. External Fault Input		
		15: PID function disabled		
		16: Output shutoff stop		
		17: Parameter lock enable		
		18: Operation command selection (external terminals)		
		19: Operation command selection(keypad)		
		20: Operation command selection (communication)		
		21: FWD/REV command		
		22: Source of second frequency command		
		23: Quick Stop (Only for VFD*E*C models)		
		24: Download/execute/monitor PLC Program (PLC2) (NOT for VFD*E*C models)		
		25: Simple position function		
		26: OOB (Out of Balance Detection)		

Parameter	Explanation	Settings	Factory Setting	Customer
		27: Motor selection (bit 0)		
		28: Motor selection (bit 1)		
04.24	Reserved			
04.25	Reserved			

Chapter 4 Parameters | Group 7 Motor Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
07.08	Torque Compensation Time Constant	0.01 ~10.00 Sec	0.30	
07.10	Accumulative Motor Operation Time (Min.)	00~1439	0	

Chapter 4 Parameters | Group 9 Communication Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
09.12~ 09.19	Reserved			
09.20	CANopen Communication Address	0: disable 1: 1 to 127	1	
09.21	CANbus Baud Rate	0: 1M 1: 500K 2: 250K 3: 125K 4: 100K 5: 50K	0	
09.22	Gain of CANbus Frequency	0.00~2.00	1.00	
09.23	CANbus Warning	bit 0 : CANopen Guarding Time out bit 1 : CANopen Heartbeat Time out bit 2 : CANopen SYNC Time out bit 3 : CANopen SDO Time out bit 4 : CANopen SDO buffer overflow bit 5 : CANbus Off bit 6 : Error protocol of CANopen	Read- only	
09.24	DS402 Protocol	0: Disable (By Delta rule) 1: Enable (By DS402)	1	
09.25	Detect SYNC signal	0:Ignore 1:Yes	0	
09.26	The operation state of CAN bus	Node reset Communication reset	0	
09.27	The operation state of CANopen	0: Not Ready For Use State 1: Inhibit Start State 2: Ready To Switch On State	0	

Chapter 4 Parameters | Group 11 Parameters for Extension Card

Parameter	Explanation	Settings	Factory Setting	Customer
		0: No function	0	
11.06	Multi-function Input Terminal (MI7)	1: Multi-Step speed command 1		
	,	2: Multi-Step speed command 2		
		3: Multi-Step speed command 3	0	
11.07	Multi-function Input Terminal (MI8)	4: Multi-Step speed command 4		
	, ,	5: External reset		
		6: Accel/Decel inhibit	0	
11.08	Multi-function Input Terminal (MI9)	7: Accel/Decel time selection command		
	,	8: Jog Operation		
		9: External base block	0	
11.09	Multi-function Input Terminal (MI10)	10: Up: Increment master frequency		
		11: Down: Decrement master frequency		
		12: Counter Trigger Signal	0	
11.10	Multi-function Input Terminal (MI11)	13: Counter reset		
11.10		14: E.F. External Fault Input		
		15: PID function disabled		
11.11	Multi-function Input	16: Output shutoff stop	0	
	Terminal (MI12)	17: Parameter lock enable		
		18: Operation command selection (external terminals)		
		19: Operation command selection (keypad)		
		20: Operation command selection (communication)		
		21: FWD/REV command		
		22: Source of second frequency command		
		23: Quick Stop (Only for VFD*E*C models)		
		24: Download/execute/monitor PLC Program (PLC2) (NOT for VFD*E*C models)		
		25: Simple position function		

Parameter	Explanation	Settings	Factory Setting	Customer
		26: OOB (Out of Balance Detection)		
		27: Motor selection (bit 0)		
		28: Motor selection (bit 1)		

Group 13: PG function Parameters for Extension Card

Parameter	Explanation	Settings	Factory Setting Customer
13.10	Reserved		

Appendix A: Specifications

There are 115V, 230V and 460V models in the VFD-E series. For 115V models, it is 1-phase models. For 0.25 to 3HP of the 230V models, there are 1-phase/3-phase models. Refer to following specifications for details.

	Voltage Class		115V Class				
	Model Number VFD-XXXE	002	004	007			
Max	. Applicable Motor Output (kW)	0.2	0.4	0.75			
Max	. Applicable Motor Output (hp)	0.25	0.5	1.0			
	Rated Output Capacity (kVA)	0.6	1.0	1.6			
atin	Rated Output Current (A)	1.6	2.5	4.2			
Output Rating	Maximum Output Voltage (V)	3-Phase Proportional to Twice the Input Voltage					
	Output Frequency (Hz)	0.1~600 Hz (Japanese version: 0.1 to 599 Hz)					
ō	Carrier Frequency (kHz)	1-15					
	Detect In most Comment (A)	Single-phase					
ting	Rated Input Current (A)	6	9	18			
Input Rating	Rated Voltage/Frequency	Sir	igle phase, 100-120V, 50/60)Hz			
ndu	Voltage Tolerance		<u>+</u> 10%(90~132 V)				
_	Frequency Tolerance						
Coc	bling Method	Natural Cooling		Fan Cooling			
Weight (kg)		1.2	1.2	1.2			

	Voltage Class	230V Class											
	Model Number VFD-XXXE	002	004	007	015	022	037	055	075	110	150		
Ma (kV	x. Applicable Motor Output V)	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15		
Ма	x. Applicable Motor Output (hp)	0.25	0.5	1.0	2.0	3.0	5.0	7.5	10	15	20		
ם	Rated Output Capacity (kVA)	0.6	1.0	1.6	2.9	4.2	6.5	9.5	12.5	17.1	25		
ating	Rated Output Current (A)	1.6	2.5	4.2	7.5	11.0	17	25	33	45	65		
utput Ra	Maximum Output Voltage (V)		3-Phase Proportional to Input Voltage										
utp	Output Frequency (Hz)		0.1~600 Hz (Japanese version: 0.1 to 599 Hz)										
0	Carrier Frequency (kHz)					1-	15						
'	Data d Janut Comment (A)		Single/3-phase 3-phase										
ing	Rated Input Current (A)	4.9/1.9	6.5/2.7	9.5/5.1	15.7/9	24/15	20.6	26	34	48	70		
ut Rating	Rated Voltage/Frequency	Single/3-phase 3-phase 200-240 V, 50/60Hz 200-240V, 50/6											
Input	Voltage Tolerance					<u>+</u> 10%	6(180~26	64 V)					
Frequency Tolerance						<u>+</u> 5%	6(47~63	Hz)					
Co	poling Method	Natural Cooling Fan Cooling											
Weight (kg)		1.1	1.1	1.1	1.9	1.9	1.9	3.5	3.5	3.57	6.6		

Voltage Class			460V Class									
Model Number VFD-XXXE			007	015	022	037	055	075	110	150	185	220
Max. A	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	
Max. Applicable Motor Output (hp)		0.5	1.0	2.0	3.0	5.0	7.5	10	15	20	25	30
	Rated Output Capacity (kVA)	1.2	2.0	3.3	4.4	6.8	9.9	13.7	18.3	24	29	34
Output Rating	Rated Output Current (A)	1.5	2.5	4.2	5.5	8.5	13	18	24	32	38	45
tput	Maximum Output Voltage (V)	3-Phase Proportional to Input Voltage										
nO	Output Frequency (Hz)			0.1~6	600 Hz	(Japane	ese ver	sion: 0.	1 to 599	Hz)		
	Carrier Frequency (kHz)		1-15									
						3	3-phase)				
ting	Rated Input Current (A)	1.9	3.2	4.3	7.1	11.2	14	19	26	35	41	49
Input Rating	Rated Voltage/Frequency	3-phase, 380-480V, 50/60Hz										
dul	Voltage Tolerance					<u>+</u> 109	%(342~	528V)				
	Frequency Tolerance					<u>+</u> 59	%(47~6	3Hz)				
Cooling Method		Natural Fan Cooling										
Weigh	nt (kg)	1.2	1.2	1.2	1.9	1.9	4.2	4.2	4.2	7.47	7.47	7.47

			General Specifications			
	Control Syste	em	SPWM(Sinusoidal Pulse Width Modulation) control (V/f or sensorless vector control)			
	Frequency S	etting Resolution	0.01Hz			
	Output Frequ	uency Resolution	0.01Hz			
	Torque Cha	racteristics	Including the auto-torque/auto-slip compensation; starting torque can be 150% at 3.0Hz			
	Overload Er	ndurance	150% of rated current for 1 minute			
S	Skip Frequency		Three zones, setting range 0.1-600Hz (Japanese version: 0.1 to 599 Hz)			
erist	Accel/Decel Time		0.1 to 600 seconds (2 Independent settings for Accel/Decel time)			
acte	Stall Prevention Level		Setting 20 to 250% of rated current			
Control Characteristics	DC Brake		Operation frequency 0.10-600.00Hz (Japanese version: 0.10 to 599.00 Hz), output 0-100% rated current Start time 0-60 seconds, stop time 0-60 seconds			
So	Regenerated	Brake Torque	Approx. 20% (up to 125% possible with optional brake resistor or externally mounted brake unit, 1-15hp (0.75-11kW) models have brake chopper built-in)			
	V/f Pattern		4-point adjustable V/f pattern			
	Speed contro	ol accuracy	+- 3% (VF), +-1% (SVC)			
	Speed contro	ol range	1:40 (VF and VF with PG), 1:100 (SVC) , 1:200 (SVC with PG)			
	Resolution		Analogue input: 10bit (0~5V correspond to 0~-1024) Analogue output: 10bit (0~-1024 correspond to 0~10V)			
ung	Erogueney	Keypad	Setting by			
Operating Characteri	Frequency Setting	External Signal	Potentiometer-5k Ω /0.5W, 0 to +10VDC, 4 to 20mA, RS-485 interface; Multifunction Inputs 3 to 9 (15 steps, Jog, up/down)			



	General Specifications						
	On anation	Keypad	Set by RUN and STOP				
	Operation Setting Signal	External Signal	2 wires/3 wires (MI1, MI2, MI3), JOG operation, RS-485 serial interface (MODBUS), programmable logic controller				
	Multi-functio	on Input Signal	Multi-step selection 0 to 15, Jog, accel/decel inhibit, 2 accel/decel switches, counter, external Base Block, ACI/AVI selections, driver reset, UP/DOWN key settings, NPN/PNP input selection				
	Multi-functio	on Output Indication	AC drive operating, frequency attained, zero speed, Base Block, fault indication, overheat alarm, emergency stop and status selections of input terminals				
	Analog Outp	out Signal	Output frequency/current				
	Alarm Out	put Contact	Contact will be On when drive malfunctions (1 Form C/change-over contact and 1 open collector output) for standard type)				
	Operation	n Functions	Built-in PLC(NOT for CANopen models), AVR, accel/decel S-Curve, overvoltage/over-current stall prevention, 5 fault records, reverse inhibition, momentary power loss restart, DC brake, auto torque/slip compensation, auto tuning, adjustable carrier frequency, output frequency limits, parameter lock/reset, vector control, PID control, external counter, MODBUS communication, abnormal reset, abnormal re-start, power-saving, fan control, sleep/wake frequency, 1st/2nd frequency source selections, 1st/2nd frequency source combination, NPN/PNP selection, parameters for motor 0 to motor 3, DEB and OOB (Out Of Balance Detection)(for washing machine)				
	Protection	n Functions	Over voltage, over current, under voltage, external fault, overload, ground fault, overheating, electronic thermal, IGBT short circuit, PTC, instantly stop and then reboot(up to 20 sec by setting parameter)				
	Display Key	pad (optional)	6-key, 7-segment LED with 4-digit, 5 status LEDs, master frequency, output frequency, output current, custom units, parameter values for setup and lock, faults, RUN, STOP, RESET, FWD/REV, PLC				
	Built-in Bra	ake Chopper	VFD002E11T/21T/23T, VFD004E11T/21T/23T/43T, VFD007E21T/23T/43T, VFD015E23T/43T, VFD007E11A/11C, VFD015E21A/21C, VFD022E21A/21C/23A/23C/43A/43C, VFD037E23A/23C/43A/43C, VFD055E23A/23C/43A/43C, VFD150E23A/23C/43A/43C, VFD110E23A/23C/43A/43C, VFD185E43A/43C, VFD185E43A/43C, VFD220E43A/43C				
	Built-in I	EMI Filter	For 230V 1-phase and 460V 3-phase models.				
	Enclosure F	Rating	IP20				
SL	Pollution De	egree	2				
nditio	Installation	Location	Altitude 1,000 m or lower, keep from corrosive gasses, liquid and dust				
Environmental Conditions	Ambient Te	emperature	-10°C to 50°C (40°C for side-by-side mounting) Non-Condensing and not frozen				
onmen	Storage/ Tr Temperatur	ansportation re	-20 °C to 60 °C				
nvira	Ambient Hu	umidity	Below 90% RH (non-condensing)				
<u>ш</u>	Vibration		10Hz≦f≦57Hz Fix Amplitude:0.075mm 57Hz≦f≦150Hz Fix Acceleration: 1G (According to IEC 60068-2-6)				
App	Approvals						

Appendix B: Accessories

B.1 All Brake Resistors & Brake Units Used in AC Motor Drives

Note: Please only use DELTA resistors and recommended values. Other resistors and values will void Delta's warranty. Please contact your nearest Delta representative for use of special resistors. The brake unit should be at least 10 cm away from AC motor drive to avoid possible interference. Refer to the "Brake unit Module User Manual" for further details.

				110V Se	ries						
Applicable			125% Braking Torque 10%ED*						Max. Brake Torque**		
Motor HP [kW]	Ac Drive Part No.	Full Load Torque KG-M***	Brake Unit [VFDB]	Resistor or Value spec. for each Ac motor Drive	Braking Resistor series for each Brake Unit ****	total Braking current (A)	Min. resistor value (Ω)	Max.Total Braking current (A)	Peak Power (kW)		
0.25 [0.2]	VFD002E11A VFD002E11C VFD002E11P	0.14	20015*1	80W 200Ω	BR080W200*1	1.9	105.6	3.6	1.4		
	VFD002E11T VFD004E11A								\vdash		
0.5 [0.4]	VFD004E11A VFD004E11C VFD004E11P	0.27	20015*1	80W 200Ω	BR080W200*1	1.9	105.6	3.6	1.4		
	VFD004E11T										
1 [0.75]	VFD007E11A VFD007E11C VFD007E11P	0.51		80W 200Ω	BR080W200*1	1.9	105.6	3.6	1.4		


				230V Se					
Applicable				125% Braking Torq	ue 10%ED*			Brake Torqu	re**
Motor HP [kW]	Ac Drive Part No.	Full Load Torque KG-M***	Brake Unit [VFDB]	Resistor or Value spec. for each Ac motor Drive	Braking Resistor se for each Brake Unit		Min. resistor value (Ω)	Max.Total Braking current (A)	Peak Power (kW)
0.25 [0.2]	VFD002E21A VFD002E21C VFD002E21P VFD002E23A VFD002E23C VFD002E23P	0.14	20015*1	80W 200Ω	BR080W200*1	1.9	105.6	3.6	1.4
	VFD002E21T VFD002E23T								
0.5 [0.4]	VFD004E21A VFD004E21C VFD004E21P VFD004E23A VFD004E23C VFD004E23P	0.27	20015*1	80W 200Ω	BR080W200*1	1.9	105.6	3.6	1.4
	VFD004E21T VFD004E23T								
1 [0.75]	VFD007E21A VFD007E21C VFD007E21P VFD007E23A VFD007E23C VFD007E23P	0.51	20015*1	80W 200Ω	BR080W200*1	1.9	105.6	3.6	1.4
	VFD007E21T VFD007E23T								
2	VFD015E21A VFD015E21C VFD015E21P	1.02		300W110Ω	BR300W110	3.5	105.6	3.6	1.4
[1.5]	VFD015E23A VFD015E23C VFD015E23P	1.02	20015*1	30000 11002	BR300W110	3.5	105.6	3.6	1.4
3 [2.2]	VFD022E21A VFD022E21C VFD022E23A VFD022E23C	1.49		300W110Ω	BR300W110	3.5	105.6	3.6	1.4
5 [3.7]	VFD037E23A VFD037E23C	2.50		600W50Ω	BR300W025*2 2 se	eries 7.6	47.5	8	3.0


	230V Series								
Applicable				125% Braking Torq	ue 10%ED*		Max. Brake Torque**		
Motor HP [kW]		Full Load Torque KG-M***	Brake Unit [VFDB]	Resistor or Value spec. for each Ac motor Drive	Braking Resistor serie for each Brake Unit **	total Braking current (A)	Min. resistor value (Ω)	Max.Total Braking current (A)	Peak Power (kW)
7.5 [5.5]	VFD055E23A VFD055E23C	3.72		750W33Ω	BR750W033*1	15.2	25.3	15	5.7
10 [7.5]	VFD075E23A VFD075E23C	5.08		1000W20Ω	BR1K0W020*1	20.7	16.5	23	8.7
15 [11]	VFD110E23A VFD110E23C	7.45		1500W13Ω	BR1K5W013*1	30.3	11.5	33	12.5
20 [15]	VFD150E23A VFD150E23C	10.16		2000W10Ω	BR1K0W020*2 2 paral	el 41.5	7.6	50	19.0

	460V Series									
Applicable		125% Braking Torque 10%ED*							Brake Torqu	ıe**
Motor HP [kW]	Ac Drive Part No.	Full Load Torque KG-M***	Brake Unit [VFDB]	Resistor or Value spec. for each Ac motor Drive	Braking Resist for each Brake		total Braking current (A)	Min. resistor value (Ω)	Max.Total Braking current (A)	Peak Power (kW)
0.5 [0.4]	VFD004E43A VFD004E43C VFD004E43P VFD004E43T	0.27	40015*1	80W750Ω	BR080W7	50*1	1.1	422.2	1.8	1.4
1 [0.75]	VFD007E43A VFD007E43C VFD007E43P	0.51	40015*1	80W750Ω	BR080W7	50*1	1.1	422.2 126.7	1.8	1.4
2 [1.5]	VFD007E43T VFD015E43A VFD015E43C VFD015E43P	1.02	40037*1	200W360Ω	BR200W	360	2.2	95.0	8	6.1
3	VFD015E43T VFD022E43A							126.7	6	4.6
[2.2]	VFD022E43A	1.49		300W250Ω	BR300W250 3.		3.2	84.4	9	6.8
5 [3.7]	VFD037E43A VFD037E43C	2.50		600W140Ω	BR300W070*2	2 series	5.4	84.4	9	6.8
7.5 [5.5]	VFD055E43A VFD055E43C	3.72		1000W75Ω	BR1K0W0	75*1	10.4	63.3	12	9.1
10 [7.5]	VFD075E43A VFD075E43C	5.08		1000W75Ω	BR1K0W0	75*1	10.4	42.2	18	13.7
15 [11]	VFD110E43A VFD110E43C	7.45		1500W43Ω	BR1K5W043*1 1		17.7	42.2	18	13.7
20 [15]	VFD150E43A VFD150E43C	10.16		2000W40Ω	BR1K0W020*2	2 series	20.7	21.1	36	27.4
25 [18.5]	VFD185E43A VFD185E43C	12.52		2400W30Ω	BR1K2W015*2	2 series	25.5	17.7	43	32.7
30 [22]	VFD220E43A VFD220E43C	14.89		3000W26Ω	BR1K5W013*2	2 series	25.5	17.7	43	32.7

NOTE

* Calculation for 125% brake toque: (kw)*125%*0.8; where 0.8 is motor efficiency. Because there is a resistor limit of power consumption, the longest operation time for 10%ED is 10sec (on: 10sec/ off: 90sec).






Thermal Relay:


Thermal relay selection is basing on its overload capability. A standard braking capacity for VFD-E is 10%ED (Tripping time=10s). The figure below is an example of 460V, 22kw AC motor drive. It requires the thermal relay to take 260% overload capacity in 10s (Host starting) and the braking current is 30.3A. In this case, user should select a rated 12A thermal relay. The property of each thermal relay may vary among different manufacturer, please carefully read specification.

- ***The calculation of the barking torque is based on 4-pole (1800 rpm) motor.
- ****For heat dissipation, a resistor of 400W or lower should be fixed to the frame and maintain the surface temperature below 250°C (400°C); a resistor of 1000W and above should maintain the surface temperature below 600°C.
- 1. If damage to the drive or other equipment is due to the fact that the brake resistors and the brake modules in use are not provided by Delta, the warranty will be void.
- 2. Take into consideration the safety of the environment when installing the brake resistors.
- 3. Definition for Brake Usage ED%

Explanation: The definition of the barking usage ED(%) is for assurance of enough time for the brake unit and brake resistor to dissipate away heat generated by braking. When the brake resistor heats up, the resistance would increase with temperature, and brake torque would decrease accordingly. Suggested cycle time is one minute



- 4. Please select the brake unit and/or brake resistor according to the table. "-" means no Delta product. Please use the brake unit according to the Equivalent Resistor Value.
- 5. For safety reasons, install a thermal overload relay between brake unit and brake resistor. Together with the magnetic contactor (MC) in the mains supply circuit to the drive it offers protection in case of any malfunctioning. The purpose of installing the thermal overload relay is to protect the brake resistor against damage due to frequent brake or in case the brake unit is continuously on due to unusual high input voltage. Under these circumstances the thermal overload relay switches off the power to the drive. Never let the thermal overload relay switch off only the brake resistor as this will cause serious damage to the AC Motor Drive.




Note1: When using the AC drive with DC reactor, please refer to wiring diagram in the AC drive user manual for the wiring of terminal +(P) of Brake unit.

Note2: **Do NOT** wire terminal -(N) to the neutral point of power system.

B.1.1 Dimensions and Weights for Brake Resistors

Brake Resistors


Model no.	Dimension (mm)						
Model 110.	L1±2	L2±2	W±0.5	H±0.5			
BR080WXXX	140	125	40	20			
BR1K0WXXX							
BR1K1WXXX	P1						
BR1K2WXXX							
BR1K5WXXX							
BR200W360	165	150	60	30			
BR300WXXX	215	200	60	30			
BR750W033		Р	22				





B.1.2 Specifications for Brake Unit


·	Voltage level	115/230	V Series	460V Series			
Model Name BUE-XXXXX		20015	20037	40015	40037		
Ma	x. Motor Power (kW)	1.5	3.7	1.5	3.7		
Output	Max. Peak Discharge Current (A) 10%ED	3.6	16	1.8	8		
Rating	Brake Start-up Voltage (DC)	328/345/362	/380/400±3V	656/690/725/760/800±6V			
Power	DC Voltage	200~40	200~400VDC		00VDC		
Protection	Heat Sink Overheat	Temperature over +100°C (212°F)					
Protection	Power Charge Display	Blackout until bus (P~N) voltage is below 50VDC					
	Installation Location		Indoor (no corrosive gases, metallic dust)				
	Operating Temperature		-10°C ~ +50°C (14°F to 122°F)				
Environment Storage Temperature		-20°C ~ +60°C (-4°F to 140°F)					
Humidity		90% Non-condensing					
Vibration		9.8m/s ² (1G) under 20Hz, 2m/s ² (0.2G) at 20~50Hz					
Wall-r	mounted Enclosed Type	IP20					

B.1.3 Dimensions for Brake Unit










B.1.4 DIN Rail Installation



B.2 No-fuse Circuit Breaker Chart

For 1-phase/3-phase drives, the current rating of the breaker shall be within 2-4 times rated input current.

Model	Pagammandad na fuga bracker (A)	Fuse Specification			
Model	Recommended no-fuse breaker (A)	Max. I (A)	Min. I (A)		
VFD002E11A		15	15		
VFD004E11A		20	20		
VFD007E11A	7	30	30		
VFD002E21A		10	10		
VFD004E21A		15	15		
VFD007E21A		20	20		
VFD015E21A		30	30		
VFD022E21A	1	50	50		
VFD002E23A		6	6		
VFD004E23A]	6	10		
VFD007E23A		10	15		
VFD015E23A		20	25		
VFD022E23A	1	30	35		
VFD037E23A	1.6.2.6 times of the reted input ourrent	40	50		
VFD055E23A	1.6~2.6 times of the rated input current	50	60		
VFD075E23A		60	80		
VFD110E23A]	100	125		
VFD150E23A]	150	180		
VFD004E43A	1	6	6		
VFD007E43A		6	10		
VFD015E43A]	10	15		
VFD022E43A		15	20		
VFD037E43A		20	30		
VFD055E43A		30	40		
VFD075E43A		40	50		
VFD110E43A		50	60		
VFD150E43A		70	90		
VFD185E43A]	80	100		
VFD220E43A] [100	125		

B.3 AC Reactor

B.3.1 AC Input & Output Reactor Recommended Value

115V, 50/60Hz,

Model	kW [HP]	Rated Amps	Fundamental Amps	3% impedance (mH)	5% impedance (mH)	3% input reactor Delta Part. No.
002	0.2 [0.25]	1.6	2.4	0.686	1.1439	N/A
004	0.4 [0.5]	2.5	3.75	0.439	0.7321	N/A
007	0.75 [1]	4.2	6.3	0.261	0.4358	N/A

200~230V, 50/60Hz,

Model	kW [HP]	_	ted ips	Funda Am	mental nps		edance IH)	-	edance H)	3% input re Delta Part	
	[i ii]	3-phase	1-phase	3-phase	1-phase	3-phase	1-phase	3-phase	1-phase	3-phase	1-phase
002	0.2 [0.25]	1.9	4.9	2.85	7.35	5.562	3.735	9.269	6.225	N/A	N/A
004	0.4 [0.5]	2.7	6.5	4.05	10.4	3.913	2.816	6.523	4.693	N/A	N/A
007	0.75 [1]	5.1	9.7	7.65	15.52	2.113	1.887	3.522	3.145	N/A	N/A
015	1.5 [2]	9	15.7	13.5	25.12	1.321	1.166	2.201	1.943	N/A	N/A
022	2.2 [3]	15	24	22.5	38.4	0.704	0.763	1.174	1.271	N/A	N/A
037	3.7 [5]	20.6	ı	30.9	ı	0.622	ı	1.036	ı	N/A	-
055	5.5 [7.5]	26	ı	39	ı	0.423	ı	0.704	ı	N/A	-
075	7.5 [10]	34	-	51	-	0.320	-	0.534	-	DR033AP320	-
110	11 [15]	48	-	72	-	0.216	-	0.359	-	DR049AP215	-
150	15 [20]	70	-	105	-	0.163	-	0.271	-	DR065AP162	-

380~460V, 50/60Hz,

Model	kW [HP]	Rated Amps	Fundamental Amps	3% impedance (mH)	5% impedance (mH)	3% input reactor Delta Part. No.
004	0.4 [0.5]	1.5	2.3	14.090	23.483	N/A
007	0.75 [1]	2.5	3.8	7.045	11.741	N/A
015	1.5 [2]	4.2	6.3	5.284	8.806	N/A
022	2.2 [3]	5.5	8.3	3.522	5.871	N/A
037	3.7 [5]	8.5	12.8	2.348	3.914	N/A
055	5.5 [7.5]	13	19.5	1.761	2.935	N/A
075	7.5 [10]	18	27	1.174	1.957	DR018A0117
110	11 [15]	24	36	0.881	1.468	DR024AP880
150	15 [20]	32	48	0.660	1.101	DR032AP660
185	18.5 [25]	38	57	0.556	0.927	N/A
220	22 [30]	45	67.5	0.470	0.783	N/A


Note:

AC motor Drive Spec.	No built-in DC reactor		
Reactors in series specifications	3% input reactor	5% input reactor	
THD	44%	35%	
Warning	conditions (e.g.: cables, motors). 2. Use the output AC reactor can prote length. 3. The specification of output and inpu	ces because of the different installation ect the motor and extend the cable usage of t reactors are the same, Delta's part refer to the table above for purchasing.	

Applications

Connected in input circuit


Application 1	Question
When more than one AC motor drive is connected to the same mains power and one of them is ON during operation.	When applying power to one of the AC motor drive, the charge current of the capacitors may cause voltage dip. The AC motor drive may be damaged when over current occurs during operation.




Application 2	Question
Silicon rectifier and AC motor drive are connected to the same power.	Switching spikes will be generated when the silicon rectifier switches on/off. These spikes may damage the mains circuit.

Correct wiring

Silicon Controlled Rectifier





Application 3	Question
Used to improve the input power factor, to	When the mains power capacity is too large,
reduce harmonics and provide protection from	line impedance will be small and the charge
AC line disturbances₌ (surges, switching	current will be too high. This may damage AC
spikes, short interruptions, etc.). The AC line	motor drive due to higher rectifier
reactor should be installed when the power	temperature.
supply capacity is 500kVA or more and	
exceeds 6 times the inverter capacity, or the	
mains wiring distance \leq 10m.	




B.3.2 Zero Phase Reactor (RF220X00A)

Dimensions are in millimeter and (inch)








Cable type	Recommended Wire Size (mm²)			Qty.	Wiring
(Note)	AWG	mm ²	Nominal (mm²)	Qiy.	Method
Single-	≤10	≤5.3	≤5.5	1	Diagram A
core	≤2	≤33.6	≤38	4	Diagram B
Three-	≤12	≤3.3	≤3.5	1	Diagram A
Core	≤1	≤42.4	≤50	4	Diagram B

Diagram A


Please wind each wire 4 times around the core. The reactor must be put at inverter output as close as possible.



Note: 600V Insulated unshielded Cable.


- The table above gives approximate wire size for Please put all wires through 4 cores in series without the zero phase reactors but the selection is winding. ultimately governed by the type and diameter of cable fitted i.e. the cable must fit through the center hole of zero phase reactors.
- Only the phase conductors should pass through, not the earth core or screen.
- When long motor output cables are used an output zero phase reactor may be required to reduce radiated emissions from the cable.

Diagram B



B.4 Remote Controller RC-01

Dimensions are in millimeter



VFD-E Programming:

Pr.02.00 set to 2

Pr.02.01 set to 1 (external controls)


Pr.04.04 set to 1 (setting Run/Stop and Fwd/Rev controls)

Pr.04.07 (MI5) set to 5 (External reset)

Pr.04.08 (MI6) set to 8 (JOG operation)

B.5 PU06

B.5.1 Description of the Digital Keypad VFD-PU06



Note:

- 1) CANopen models are not compatible with PU06 keypad.
- 2) After completing copying parameters by using a PU06 keypad, a KPC-CC01 keypad or a PC software, do not operating the motor drive right away. Wait for 5 seconds before operating motor drive.


B.5.2 Explanation of Display Message

Display Message	Descriptions
F 80.00	The AC motor drive Master Frequency Command.
H 5000	The Actual Operation Frequency present at terminals U, V, and W.
u 18000	The custom unit (u)
8 5.8	The output current present at terminals U, V, and W.
-E848	Press to change the mode to READ. Press PROG/DATA for about 2 sec or until it's flashing, read the parameters of AC drive to the digital keypad PU06. It can read 2 groups of parameters to PU06. (read 0 – read 1)
5808-	Press to change the mode to SAVE. Press PROG/DATA for about 2 sec or until it's flashing, then write the parameters from the digital keypad PU06 to AC drive. If it has saved, it will show the type of AC motor drive.
88-88	The specified parameter setting.
	The actual value stored in the specified parameter.


Display Message	Descriptions
E.F.	External Fault
-End-	"End" displays for approximately 1 second if the entered input data have been accepted. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the or keys.
-6	"Err" displays if the input is invalid.
81-33	Communication Error. Please check the AC motor drive user manual (Chapter 5, Group 9 Communication Parameter) for more details.


B.5.3 Operation Flow Chart

VFD-PU06 Operation Flow Chart



B.5.4 PU06 Dimensions







Do NOT copy the setting of the parameters below when copying parameters by using a PU06 keypad, a KPC-CC01 keypad or PC software.

GROUP 0	
	_
00.00	Identity Code of the AC motor drive
00.01	Rated Current Display of the AC motor drive
00.02	Parameter Reset
00.06	Power Board Software Version
00.07	Control Board Software Version
GROUP 2	
02.16	Display the Master Freq Command Source
02.17	Display the Operation Command Source
GROUP 3	
03.09	The Digital Output Used by PLC
03.10	The Analog Output Used by PLC
03.13	Display the Status of Multi-function Output Terminals
GROUP 4	
04.24	The Digital Input Used by PLC
04.25	The Analog Input Used by PLC
04.26	Display the Status of Multi-function Input Terminal
GROUP 6	
06.08	Present Fault Record
06.09	Second Most Recent Fault Record
06.10	Third Most Recent Fault Record
06.11	Fourth Most Recent Fault Record
06.12	Fifth Most Recent Fault Record
GROUP 7	
07.10	Accumulative Motor Operation Time (Min.)
07.11	Accumulative Motor Operation Time (Day)
GROUP 8	
08.23	OOB Average Sampling Angle
GROUP 1	
13.10	Source of the High-speed Counter

B.6 KPE-LE02

B.6.1 Description of the Digital Keypad KPE-LE02



Status Display

Display the driver's current status.

2 LED Display

Indicates frequency, voltage, current, user defined units and etc.

O Potentiometer

For master Frequency setting.

4 RUN Key

Start AC drive operation.

6 UP and DOWN Key

Set the parameter number and changes the numerical data, such as Master Frequency.

6 MODE

Change between different display mode.

7 STOP/RESET

Stops AC drive operation and reset the drive after fault occurred.

® ENTER

Used to enter/modify programming parameters


Display Message	Descriptions
RUN- FWD- REV-	Displays the AC drive Master Frequency.
RUN- FWD- REV-	Displays the actual output frequency at terminals U/T1, V/T2, and W/T3.
RUN• FWD• REV•	User defined unit (where U = F x Pr.00.05)
RUN- FWD- REV-	Displays the output current at terminals U/T1, V/T2, and W/T3.
RUN• FWD• REV•	Displays the AC motor drive forward run status.
RUN• FWD• REV•	Displays the AC motor drive reverse run status.
RUN• FWD• REV•	The counter value (C).
RUN STOP	Displays the selected parameter.
RUN• FWD• REV•	Displays the actual stored value of the selected parameter.
RUN• FWD• REV•	External Fault.
RUNO STOP STOP REVO	Display "End" for approximately 1 second if input has been accepted by pressing ENTER key. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the and keys.
RUN• FWD• REV•	Display "Err", if the input is invalid.

Note:

When the setting exceeds 99.99 for those numbers with 2 decimals (i.e. unit is 0.01), it will only display 1 decimal due to 4-digital display.


B.6.2 Keypad Dimensions

(Dimensions are in millimeter [inch])




B.6.3 Digital Keypad Installation

Method1. Install directly (Unit: mm [inch])




Method2. Install according to plank thickness (Unit: mm [inch])

A. Plank thickness=1.2mm[0.05 inches]



B. Plank thickness =2.0mm[0.08 inches]



B.6.4 How to Operate the Digital Keypad



enter PLC1 mode

B.6.5 Reference Table for the 7-segment LED Display of the Digital Keypad

Digit	0	1	2	3	4	5	6	7	8	9
LED Display	O	-	2	3	.r	5	8		8	9
English alphabet	Α	а	В	С	С	D	d	E	е	F
LED Display	Ā	-	-	اا	C	-	70	ררי	-	7
English alphabet	f	G	g	Н	h	I	i	J	j	K
LED Display	-	נט	ı	X	7		ا_ ا)	۱ ٦	1
English alphabet	k	L	Ι	М	m	N	n	0	0	Р
LED Display	-	1	ı	וב:	-	ı	c	כבו	0	9
English alphabet	р	Q	q	R	r	S	S	Т	t	U
LED Display	-	1	Q*	-	•	5	-		Ţ	:]
English alphabet	u	V	V	W	W	Х	х	Y	у	Z
LED Display	-	-	נ	-	-	-	-	3	-	111
English alphabet	z									
LED Display	-									


B.7 Extension Card

For details, please refer to the separate instruction shipped with these optional cards or download from our website http://www.delta.com.tw/industrialautomation/.

Installation method:




B.7.1 Relay Card



- Screw torque of terminal: 5kgf-cm (max.)
- Wire gauge: 12~24 AWG
- If the extension card is installed on the AC motor drive, AC motor drive will detect the extension card automatically, and it can also use the parameter Group 11 for setting. In case there is no extension card installation, the parameters only have Group 0 ~ Group 10 for setting. Please refer to manual CH.5 for detail parameter settings.
- Environment (Please use this product indoor with no dust, corrosive gas and liquid .)

Operation Temperature	-10°C to 50°C (Non-condensation, on-frozen)
Storage Temperature	-20°C to +60°C
Rated Humidity	Under 90%RH (Non-condensation)
Maximum Altitude	Lower than 1000m
Vibration	10Hz≦f≦57Hz Fix Amplitude:0.075mm 57Hz≦f≦150Hz Fix Acceleration: 1G (According to IEC 60068-2-6)

Dimensions: Unit: mm [inch]




■ Input / Output

EME-R2CA (Each contact can withstand voltage / current)

Resistive Load	C-A (N.O.): 5A 250VAC/30VDC C-B (N.C.): 3A 250VAC/30VDC
Inductive Load	C-A (N.O.): 1.5A 250VAC/30VDC C-B (N.C.): 0.5A 250VAC/30VDC

Warning:

- To connect the inductive load (relay, electromagnetic contactors, motor ... etc.), please install RC network or Varistor beside the coil.
- Please install fuse (the spec can't greater than contact limits) in the loops for safety concern.
- Please use isolated cable to prevent the interface as far as possible.
- Please have soldering or terminal for cable.
- Based on the safety considerations, please keep more than 15cm with other control, motor and power cables and wiring independently; please keep the vertical wiring if it is necessary for cable staggering.
- All operations can NOT exceed the limitation of spec.



- Screw torque of terminal: 5kgf-cm (max.)
- Wire gauge: 12~24 AWG
- If the extension card is installed on the AC motor drive, AC motor drive will detect the extension card automatically, and it can also use the parameter Group 11 for setting. In case there is no extension card installation, the parameters only have Group 0 ~ Group 10 for setting. Please refer to manual CH.5 for detail parameter settings.
- Environment (Please use this product indoor with no dust, corrosive gas and liquid .)

Operation	-10°C to 50°C (Non-condensation, on-frozen)
Temperature	- 10 C to 50 C (Non-condensation, on-nozem)

_		
	Storage Temperature	-20°C to +60°C
Rated Humidity Under 90%RH (N		Under 90%RH (Non-condensation)
	Maximum Altitude	Lower than 1000m
	Vibration	10Hz≦f≦57Hz Fix Amplitude:0.075mm 57Hz≦f≦150Hz Fix Acceleration: 1G (According to IEC 60068-2-6)

■ Input / Output


EME-R3AA (Each contact can withstand voltage / current)

Resistive Load	6A 250VAC/30VDC
Inductive Load	2A 250VAC/30VDC


Warning:

- To connect the inductive load (relay, electromagnetic contactors, motor ... etc.), please install RC network or Varistor beside the coil.
- Please install fuse (the spec can't greater than contact limits) in the loops for safety concern.
- Please use isolated cable to prevent the interface as far as possible.
- Please have soldering or terminal for cable.
- Based on the safety considerations, please keep more than 15cm with other control, motor and power cables and wiring independently; please keep the vertical wiring if it is necessary for cable staggering.
- All operations can NOT exceed the limitation of spec.

Dimensions: Unit: mm [inch]



B.7.2 Digital I/O Card



- Screw torque of terminal: 2kgf-cm (max.)
- Wire gauge: 16~24 AWG
- If the extension card is installed on the AC motor drive, AC motor drive will detect the extension card automatically, and it can also use the parameter Group 11 for setting. In case there is no extension card installation, the parameters only have Group 0 ~ Group 10 for setting. Please refer to manual CH.5 for detail parameter settings.
- Environment (Please use this product indoor with no dust, corrosive gas and liquid.)

	, ,
Operation Temperature	-10°C to 50°C (Non-condensation, on-frozen)
Storage Temperature	-20°C to +60°C
Rated Humidity	Under 90%RH (Non-condensation)
Maximum Altitude	Lower than 1000m
Vibration	10Hz≦f≦57Hz Fix Amplitude:0.075mm 57Hz≦f≦150Hz Fix Acceleration: 1G (According to IEC 60068-2-6)


■ Input / Output EME-D33A

MI7~MI9	ON: Operating current: Min.: 4mA, Max.: 16mA OFF: Allowable leakage current:10µA
MO2~MO4	Withstand voltage / current: 48VDC, 50mA


Warning:

- To connect the inductive load (relay, electromagnetic contactors, motor ... etc.), please install RC network or Varistor beside the coil.
- Please install fuse (the spec can't greater than contact limits) in the loops for safety concern.
- Please use isolated cable to prevent the interface as far as possible.
- Please have soldering or terminal for cable.
- Based on the safety considerations, please keep more than 15cm with other control, motor and power cables and wiring independently; please keep the vertical wiring if it is necessary for cable staggering.
- All operations can NOT exceed the limitation of spec.

Dimensions: Unit: mm [inch]



B.7.3 Analog I/O Card



- Screw torque of terminal: 5kgf-cm (max.)
- Wire gauge: 14~24 AWG(2.1 ~ 0.2 mm²)
- If the extension card is installed on the AC motor drive, AC motor drive will detect the extension card automatically, and it can also use the parameter Group 12 for setting. In case there is no extension card installation, the parameters only have Group 0 ~ Group 10 for setting. Please refer to manual CH.5 for detail parameter settings.
- Environment (Please use this product indoor with no dust, corrosive gas and liquid .)

	Operation Temperature	-10°C to 50°C (Non-condensation, on-frozen)			
Storage -20°C to +		-20°C to +60°C			
	Rated Humidity	Under 90%RH (Non-condensation)			
	Maximum Altitude	Lower than 1000m			
		10Hz≦f≦57Hz Fix Amplitude:0.075mm			
	Vibration	57Hz≦f≦150Hz Fix Acceleration: 1G			
		(According to IEC 60068-2-6)			


■ Input / Output EME-A22A


Terminal	Description			
Al1 Al2	Input voltage range : 0 ~ 10VDC =0 ~ Max. output frequency(Pr.01.00) Input impedance : $100K\Omega$ Resolution : 12 bits Input current range : DC 0 ~ $20mA=0$ ~ Max. output frequency (Pr.01.00) Input impedance : 250Ω Resolution : 12 bits			
AO1 AO2	Input voltage range : DC 0 ~ 10V Input impedance : 1K ~ 2M Ω Resolution : 12 bits Input current range : DC 0 ~ 20mA Input impedance : 0 ~ 500 Ω Resolution : 12 bits			
ACM	Analog control signal common terminal			

Warning:

- To connect the inductive load (relay, electromagnetic contactors, motor ... etc.), please install RC network or Varistor beside the coil.
- Please install fuse (the spec can't greater than contact limits) in the loops for safety concern.
- Please use isolated cable to prevent the interface as far as possible.
- Please have soldering or terminal for cable.
- Based on the safety considerations, please keep more than 15cm with other control, motor and power cables and wiring independently; please keep the vertical wiring if it is necessary for cable staggering.
- All operations can NOT exceed the limitation of spec.

Dimensions: Unit: mm [inch]






■ Screw torque of terminal: 2kgf-cm (max.)


■ Wire gauge: 16 ~ 24 AWG


Terminal	Terminal Function	Function Description		
AUI	Analog voltage frequency command	Input voltage range : -10~+10V Input impedance : 100KΩ Resolution : 12 bits		
DCM	Digital control signal common terminal	Common for digital inputs and used for NPN mode		
-10V	Power for speed setting	Power for Analog frequency setting -10VDC , 10mA		
MO2	Multi-function output terminal 2 (optical coupling)	Reference Parameters :Pr.11.00		
МО3	Multi-function output terminal 3 (optical coupling)	M∘2 ~M○4-MCM Ma x: 48Vdc/50mA		
MO4	Multi-function output terminal 4 (optical coupling)	MO2 MO4 MO4		
МСМ	Multi-function output common terminal (optical coupling)	The common side of multi-function output terminal		


Dimensions: Unit: mm [inch.]



B.7.4 Multi-function Input Terminal MI1~MI6-COM Card









■ Screw torque of terminal: 2kgf-cm (max.)


■ Wire gauge: 16 ~ 24 AWG



B.7.5 Communication Card




B.7.6 Speed Feedback Card



■ Screw torque of terminal: 2kgf-cm (max.)

■ Wire gauge: 16 ~ 24 AWG

Dimensions: Unit: mm [inch.]




B.8 Fieldbus Modules

B.8.1 DeviceNet Communication Module (CME-DN01)



B.8.1.1 Panel Appearance and Dimensions





- 1. For RS-485 connection to VFD-E
- 2. Communication port for connecting DeviceNet network
- 3. Address selector
- 4. Baud rate selector
- 5. Three LED status indicators for monitor

Unit: mm[inch.]

B.8.1.2 Wiring and Settings

Refer to following diagram for details.






- 1: Reserved
- 2. EV
- 3. GND
- 4. SG-
- 5. SG+
- 6. Reserved
- 7. Reserved
- 8. Reserved

Setting baud rate


125K 250K 500K	Switch Value	0	1	2	Other
BAUD	Baud Rate	125K	250K	500K	Auto

Setting MAC addresses: use decimal system.



B.8.1.3 Mounting Method

Step1 and step2 show how to mount this communication module onto VFD-E. The dimension on the left hand side is for your reference.



B.8.1.4 Power Supply

No external power is needed. Power is supplied via RS-485 port that is connected to VFD-E. An 8 pins RJ-45 cable, which is packed together with this communication module, is used to connect the RS-485 port between VFD-E and this communication module for power. This communication module will perform the function once it is connected. Refer to the following paragraph for LED indications.

B.8.1.5 LEDs Display

- 1. SP: Green LED means in normal condition, Red LED means abnormal condition.
- 2. MS (Module): Green blinking LED means no I/O data transmission, Green steady LED means I/O data transmission OK. Red LED blinking or steady LED means module communication is abnormal.
- 3. Ns (Network): Green LED means DeviceNet communication is normal, Red LED means abnormal


Note:

Refer to user manual for detail information-- Chapter 5 Troubleshooting.

B.8.2 Profibus Communication Module (CME-PD01)





B.8.2.1 Panel Appearance



- 1. SP LED: Indicating the connection status between VFD-E and CME-PD01.
- 2. NET LED: Indicating the connection status between CME-PD01 and PROFIBUS-DP.
- 3. Address Switches: Setting the address of CME-PD01 on PROFIBUS- DP network.
- 4. RS-485 Interface (RJ45): Connecting to VFD-E, and supply power to CME-PD01.
- PROFIBUS-DP Interface (DB9): 9-PIN connector that connects to PROFIBUS-DP network.
- 6. Extended Socket: 4-PIN socket that connects to PROFIBUS-DP network.

B.8.2.2 Dimensions Unit: mm[inch]





B.8.2.3 Parameters Settings in VFD-E

ameters cettings in Vi B E	
	VFD-E
Baud Rate 9600	Pr.09.01=1
RTU 8, N, 2	Pr.09.04=3
Freq. Source	Pr.02.00=4
Command Source	Pr.02.01=3

B.8.2.4 Power Supply

The power of CME-PD01 is supplied from VFD-E. Please connect VFD-E to CME-PD01 by using 8 pins RJ-45 cable, which is packed together with CME-PD01. After connection is completed, CME-PD01 is powered whenever power is applied to VFD-E.

B.8.2.5 PROFIBUS Address



ADDH ADDL

CME-PD01 has two rotary switches for the user to select the PROFIBUS address. The set value via 2 address switches, ADDH and ADDL, is in HEX format. ADDH sets the upper 4 bits, and ADDL sets the lower 4 bits of the PROFIBUS address.


Address	Meaning
10x7D	Valid PROFIBUS address
0 or 0x7E0xFE	Invalid PROFIBUS address


B.8.3 CME-COP01 (CANopen)

CME-COP01 CANopen communication module is specifically for connecting to CANopen communication module of Delta VFD-E AC motor drive.



B.8.3.1 Product Profile





1)	COM port
2	CANopen connection port
3	RUN indicator
4	ERROR indicator
(5)	SP (Scan Port) indicator
6	Baud rate switch
7	Address switch

B.8.3.2 Specifications

CANopen Connection

Interface	Pluggable connector (5.08mm)
Transmission method	CAN
Transmission cable	2-wire twisted shielded cable
Electrical isolation	500V DC

Communication

Message type	Process Data Objects (PDO) Service Data Object (SDO) Synchronization (SYNC) Emergency (EMCY) Network Management (NMT)	Baud rate	10 Kbps 20 Kbps 50 Kbps 125 Kbps 250 Kbps 500 Kbps 800 Kbps
Product code	Delta VFD-E AC motor drive	22	_
Device type	402	·	
Vendor ID	477	·	

Environmental Specifications

	ESD(IEC 61131-2, IEC 61000-4-2): 8KV Air Discharge EFT(IEC 61131-2, IEC 61000-4-4): Power Line: 2KV, Digital I/O: 1KV,
Noise Immunity	Analog & Communication I/O: 1KV Damped-Oscillatory Wave: Power Line: 1KV, Digital I/O: 1KV
	RS(IEC 61131-2, IEC 61000-4-3): 26MHz ~ 1GHz, 10V/m


Environment	Operation: 0°C ~ 55°C (Temperature), 50 ~ 95% (Humidity), Pollution degree 2; Storage: -40°C ~ 70°C (Temperature), 5 ~ 95% (Humidity)
Vibration / Shock Resistance	Standard: IEC1131-2, IEC 68-2-6 (TEST Fc/IEC1131-2 & IEC 68-2-27 (TEST Ea)
Certifications	Standard: IEC 61131-2,UL508

B.8.3.3 Components

Pin Definition on CANopen Connection Port

To connect with CANopen, use the connector enclosed with CME-COP01 or any connectors you can buy in the store for wiring.

Pin	Signal	Content
1	CAN_GND	Ground / 0 V / V-
2	CAN_L	Signal-
3	SHIELD	Shield
4	CAN_H	Signal+
5	-	Reserved



Baud Rate Setting

Rotary switch (BR) sets up the communication speed on CANopen network in hex. Setup range: $0 \sim 7$ (8 \sim F are forbidden)



Example: If you need to set up the communication speed of CME-COP01 as 500K, simply switch BR to "5".

BR Value	Baud rate	BR Value	Baud rate
0	10K	4	250K
1	20K	5	500K
2	50K	6	800K
3	125K	7	1M

MAC ID Setting

Rotary switches (ID_L and ID_H) set up the Node-ID on CANopen network in hex. Setup range: 00 ~ 7F (80 ~FF are forbidden)





Example: If you need to set up the communication address of CME-COP01 as 26(1AH), simply switch ID_H to "1" and ID_L to "A".

Switch Setting	Content
0 7F	Valid CANopen MAC ID setting
Other	Invalid CANopen MAC ID setting

B.8.3.4 LED Indicator Explanation & Troubleshooting
There are 3 LED indicators, RUN, ERROR and SP, on CME-COP01 to indicate the communication status of CME-COP01.

RUN LED


LED Status	State	Indication	
OFF	No power	No power on CME-COP01 card	
Single Flash (Green)	STOPPED	CME-COP01 is in STOPPED state	
Blinking (Green)	PRE-OPERATIONAL	CME-COP01 is in the PRE-OPERATIONAL state	
Green ON	OPERATIONAL	CME-COP01 is in the OPERATIONAL state	
Red ON	Configuration error	Node-ID or Baud rate setting error	
ERROR LED			
LED Status	State	Indication	
OFF	No error	CME-COP01 is working condition	
Single Flash (Red)	Warning limit reached	At least one of error counter of the CANopen controller has reached or exceeded the warning level (too many error frames)	
Double Flash (Red)	Error control event	A guard event or heartbeat event has occurred	
Red ON	Bus-off	The CANopen controller is bus-off	
SP LED			
SP LED			
LED Status	State	Indication	
	State No Power	Indication No power on CME-COP01 card	
LED Status			
LED Status OFF LED Blinking	No Power	No power on CME-COP01 card Check your communication setting in	
LED Status OFF LED Blinking (Red)	No Power CRC check error Connection failure/No	No power on CME-COP01 card Check your communication setting in VFD-E drives (19200,<8,N,2>,RTU) 1. Check the connection between VFD-E drive and CME-COP01 card is correct 2. Re-wire the VFD-E connection and ensure that the wire specification is	
LED Status OFF LED Blinking (Red) Red ON LED Blinking	No Power CRC check error Connection failure/No connection CME-COP01 returns error	No power on CME-COP01 card Check your communication setting in VFD-E drives (19200,<8,N,2>,RTU) 1. Check the connection between VFD-E drive and CME-COP01 card is correct 2. Re-wire the VFD-E connection and ensure that the wire specification is correct Check the PLC program, ensure the	
LED Status OFF LED Blinking (Red) Red ON LED Blinking (Green)	No Power CRC check error Connection failure/No connection CME-COP01 returns error code	No power on CME-COP01 card Check your communication setting in VFD-E drives (19200,<8,N,2>,RTU) 1. Check the connection between VFD-E drive and CME-COP01 card is correct 2. Re-wire the VFD-E connection and ensure that the wire specification is correct Check the PLC program, ensure the index and sub-index is correct	
LED Status OFF LED Blinking (Red) Red ON LED Blinking (Green) Green ON	No Power CRC check error Connection failure/No connection CME-COP01 returns error code Normal	No power on CME-COP01 card Check your communication setting in VFD-E drives (19200,<8,N,2>,RTU) 1. Check the connection between VFD-E drive and CME-COP01 card is correct 2. Re-wire the VFD-E connection and ensure that the wire specification is correct Check the PLC program, ensure the index and sub-index is correct	
LED Status OFF LED Blinking (Red) Red ON LED Blinking (Green) Green ON LED Descriptions	No Power CRC check error Connection failure/No connection CME-COP01 returns error code Normal	No power on CME-COP01 card Check your communication setting in VFD-E drives (19200,<8,N,2>,RTU) 1. Check the connection between VFD-E drive and CME-COP01 card is correct 2. Re-wire the VFD-E connection and ensure that the wire specification is correct Check the PLC program, ensure the index and sub-index is correct Communication is normal	
LED Status OFF LED Blinking (Red) Red ON LED Blinking (Green) Green ON LED Descriptions State	No Power CRC check error Connection failure/No connection CME-COP01 returns error code Normal	No power on CME-COP01 card Check your communication setting in VFD-E drives (19200,<8,N,2>,RTU) 1. Check the connection between VFD-E drive and CME-COP01 card is correct 2. Re-wire the VFD-E connection and ensure that the wire specification is correct Check the PLC program, ensure the index and sub-index is correct Communication is normal	
LED Status OFF LED Blinking (Red) Red ON LED Blinking (Green) Green ON LED Descriptions State LED ON	No Power CRC check error Connection failure/No connection CME-COP01 returns error code Normal	No power on CME-COP01 card Check your communication setting in VFD-E drives (19200,<8,N,2>,RTU) 1. Check the connection between VFD-E drive and CME-COP01 card is correct 2. Re-wire the VFD-E connection and ensure that the wire specification is correct Check the PLC program, ensure the index and sub-index is correct Communication is normal	


LED double	On for 0.25 off for 0.25 on for 0.25 and off for 15
flash	On for 0.2s off for 0.2s, on for 0.2s and off for 1s

B.8.4 MKE-HUB01

In order to improve the reliability for multiple communication wiring, Delta has developed a special communication hub MKE-HUB01.

Please refer to the following diagram for operating and wiring:





B.8.5 IFD6500

Introduction

IFD6500 is a convenient RS-485-to-USB converter, which does not require external power-supply and complex setting process. It supports baud rate from 75 to 115.2kbps and auto switching direction of data transmission. In addition, it adopts RJ-45 in RS-485 connector for users to wire conveniently. And its tiny dimension, handy use of plug-and-play and hot-swap provide more conveniences for connecting all DELTA IABU products to your PC. Applicable Models: All DELTA IABU products.

Application & Dimension




Specifications

opcomodiono		
Power supply	No external power is needed	
Power consumption	0.4W	
Isolated voltage	2,500VDC	
Baud rate	75, 150, 300, 600, 1,200, 2,400, 4,800, 9,600, 19,200, 38,400, 57,600, 115,200 bps	
RS-485 connector	RJ-45	
USB connector	A type (plug)	
Compatibility	Full compliance with USB V2.0 specification	
Max. cable length	RS-485 Communication Port: 100 m	
Support RS-485 half-duplex transmission		

RJ-45





PIN	Description
1	Reserved
2	Reserved
3	Reserved
4	SG+


PIN	Description
5	SG-
6	Reserved
7	Reserved
8	Reserved

Preparations before Driver Installation

Please extract the driver file by following steps. You could find driver file in the CD supplied with IFD6500.

Note: DO NOT connect IFD6500 to PC before extracting the driver file.










STEP 5


You should have a folder marked SiLabs under drive C.

Driver Installation

After connecting IFD6500 to PC, please install driver by following steps. STEP 1 $\,$








STEP 5
Repeat Step 1 to Step 4 to complete
COM PORT setting.

LED Display


- 1. Steady Green LED ON: power is ON.
- 2. Blinking orange LED: data is transmitting.

B.9 DIN Rail

B.9.1 MKE-DRA




B.9.2 MKE-DRB Unit: mm [inch]



B.9.3 MKE-EP

EMC earthing plate for Shielding Cable



B.10 EMI Filter

To meet EN61800-3 variable speed drive system- part 3: EMC requirements and specific test methods,

category C1, C2 and C3. Users can choose the suitable filter by the following table.

y C1, C2 and C3. Osers can choose the suitable litter by the following table.									
	1-phase/ 3-phase	Voltage	HP	AC Motor Drive	Frame	Deltron Filter	C3	C2	C1
		110V	0.5	VFD004E11A	Α	MDF16	10m	10m	10m
		1100	1	VFD007E11A	Α	MDF25	50m	50m	50m
			0.25	VFD002E21A	Α				
	1-phase		0.5	VFD004E21A	Α	MDF16	50m	50m	50m
		230V	1	VFD007E21A	Α				
			2	VFD015E21A	В	MDF25	50m	50m	Fail*
			3	VFD022E21A	В				Ган
		230V	2	VFD015E23A	В	KMF310A	100m	100m	25m
			20	VFD150E23A	D	KMF3100A	100m	100m	3m
			0.5	VFD004E43A	Α	KMF306A	50m	50m	
			1	VFD007E43A	Α				50m
			2	VFD015E43A	Α				
	3-phase		3	VFD022E43A	В	KMF318A	50	50m	50m
		460V	5	VFD037E43A	В	KIVIF3 IOA	50m	50111	SUIII
			7.5	VFD055E43A	С	KMF325A	75m		
			10	VFD075E43A	С			50m	50m
			15	VFD110E43A	С				
			30	VFD220E43A	D	KMF350A	100m	100m	50m

NOTE: For model VFD022E21A and VFD015E21A, please use MIF filter to meet Category C1.

Installation

All electrical equipment, including AC motor drives, will generate high-frequency/low-frequency noise and will interfere with peripheral equipment by radiation or conduction when in operation. By using an EMI filter with correct installation, much interference can be eliminated. It is recommended to use DELTA EMI filter to have the best interference elimination performance.

We assure that it can comply with following rules when AC motor drive and EMI filter are installed and wired according to user manual:

EN61000-6-4

EN61800-3: 1996

EN55011 (1991) Class A Group 1

General precaution


- 1. EMI filter and AC motor drive should be installed on the same metal plate.
- Please install AC motor drive on footprint EMI filter or install EMI filter as close as possible to the AC motor drive.
- 3. Please wire as short as possible.
- 4. Metal plate should be grounded.
- 5. The cover of EMI filter and AC motor drive or grounding should be fixed on the metal plate and the contact area should be as large as possible.

Choose suitable motor cable and precautions

Improper installation and choice of motor cable will affect the performance of EMI filter. Be sure to observe the following precautions when selecting motor cable.

- 1. Use the cable with shielding (double shielding is the best).
- 2. The shielding on both ends of the motor cable should be grounded with the minimum length and maximum contact area.
- 3. Remove any paint on metal saddle for good ground contact with the plate and shielding.

Remove any paint on metal saddle for good ground contact with the plate and shielding.



Saddle on one end

The length of motor cable

When motor is driven by an AC motor drive of PWM type, the motor terminals will experience surge voltages easily due to components conversion of AC motor drive and cable capacitance. When the motor cable is very long (especially for the 460V series), surge voltages may reduce insulation quality. To prevent this situation, please follow the rules below:

- Use a motor with enhanced insulation.
- Connect an output reactor (optional) to the output terminals of the AC motor drive
- The length of the cable between AC motor drive and motor should be as short as possible (10 to 20 m or less)
- For models 7.5hp/5.5kW and above:

a olo Tionprotenti ana abe	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			
Insulation level of motor	1000V	1300V	1600V	
460VAC input voltage	66 ft (20m)	328 ft (100m)	1312 ft (400m)	
230VAC input voltage	1312 ft (400m)	1312 ft (400m)	1312 ft (400m)	

Note:

When a thermal O/L relay protected by motor is used between AC motor drive and motor, it may malfunction (especially for 460V series), even if the length of motor cable is only 165 ft (50m) or less. To prevent it, please use AC reactor and/or lower the carrier frequency (Pr. 02.03 PWM carrier frequency)


Note:

Never connect phase lead capacitors or surge absorbers to the output terminals of the AC motor drive.

- If the length is too long, the stray capacitance between cables will increase and may cause leakage current. It will activate the protection of over current, increase leakage current or not insure the correction of current display. The worst case is that AC motor drive may damage.
- If more than one motor is connected to the AC motor drive, the total wiring length is the sum of the wiring length from AC motor drive to each motor.

B.11 Fan Kit

Frames of the fan kit Unit: mm [inch]



Note:

In order to make sure that fans work properly, it is recommended to verify their functions every 6 to 12 months. It is also recommended to change module of fans every 8 years to ensure the proper function and safety of the product.

B.12 KPC-CC01 keypad

Due to VFD-E default communication protocol is ASCII 9600, 7, N, 2, but KPC-CC01 communication protocol is RTU 19200, 8, N, 2, you need to set VFD-E communication parameters so that it can connect with KPC-CC01. Set Pr.09.00=1, 09.01=2, 09.04=3 and you can select operating functions by pressing KPC-CC01 MENU key. Please refer to CH.4 Pr.09 Group for details.

Pr.09.00 Communication Address

Pr.09.01 Transmission Speed (Baud rate)

Pr.09.04 Communication Protocol

KPC-CC01 is communicating with control board by using 255 communication station, so if the Transmission Speed is corresponding with Communication Protocol, the control board can receive packet properly, it can judge as keypad devices and communicate mutually.

Digital Keypad only can support the serial production after product series No.: xxxExxAxT205xxxx, xxxExxAxW202xxxx.

Some parameters cannot be copied by using PU06, KPC-CC01 or VFDSoft, please refer to B-5 Digital Keypad PU06 for details.

Descriptions of Digital Keypad KPC-CC01



Communication Interface: RJ-45 (socket) \ RS-485 interface

Installation:


- Embedded, it can flat the control box surface and front waterproof.
- You can select optional model:

 MKC-KPPK, the protection level is IP56;
 user can choose wall mounting or
 embedded mounting.


Descriptions of Keypad Functions

Descriptions of Keypad Functions							
Key	Descriptions						
RUN	 Start Operation Key It is only valid when the source of operation command is from the keypad. It can operate the AC motor drive by the function setting and the RUN LED will be ON. It can be pressed again and again at stop process. 						
	Stop Command Key. This key has the highest processing priority in any situation.						
	1. When it receives STOP command, no matter the AC motor drive is in operation						
(STOP RESET	or stop status, the AC motor drive needs to execute "STOP" command.						
	2. The RESET key can be used to reset the drive after the fault occurs. For those						
	faults that can't be reset by the RESET key, see the fault records after pressing						
	MENU key for details.						
	Operation Direction Key						
FWD	1. This key is only control the operation direction NOT for activate the drive.						
REV	FWD: forward, REV: reverse.						
	Refer to the LED descriptions for more details.						
ENTER	ENTER Key Press ENTER and go to the next level. If it is the last level then press ENTER to execute the command.						
	ESC Key						
ESC	ESC key function is to leave current menu and return to the last menu. It is also functioned as a return key in the sub-menu.						
	Press menu to return to main menu. Menu content:						
	KPC-CC01 does not support function 1, 4, 5, and 7; only support part function of						
	10,11, 12, and 13.						
MENU	 Detail Parameter 7. Quick/Simple Setup 13. PC Link Copy Parameter 8. Display Setup 						
	3. Keypad Locked 9. Time Setup						
	4. PLC Function 10. Language Setup5. Copy PLC 11. Startup Menu						
	6. Fault Record 12. Main Page						
^	Direction: Left/Right/Up/Down						
>	 In the numeric value setting mode, it is used to move the cursor and change the numeric value. 						
	In the menu/text selection mode, it is used for item selection.						
F1 F2							
F1 F2 F3 F4	Does not support function						

Descriptions of LED Functions




Function of Digital Keypad KPC-CC01




Note:

- 1. Startup page can only display pictures, no flash.
- 2. When Power ON, it will display startup page then the main page. The main page displays Delta's default setting F/H/A/U, the display order can be set by Pr.00.03 (Startup display). When the selected item is U page, use left key and right key to switch between the items, the display order of U page is set by Pr.00.04 (User display).

Display Icon



Display item




Item 1~4 are the common items for

KPC-CC01 & KPC-CE01


MENU

- 1.Detail Parameter 2.Copy Parameter
- 3. Keypad Locked
- 4.PLC Function
- 5. Copy PLC
- 6. Fault Record
- 7. Quick/Simple Setup
- 8. Display Setup
- 9. Time Setup
- 10. Language Setup
- 11. Start-up
- 12. Main page
- 13. PC Link


Detail Parameter




00 System Pr Content




00-08 Password disable



01-00 Max Output freq



Copy Parameter




4 sets of parameters duplication.


Keypad V1.02 (contained) previous versions: it does not support self-editing file name function, and use KPC-CC01 internal date as file name directly when saving.

Keypad V1.03 (contained) later versions: you can enter file name when parameters are copying in order to distinguish by customers, and when the set is completed, it will modify date and time into the parameter copied screen (file name _ date _ time) immediately, the step process is as the following example.

Example: If you want to copy drive's parameters into KPC-CC01, you need to enter "Copy Pr" function first, select the locations (001~004) you want to save, and then press the"Enter" key.



Press (ENTER) to select.



Select 2. VFD-> Keypad => Press "Enter" then enter file name setting

screen(as shown below),use key to select text*1 with key to switch the location moving function.



After finishing, press ENTER to save

1: File name is setting as text patterns and defines as text (0~9,A~Z,+-/.....).It is according to ASCII Table to scroll sequence by using UP/DOWN keys.

Keypad Lock

Menu

- 1: Pr Setup
- 2: Copy Pr
- 3: Keypad Lock

Keypad Lock

Press ENTER to Lock Key



This function is selecting "Keypad Lock":

When the keypad locked, the main screen does not display lock status, if you press any button it will pop up a dialog box and showing "Press ESC 3 sec to Unlock key"





Press any key

Keypad Lock

Press ESC 3sec to Unlock Key

Fault Record






Keypad V1.02(contained) previous versions: It can accumulate 6 sets fault code.

Keypad V1.03 (contained) later versions: It can accumulate 20sets fault code.

The latest one is the unusual record from the recent date, click enter to check detailed record (Included date, time, output frequency, output current, output voltage and DC BUS voltage)


Example:

















This function is just only for the failure record of drive as the moment and recorded in KPC-CC01. If user put KPC-CC01 keypad to other drive randomly, it needs to pay attention to their own failure record will not lose due to replace KPC-CC01 keypad.


Display Setup








1. Contrast Adjustment



2. Back-Light Time




[Note]: If you want to close the backlight of failure message, you can set backlight time to 0.


3. Text Color



Time Setup



Enter time setup page, "3" will continue to blink




ENTER to confirm.



Limitations: The capacitor charging time of KPC-CC01 is around 6minutes. When the digital keypad is removed, the time setting will be in standby status for 7 days. After this period, the time needs to be reset.


Language Setup






Language setting option is displayed the language fonts $\dot{}$ you can use Up / Down keys to make a choice , then press the ENTER key to do the display language setting.

(VFD-E menu contents: 1:Pr Setup only can support English display,[Failure message only can support English display])



Start-up Page Setup





- 1. Default picture 1
 DELTA LOGO
- 2. Default picture 2 DELTA Text
- 3. User Defined (VFD-E does not support this function)

Start-up ▼ 1: Default1 2: Default2

3: User Defined

Main Page





Provide "Default" and "User Defined" mode to select




1.Default Page




F 60.00Hz $\Rightarrow\Rightarrow$ H $\Rightarrow\Rightarrow$ U $\Rightarrow\Rightarrow$ A (cycle display)

2. User Defined (VFD-E does not support this function)

PC Link






Select"2" VFDSoft and press **ENTER** (VFD-E does not support TPEditor)


Select VFDSoft option, enter this function page1 and

via VFDSoft to upload the parameters from KPC-CC01.

1. choose parameter file you want to upload, press "Enter" to go to next page and wait for the communication confirmation from PC.

The function of PC Link is to establish a connection with computer






2. Open VFDSoft =>select"Parameter Manager" =>select upper right options "table".

=>Select "Load parameter table from KPC-CC01" => there will be a "Communication Settings" window now.

=>Please select the corresponding connection port for PC and KPC-CC01 then press "OK".


3. Upload parameters to PC via KPC-CC01=> when started the waiting page will appear=>after completing then press "MENU" back to Main Page.






Other display

When fault occur, the menu will display:





- Press ENTER and start RESET. If still no response, please contact local distributor or return to 1. the factory. To view the fault DC BUS voltage, output current and output voltage, press "MENU"→"Fault Record".
- Press ENTER again, if the screen returns to main page, the fault is clear. 2.
- When fault or warning message appears, backlight LED will blinks until the fault or the warning is cleared.

Optional accessory: RJ45 Extension Lead for Digital Keypad

	<u> </u>			
Part No.	Description			
CBC-K3FT	RJ45 extension lead, 3 feet (approximately 0.9m)			
CBC-K5FT	RJ45 extension lead, 5 feet (approximately 1.5 m)			
CBC-K7FT	RJ45 extension lead, 7 feet (approximately 2.1 m)			
CBC-K10FT	RJ45 extension lead, 10 feet (approximately 3 m)			
CBC-K16FT	RJ45 extension lead, 16 feet (approximately 4.9 m)			

Appendix C: How to Select the Right AC Motor Drive

The choice of the right AC motor drive for the application is very important and has great influence on its lifetime. If the capacity of AC motor drive is too large, it cannot offer complete protection to the motor and motor maybe damaged. If the capacity of AC motor drive is too small, it cannot offer the required performance and the AC motor drive maybe damaged due to overloading.

But by simply selecting the AC motor drive of the same capacity as the motor, user application requirements cannot be met completely. Therefore, a designer should consider all the conditions, including load type, load speed, load characteristic, operation method, rated output, rated speed, power and the change of load capacity. The following table lists the factors you need to consider, depending on your requirements.

		Related Specification						
	Speed and torque characteristics	Time ratings	Overload capacity	Starting torque				
Load type	Friction load and weight load Liquid (viscous) load Inertia load Load with power transmission	•			•			
Load speed and torque characteristics	Constant torque Constant output Decreasing torque Decreasing output	•	•					
Load characteristics	Constant load Shock load Repetitive load High starting torque Low starting torque	•	•	•	•			
	tion, Short-time operation on at medium/low speeds		•	•				
	current (instantaneous) urrent (continuous)	•		•				
Maximum frequen	•							
Power supply tran percentage imped Voltage fluctuation Number of phases Frequency			•	•				
Mechanical friction	n, losses in wiring			•	•			
Duty cycle modific	eation		•					

C.1 Capacity Formulas

1. When one AC motor drive operates one motor

The starting capacity should be less than 1.5x rated capacity of AC motor drive The starting capacity=

$$\frac{k \times N}{973 \times \eta \times \cos \varphi} \left(T_L + \frac{GD^2}{375} \times \frac{N}{t_A} \right) \le 1.5 \times the _capacity _of _AC _motor _drive(kVA)$$

2. When one AC motor drive operates more than one motor

- 2.1 The starting capacity should be less than the rated capacity of AC motor drive
- Acceleration time ≤60 seconds

The starting capacity=

$$\frac{k \times N}{\eta \times \cos \varphi} \left[n_{\tau} + n_{s} \left(k_{s-1} \right) \right] = P_{C1} \left[1 + \frac{n_{s}}{n_{\tau}} \left(k_{s-1} \right) \right] \leq 1.5 \times the \ _capacity \ _of \ _AC \ _motor \ _drive(kVA)$$

■ Acceleration time ≥60 seconds

The starting capacity=

$$\frac{k \times N}{\eta \times \cos \varphi} \left[n_{\tau} + n_{s}(k_{s-1}) \right] = P_{C1} \left[1 + \frac{n_{s}}{n_{\tau}}(k_{s-1}) \right] \leq the _capacity_of_AC_motor_drive(kVA)$$

- 2.2 The current should be less than the rated current of AC motor drive(A)
- Acceleration time ≤60 seconds

$$n_T + I_M \left[1 + \frac{n_S}{n_T} (k_S - 1) \right] \le 1.5 \times the _rated _current _of _AC _motor _drive(A)$$

■ Acceleration time ≥60 seconds

$$n_T + I_M \left[1 + \frac{n_S}{n_T} (k_{S-1}) \right] \le the _rated _current _of _AC _motor _drive(A)$$

- 2.3 When it is running continuously
- The requirement of load capacity should be less than the capacity of AC motor drive(kVA)

The requirement of load capacity=

$$\frac{k \times P_M}{\eta \times \cos \varphi} \le the_capacity_of_AC_motor_drive(kVA)$$

■ The motor capacity should be less than the capacity of AC motor drive

$$k \times \sqrt{3} \times V_M \times I_M \times 10^{-3} \le the_capacity_of_AC_motor_drive(kVA)$$

■ The current should be less than the rated current of AC motor drive(A)

$$k \times I_M \le the_rated_current_of_AC_motor_drive(A)$$

Symbol explanation

 P_M : Motor shaft output for load (kW)

 η : Motor efficiency (normally, approx. 0.85)

 $\cos \varphi$: Motor power factor (normally, approx. 0.75)

 V_M : Motor rated voltage(V)

 I_M : Motor rated current(A), for commercial power

k : Correction factor calculated from current distortion factor (1.05-1.1, depending on

PWM method)

 P_{C1} : Continuous motor capacity (kVA)

ks : Starting current/rated current of motor

 n_T : Number of motors in parallel

 n_{S} : Number of simultaneously started motors

 GD^2 : Total inertia (GD^2) calculated back to motor shaft (kg m²)

 T_L : Load torque

 t_A : Motor acceleration time

N : Motor speed

C.2 General Precaution

Selection Note

- 1. When the AC Motor Drive is connected directly to a large-capacity power transformer (600kVA or above) or when a phase lead capacitor is switched, excess peak currents may occur in the power input circuit and the converter section may be damaged. To avoid this, use an AC input reactor (optional) before AC Motor Drive mains input to reduce the current and improve the input power efficiency.
- When a special motor is used or more than one motor is driven in parallel with a single AC Motor Drive, select the AC Motor Drive current ≥1.25x(Sum of the motor rated currents).
- 3. The starting and accel./decel. characteristics of a motor are limited by the rated current and the overload protection of the AC Motor Drive. Compared to running the motor D.O.L. (Direct On-Line), a lower starting torque output with AC Motor Drive can be expected. If higher starting torque is required (such as for elevators, mixers, tooling machines, etc.) use an AC Motor Drive of higher capacity or increase the capacities for both the motor and the AC Motor Drive.
- 4. When an error occurs on the drive, a protective circuit will be activated and the AC Motor Drive output is turned off. Then the motor will coast to stop. For an emergency stop, an external mechanical brake is needed to quickly stop the motor.

Parameter Settings Note

- The AC Motor Drive can be driven at an output frequency up to 400Hz (less for some models) with the digital keypad. Setting errors may create a dangerous situation. For safety, the use of the upper limit frequency function is strongly recommended.
- High DC brake operating voltages and long operation time (at low frequencies) may cause overheating of the motor. In that case, forced external motor cooling is recommended.
- 3. Motor accel./decel. time is determined by motor rated torque, load torque, and load inertia.
- 4. If the stall prevention function is activated, the accel./decel. time is automatically extended to a length that the AC Motor Drive can handle. If the motor needs to decelerate within a certain time with high load inertia that can't be handled by the AC Motor Drive in the


required time, either use an external brake resistor and/or brake unit, depending on the model, (to shorten deceleration time only) or increase the capacity for both the motor and the AC Motor Drive.

C.3 How to Choose a Suitable Motor

Standard motor

When using the AC Motor Drive to operate a standard 3-phase induction motor, take the following precautions:

- 1. The energy loss is greater than for an inverter duty motor.
- Avoid running motor at low speed for a long time. Under this condition, the motor temperature may rise above the motor rating due to limited airflow produced by the motor's fan. Consider external forced motor cooling.
- When the standard motor operates at low speed for long time, the output load must be decreased.
- 4. The load tolerance of a standard motor is as follows:



- 5. If 100% continuous torque is required at low speed, it may be necessary to use a special inverter duty motor.
- 6. Motor dynamic balance and rotor endurance should be considered once the operating speed exceeds the rated speed (60Hz) of a standard motor.

- 7. Motor torque characteristics vary when an AC Motor Drive instead of commercial power supply drives the motor. Check the load torque characteristics of the machine to be connected.
- 8. Because of the high carrier frequency PWM control of the VFD series, pay attention to the following motor vibration problems:
- Resonant mechanical vibration: anti-vibration (damping) rubbers should be used to mount equipment that runs at varying speed.
- Motor imbalance: special care is required for operation at 50 or 60 Hz and higher frequency.
- To avoid resonances, use the Skip frequencies.
 - 9. The motor fan will be very noisy when the motor speed exceeds 50 or 60Hz.

Special motors:

1. Pole-changing (Dahlander) motor:

The rated current is differs from that of a standard motor. Please check before operation and select the capacity of the AC motor drive carefully. When changing the pole number the motor needs to be stopped first. If over current occurs during operation or regenerative voltage is too high, please let the motor free run to stop (coast).

2. Submersible motor:

The rated current is higher than that of a standard motor. Please check before operation and choose the capacity of the AC motor drive carefully. With long motor cable between AC motor drive and motor, available motor torque is reduced.

3. Explosion-proof (Ex) motor:

Needs to be installed in a safe place and the wiring should comply with the (Ex) requirements. Delta AC Motor Drives are not suitable for (Ex) areas with special precautions.

4. Gear reduction motor:

The lubricating method of reduction gearbox and speed range for continuous operation will be different and depending on brand. The lubricating function for operating long time at low speed and for high-speed operation needs to be considered carefully.

5. Synchronous motor:

The rated current and starting current are higher than for standard motors. Please check before operation and choose the capacity of the AC motor drive carefully. When the AC

motor drive operates more than one motor, please pay attention to starting and changing the motor.


Power Transmission Mechanism


Pay attention to reduced lubrication when operating gear reduction motors, gearboxes, belts and chains, etc. over longer periods at low speeds. At high speeds of 50/60Hz and above, lifetime reducing noises and vibrations may occur.


Motor torque


The torque characteristics of a motor operated by an AC motor drive and commercial mains power are different.

Below you'll find the torque-speed characteristics of a standard motor (4-pole, 15kW):









Appendix D: How to Use PLC Function

※ This function is NOT for VFD*E*C models.

D.1 PLC Overview

D.1.1 Introduction

The PLC function built in the VFD-E provides following commands: WPLSoft, basic commands and application commands. The operation methods are the same as Delta DVP-PLC series.

D.1.2 Ladder Diagram Editor – WPLSoft

WPLSoft is a program editor of Delta DVP-PLC series and VFD-E series for WINDOWS. Besides general PLC program planning and general WINDOWS editing functions, such as cut, paste, copy, multi-windows, WPLSoft also provides various Chinese/English comment editing and other special functions (e.g. register editing, settings, the data readout, the file saving, and contacts monitor and set, etc.).

Following is the system requirement for WPLSoft:

Item	System Requirement
Operation System	Windows 95/98/2000/NT/ME/XP
CPU	Pentium 90 and above
Memory	16MB and above (32MB and above is recommended)
Hard Disk	Capacity: 50MB and above CD-ROM (for installing WPLSoft)
Monitor	Resolution: 640×480, 16 colors and above, It is recommended to set display setting of Windows to 800×600.
Mouse	General mouse or the device compatible with Windows
Printer	Printer with Windows driver
RS-485 port	At least one of RS485 port can be connected to PLC

D.2 Start-up

D.2.1 The Steps for PLC Execution

Please operate PLC function by the following five steps.

- 1. Switch the mode to PLC2 for program download/upload:
 - A. Go to "PLC0" page by pressing the MODE key
 - B. Change to "PLC2" by pressing the "UP" key and then press the "ENTER" key after confirmation
 - C. If succeeded, "END" is displayed and back to "PLC2" after one or two seconds.





Run PLC



Disable

Read/write PLC program into AC drives



- If PLC is first time used: it will show PLFF or PLor warning when the program hasn't been downloaded from PLC Ladder to PLC.
- If PLC has been activated: after downloading program from PLC Ladder to PLC, it will show Plod, PLdA or PLFn if the modified program make used D or M out of range or adding new command.
- If PLC has been reset, it may show PLFF
 - 2. Connection: Please connect RJ-45 of AC motor drive to computer via RS485-to-RS232 converter.



Run the program. The PLC status will always be PLC2, even if the AC motor drive is switched off.

There are three ways to operate PLC:

A. In "PLC1" page: execute PLC program.

B. In "PLC2" page: execute/stop PLC program by using WPL software.


C. After setting multi-function input terminals (MI3 to MI9) to 23 (RUN/STOP PLC), it will display "PLC1" for executing PLC when the terminal is ON. It will display "PLC0" to stop PLC program when terminals are OFF.



When external terminals are set to 23 and the terminal is ON, it cannot use keypad to change PLC mode. Moreover, when it is PLC2, you cannot execute PLC program by external terminals.



When power on after power off, the PLC status will be in "PLC1".



4. When you are in "PLC2", please remember to change to "PLC1" when finished to prevent anyone modifying PLC program.



When output/input terminals (MI1~MI9, Relay1~Relay 4, MO1~MO4) are used in PLC program, they cannot be used in other places. For example, When Y0 in PLC program is activated, the corresponding output terminals Relay (RA/RB/RC) will be used. At this moment, parameter 03.00 setting will be invalid. Because the terminal has been used by PLC.



The PLC corresponding input points for MI1 to MI6 are X0 to X5. When extension card are added, the extension input points will be numbered from X06 and output points will start from Y2 as shown in chapter D.2.2.

D.2.2 Device Reference Table

Device		X										
ID	0	1	2	3	4	5	6	7	10	11	12	13
Terminals of AC Drives	MI1	MI2	MI3	MI4	MI5	MI6						
3IN/3OUT Card (EME-D33A) (D1022 = 6)	1		ı	1	1		MI7	MI8	MI9	1	1	
6IN 110VAC card (EME-D611A) (D1022 = 8)							MI1	MI2	MI3	MI4	MI5	MI6

Device	Υ

ID	0	1	2	3	4
Terminals of AC Drives	RY	MO1			
Relay Card-2C (EME-DR2CA)			RY2	RY3	
Relay Card-3A (EME-R3AA)			RY2	RY3	RY4
3IN/3OUT Card (EME-D33A)			MO2	МО3	MO4


D.2.3 WPLSoft Installation

See Delta's website for WPLSoft editing software:


http://www.delta.com.tw/product/em/download/download main.asp?act=3&pid=1&cid=1&tpid=3

D.2.4 Program Writing


After completing installation, the WPLSoft program will be installed in the designated subfolder "C:\Program Files\Delta Industrial Automation\WPLSoft x.xx." The editing software can now be run by clicking on the WPL icon using the mouse.



The WPL editing window will appear after 3 seconds (see figure below). When running WPLSoft for the first time, before "New file" has been used, only the "File (F)," "Communications (C)," View (V)," "Options (O)," and "Help (H)" columns will appear on the function toolbar.




After running WPLSoft for the second time, the last file edited will open and be displayed in the editing window. The following figure provides an explanation of the WPLSoft editing software window:




Click on the icon on the toolbar in the upper left part of the screen: opens new file (Ctrl+N)




You can also use "File (F)"=> New file (N) (Ctrl+N)




The "Device settings" window will appear after clicking. You can now enter the project title and filename, and select the device and communication settings to be used




Communications settings: Perform settings in accordance with the desired communications method



Press Confirm after completing settings and begin program editing. There are two program editing methods; you can choose whether to perform editing in the command mode or the ladder diagram mode.



In ladder diagram mode, you can perform program editing using the buttons on the function icon row




Basic Operation

Example: Input the ladder diagram in the following figure


```
M10 (YD )
```

Mouse operation and keyboard function key (F1 to F12) operation

1. The following screen will appear after a new file has been established:




2. Use the mouse to click on the always-open switch icon F1 or press the function key F1:




3. After the name of the input device and the comment dialog box have appeared, the device name (such as "M"), device number (such as "10"), and input comments (such as "auxiliary contact") can be selected; press the Confirm button when finished.



4. Click on the output coil icon or press function key F7. After the name of the input device and the comment dialog box have appeared, the device name (such as "Y"), device number (such as "0"), and input comments (such as "output coil") can be selected; press the Confirm button when finished.




5. Click on application command icon F6 or press function key F6. Click on "All application commands" in the function classification field, and click on the End command in the application command pull-down menu, or use the keyboard to key in "End" in that field, and press the confirm button.



6. Click on the completion, which will compile the edited ladder diagram as a command

program. After compiling, the number of steps will appear on the left side of the busbar.



D.2.5 Program Download

Please do following steps for program download.


Step 1. Press button for compiler after inputting program in WPLSoft.

Step 2. After finishing compiler, choose the item "Write to PLC" in the communication items.

After finishing Step 2, the program will be downloaded from WPLSoft to the AC motor drive by the communication format.

D.2.6 Program Monitor

If you execute "start monitor" in the communication item during executing PLC, the ladder diagram will be shown as follows.



D.2.7 The Limit of PLC

- 1. The protocol of PLC is 7,E,1
- 2. Make sure that the AC drive is stop and stop PLC before program upload/download.

- 3. PLC will be stopped when program upload/download
- 4. When using WPR, please note: The times of value changes will be within 10⁶. If exceeding this range, EEPROM may be damaged due to too much reading and writing. The criteria of counting the times is accord to whether the written value changing or not. If written value remains the same, it will not be counted as one time in next operation. If written value is changed, then it will be counted as one time.
- 5. When setting P 00.04 to 2, the display will be the value in PLC register D1043.
 - A. $0 \sim 999$ display:



B. 1000 ~ 9999 display: It will only display the first 3 digits. The LED at the bottom-right corner will light to indicate 10 times of the display value. For example, the actual value for the following figure is 100X10=1000.



C. 10000~65535 display: It will only display the first 3 digits. The LED at the bottom-right corner and the single decimal point between the middle and the right-most numbers will light to indicate 100 times of the display value. For example, the actual value for the following figure is 100X100=10000.




- 6. When it is changed to "PLC2", RS-485 will be used by PLC.
- 7. When it is in PLC1 and PLC2 mode, the function to reset all parameters to factory setting is disabled (i.e. Pr.00.02 can't be set to 9 or 10).

D.3 Ladder Diagram

D.3.1 Program Scan Chart of the PLC Ladder Diagram

Calculate the result by ladder diagram algorithm (it doesn't sent to the outer output point but the inner equipment will output immediately.)



Execute in cycles

D.3.2 Introduction

Ladder diagram is a diagram language that applies on the automatic control and it is also a diagram that made up of the symbols of electric control circuit. PLC procedures are finished after ladder diagram editor edits the ladder diagram. It is easy to understand the control flow that indicated with diagram and also accepted by technical staff of electric control circuit. Many basic symbols and motions of ladder diagram are the same as mechanical and electrical equipments of traditional automatic power panel, such as button, switch, relay, timer, counter and etc.

The kinds and amounts of PLC internal equipment will be different with brands. Although internal equipment has the name of traditional electric control circuit, such as relay, coil and contact. It doesn't have the real components in it. In PLC, it just has a basic unit of internal memory. If this bit is 1, it means the coil is ON and if this bit is 0, it means the coil is OFF.

You should read the corresponding value of that bit when using contact (Normally Open, NO or contact a). Otherwise, you should read the opposite sate of corresponding value of that bit when using contact (Normally Closed, NC or contact b). Many relays will need many bits, such as 8-bits makes up a byte. 2 bytes can make up a word. 2 words make up double word.

When using many relays to do calculation, such as add/subtraction or shift, you could use byte, word or double word. Furthermore, the two equipments, timer and counter, in PLC not only have coil but also value of counting time and times.

In conclusion, each internal storage unit occupies fixed storage unit. When using these equipments, the corresponding content will be read by bit, byte or word. Basic introduction of the inner equipment of PLC:

Input relay	Input relay is the basic storage unit of internal memory that corresponds to external input point (it is the terminal that used to connect to external input switch and receive external input signal). Input signal from external will decide it to display 0 or 1. You couldn't change the state of input relay by program design or forced ON/OFF via WPLSoft. The contacts (contact a, b) can be used unlimitedly. If there is no input signal, the corresponding input relay could be empty and can't be used with other functions. Equipment indication method: X0, X1,X7, X10, X11, The symbol of equipment is X and the number uses octal. Please refer to D-2-2 I/O Device Reference Table for the numbers of input points.
Output relay	Output relay is the basic storage unit of internal memory that corresponds to external output point (it is used to connect to external load). It can be driven by input relay contact, the contact of other internal equipment and itself contact. It uses a normally open contact to connect to external load and other contacts can be used unlimitedly as input contacts. It doesn't have the corresponding output relay, if need, it can be used as internal relay. © Equipment indication: Y0, Y1,Y4. The symbol of equipment is Y and the number uses octal. Please refer to D-2-2 I/O Device Reference
Internal relay	Table for the numbers of input points. The internal relay doesn't connect directly to outside. It is an auxiliary relay in PLC. Its function is the same as the auxiliary relay in electric control circuit. Each auxiliary relay has the corresponding basic unit. It can be driven by the contact of input relay, output relay or other internal equipment. Its contacts can be used unlimitedly. Internal auxiliary relay can't output directly, it should output with output point. Equipment indication: M0, M1,, M4, M159. The symbol of equipment is M and the number uses decimal number system.
Timer	Timer is used to control time. There are coil, contact and timer storage. When coil is ON, its contact will act (contact a is close, contact b is open) when attaining desired time. The time value of timer is set by settings and each timer has its regular period. User sets the timer value and each timer has its timing period. Once the coil is OFF, the contact won't act (contact a is open and contact b is close) and the timer will be set to zero. Equipment indication: T0, T1,,T15. The symbol of equipment is T and the number uses decimal system. The different number range corresponds with the different timing period.
Counter	Counter is used to count. It needs to set counter before using counter (i.e. the pulse of counter). There are coil, contacts and storage unit of counter in counter. When coil is from OFF to ON, that means input a pulse in counter and the counter should add 1. There are 16-bit, 32-bit and high-speed counter for user to use. © Equipment indication: C0, C1,,C7. The symbol of equipment is C and the number uses decimal.
Data register	PLC needs to handle data and operation when controlling each order, timer value and counter value. The data register is used to store data or parameters. It stores 16-bit binary number, i.e. a word, in each register. It uses two continuous number of data register to store double words. — Equipment indication: D0, D1,,D29. The symbol of equipment is D and the number uses decimal.

The structure and explanation of ladder diagram:

Ladder Diagram Structure	Explanation	Command	Equipment
HH	Normally open, contact a	LD	X, Y, M, T, C
⊢и −	Normally closed, contact b	LDI	X, Y, M, T, C
⊢ ⊢ ⊢ ⊢	Serial normally open	AND	X, Y, M, T, C
	Serial normally close	ANI	X, Y, M, T, C
	Parallel normally open	OR	X, Y, M, T, C
	Parallel normally closed	ORI	X, Y, M, T, C
├ - ! ↑ 	Rising-edge trigger switch	LDP	X, Y, M, T, C
├ - ! ↓ ├ -	Falling-edge trigger switch	LDF	X, Y, M, T, C
├ ↑ 	Rising-edge trigger in serial	ANDP	X, Y, M, T, C
+	Falling-edge trigger in serial	ANDF	X, Y, M, T, C
	Rising-edge trigger in parallel	ORP	X, Y, M, T, C
	Falling-edge trigger in parallel	ORF	X, Y, M, T, C
	Block in serial	ANB	none
	Block in parallel	ORB	none


Ladder Diagram Structure	Explanation	Command	Equipment
	Multiple output	MPS MRD MPP	none
	Output command of coil drive	OUT	Y, M, S
	Basic command, Application command	Application command	Please refer to basic command and application command
	Inverse logic	INV	none

D.3.3 The Edition of PLC Ladder Diagram

The program edited method is from left power line to right power line. (the right power line will be omitted during the edited of WPLSoft.) After editing a row, go to editing the next row. The maximum contacts in a row are 11 contacts. If you need more than 11 contacts, you could have the new row and start with continuous line to continue more input devices. The continuous number will be produced automatically and the same input point can be used repeatedly. The drawing is shown as follows.

The operation of ladder diagram is to scan from left upper corner to right lower corner. The output handling, including the operation frame of coil and application command, at the most right side in ladder diagram.

Take the following diagram for example; we analyze the process step by step. The number at the right corner is the explanation order.




The explanation of command order:


1	LD	X0	
2	OR	MO	
3	AND	X1	
4	LD	X3	
	AND	M1	
	ORB		
5	LD	Y1	
	AND	X4	
6	LD	T0	
	AND	M3	
	ORB		
7	ANB		
8	OUT	Y1	
	TMR	T0 K10	

The detail explanation of basic structure of ladder diagram


1. LD (LDI) command: give the command LD or LDI in the start of a block.



The structures of command LDP and LDF are similar to the command LD. The difference is that command LDP and LDF will act in the rising-edge or falling-edge when contact is ON as shown in the following.




2. AND (ANI) command: single device connects to a device or a block in series.




The structures of ANDP and ANDF are the same but the action is in rising-edge or falling-edge.

3. OR (ORI) command: single device connects to a device or a block.




The structures of ORP and ORF are the same but the action is in rising-edge or falling-edge.

4. ANB command: a block connects to a device or a block in series.



5. ORB command: a block connects to a device or a block in parallel.




If there are several blocks when operate ANB or ORB, they should be combined to blocks or network from up to down or from left to right.

- 6. MPS, MRD, MPP commands: Divergent memory of multi-output. It can produce many various outputs.
- 7. The command MPS is the start of divergent point. The divergent point means the connection place between horizontal line and vertical line. We should determine to have contact memory command or not according to the contacts status in the same vertical line. Basically, each contact could have memory command but in some places of ladder diagram conversion will be omitted due to the PLC operation convenience and capacity limit. MPS command can be used for 8 continuous times and you can recognize this command by the symbol "T".
- 8. MRD command is used to read memory of divergent point. Because the logical status is the same in the same horizontal line, it needs to read the status of original contact to keep on analyzing other ladder diagram. You can recognize the command MRD by the symbol "\(\dag{F}''\).
- 9. MPP command is used to read the start status of the top level and pop it out from stack.

Because it is the last item of the horizontal line, it means the status of this horizontal line is ending.

You can recognize this command by the symbol " L". Basically, that is all right to use the above method to analyze but sometimes compiler will omit the same outputs as shown at the right.




D.3.4 The Example for Designing Basic Program

Start, Stop and Latching

In the same occasions, it needs transient close button and transient open button to be start and stop switch. Therefore, if you want to keep the action, you should design latching circuit. There are several latching circuits in the following:


Example 1: the latching circuit for priority of stop

When start normally open contact X1=On, stop normally contact X2=Off, and Y1=On are set at the same time, if X2=On, the coil Y1 will stop acting. Therefore, it calls priority of stop.



Example 2: the latching circuit for priority of start

When start normally open contact X1=On, stop normally contact X2=Off and Y1=On (coil Y1 will be active and latching) are valid at the same time, if X2=On, coil Y1 will be active due to latched contact. Therefore, it calls priority of start.



SET

RST

Y1

Y1

Top priority of stop

X1

1 ŀ


X2

Example 3: the latching circuit of SET and RST commands

The figure at the right side is latching circuit that made up of RST and SET command.


It is top priority of stop when RST command is set behind SET command. When executing PLC from up to down, The coil Y1 is ON and coil Y1 will be OFF when X1 and X2 act at the same time, therefore it calls Top priority of start priority of stop.


It is top priority of start when SET command is set after RST command. When X1 and X2 act at the same time, Y1 is ON so it calls top priority of start.



The common control circuit


Example 4: condition control






X1 and X3 can start/stop Y1 separately, X2 and X4 can start/stop Y2 separately and they are all self latched circuit. Y1 is an element for Y2 to do AND function due to the normally open contact connects to Y2 in series. Therefore, Y1 is the input of Y2 and Y2 is also the input of Y1.


Example 5: Interlock control





The figure above is the circuit of interlock control. Y1 and Y2 will act according to the start contact X1 and X2. Y1 and Y2 will act not at the same time, once one of them acts and the other won't act. (This is called interlock.) Even if X1 and X2 are valid at the same time, Y1 and Y2 won't act at the same time due to up-to-down scan of ladder diagram. For this ladder diagram, Y1 has higher priority than Y2.


Example 6: Sequential Control



If add normally close contact Y2 into Y1 circuit to be an input for Y1 to do AND function. (as shown in the left side) Y1 is an input of Y2 and Y2 can stop Y1 after acting. In this way, Y1 and Y2 can execute in sequential.


Example 7: Oscillating Circuit

The period of oscillating circuit is $\Delta T + \Delta T$




The figure above is a very simple ladder step diagram. When starting to scan Y1 normally close contact, Y1 normally close contact is close due to the coil Y1 is OFF. Then it will scan Y1 and the coil Y1 will be ON and output 1. In the next scan period to scan normally close contact Y1, Y1 normally close contact will be open due to Y1 is ON. Finally, coil Y1 will be OFF. The result of repeated scan, coil Y will output the vibrating pulse with cycle time \triangle T(On)+ \triangle T(Off).

The vibrating circuitry of cycle time $\triangle T(On) + \triangle T(Off)$:




The figure above uses timer T0 to control coil Y1 to be ON. After Y1 is ON, timer T0 will be closed at the next scan period and output Y1. The oscillating circuit will be shown as above. (n is the setting of timer and it is decimal number. T is the base of timer. (clock period))

Example 8: Blinking Circuit




The figure above is common used oscillating circuit for indication light blinks or buzzer alarms. It uses two timers to control On/OFF time of Y1 coil. If figure, n1 and n2 are timer setting of T1 and T2. T is the base of timer (clock period)

Example 9: Triggered Circuit



In figure above, the rising-edge differential command of X0 will make coil M0 to have a single pulse of ΔT (a scan time). Y1 will be ON during this scan time. In the next scan time, coil M0 will be OFF, normally close M0 and normally close Y1 are all closed. However, coil Y1 will keep on being ON and it will make coil Y1 to be OFF once a rising-edge comes after input X0 and coil M0 is ON for a scan time. The timing chart is as shown above. This circuit usually executes alternate two actions with an input. From above timing: when input X0 is a square wave of a period T, output coil Y1 is square wave of a period 2T.


Example 10: Delay Circuit




When input X0 is ON, output coil Y1 will be ON at the same time due to the corresponding normally close contact OFF makes timer T10 to be OFF. Output coil Y1 will be OFF after delaying 100 seconds (K1000*0.1 seconds = 100 seconds) once input X0 is OFF and T10 is ON. Please refer to timing chart above.

Example 11: Output delay circuit


In the following example, the circuit is made up of two timers. No matter input X0 is ON or OFF, output Y4 will be delay.



Example12: Extend Timer Circuit



In this circuit, the total delay time from input X0 is close and output Y1 is $ON=(n1+n2)^* T$. where T is clock period.



D.4 PLC Devices

D.4.1 Summary of DVP-PLC Device Number

Items			Items	Specifications		Remarks
		Stored program, cyclic scan system				
I/O F	Proce	essing Mo	ethod	Batch processing (who instruction is executed		I/O refresh instruction is available
Exec	cutio	n Speed		Basic commands (mir 0.24 us)	nimum	Application commands (10 ~ hundreds us)
Prog	ıram	Languag	ge	Instruction, Ladder Lo	gic, SFC	Including the Step commands
Prog	ram	Capacity	/	500 STEPS		SRAM + Battery
Inpu	Input/Output Contact		Digital Input (X): 6, Digital output (Y): 2, Analog input AI:2, Analog output AO:1			
	Х	External	xternal Input Relay X0~X17, 16 points, octal number system Total is		Total is	Correspond to external input point
	Υ	External	Output Relay	Y0~Y17, 16 points, octal number system	32 points	Correspond to external output point
	N4	Auvilion	For general	M0~M159, 160 points	Total is	Contacts can switch to
ode	M	Auxiliary	For special	M1000~M1031, 32 points	192 points	On/Off in program
Relay bit mode	Т	Timer	100ms timer	T0~T15, 16 points	Total is 16 points	When the timer indicated by TMR command attains the setting, the T contact with the same number will be On.
	С	Counter	16-bit count up for general	C0~C7, 8 points	Total is 8 points	When the counter indicated by CNT command attains the setting, the C contact with the same number will be On.

	Items			ns	Specifications	3	Remarks
				oit count up/down n-speed counter	C235, 1 point (need to use with PG card) (Use with DHSCS+M1018+M1 028~M1030)	Total is 1 point	If the counter reaches the goal assigned by DHSCS, the contact will be ON
	T Present value of timer		T0~T15, 16 points		When timer attains, the contact of timer will be On.		
data	С	Present value of counter		e of counter	C0~C7, 8-bit counter, 8 points		When timer attains, the contact of timer will be On.
				For latched	D0~D9, 10 points	.	
ı. W	D	Data		For general	D10~D29, 20 points	Total is	It can be memory area
Register WORD		register		For special	D1000~D1044, 45 points	points	for storing data.
ant	K	Decimal			K-32,768 ~ K32,767		
Constant	Н	H Hexadecimal		H0000 ~ HFFFF			
	Communication port (for read/write program)		RS485 (slave)				
Anal	og ir	nput/outp	ut		Built-in 2 analog inputs and 1 analog output		
Func	Function extension module (optional)		Digital input/output card (A/D, D/A card)				


D.4.2 Devices Functions

■ The Function of Input/output Contacts

The function of input contact X: input contact X reads input signal and enter PLC by connecting with input equipment. It is unlimited usage times for A contact or B contact of each input contact X in program. The On/Off of input contact X can be changed with the On/Off of input equipment but can't be changed by using peripheral equipment (WPLSoft).

The Function of Output Contact Y

The mission of output contact Y is to drive the load that connects to output contact Y by sending On/Off signal. There are two kinds of output contact: one is relay and the other is transistor. It is unlimited usage times for A or B contact of each output contact Y in program. But there is number for output coil Y and it is recommended to use one time in program. Otherwise, the output result will be decided by the circuit of last output Y with PLC program scan method.



The output of Y0 will be decided by circuit (2), i.e. decided by On/Off of X10.

D.4.3 Value, Constant [K] / [H]

Constant	К	Decimal	K-32,768 ~ K32,767
Constant	Ι	Hexadecimal	H0000 ~ HFFFF

There are five value types for DVP-PLC to use by the different control destination. The following is the explanation of value types.

1. Binary Number (BIN)

It uses binary system for the PLC internal operation or storage. The relative information of binary system is in the following.

Bit : Bit is the basic unit of binary system, the status are 1 or 0.

Nibble : It is made up of continuous 4 bits, such as b3~b0. It can be used to represent

number 0~9 of decimal or 0~F of hexadecimal.

Byte : It is made up of continuous 2 nibbles, i.e. 8 bits, b7~b0. It can used to represent

00~FF of hexadecimal system.


Word : It is made up of continuous 2 bytes, i.e. 16 bits, b15~b0. It can used to represent

0000~FFFF of hexadecimal system.

Double : It is made up of continuous 2 words, i.e. 32 bits, b31~b0. It can used to

Word represent 00000000~FFFFFFF of hexadecimal system.

The relations among bit, nibble, byte, word, and double word of binary number are shown as follows.



2. Octal Number (OCT)

The numbers of external input and output terminal of DVP-PLC use octal number.

Example:

External input: X0~X7, X10~X17···(device number)

External output: Y0~Y7, Y10~Y17···(device number)

3. Decimal Number (DEC)

The suitable time for decimal number to use in DVP-PLC system.

- To be the setting value of timer T or counter C, such as TMR C0 K50. (K constant)
- To be the device number of M, T, C and D. For example: M10, T3. (device number)
- To be operand in application command, such as MOV K123 D0. (K constant)
- 4. BCD (Binary Code Decimal, BCD)

It shows a decimal number by a unit number or four bits so continuous 16 bits can use to represent the four numbers of decimal number. BCD code is usually used to read the input value of DIP switch or output value to 7-segment display to be display.

5. Hexadecimal Number (HEX)

The suitable time for hexadecimal number to use in DVP-PLC system.

■ To be operand in application command. For example: MOV H1A2B D0. (constant H) Constant K:

In PLC, it is usually have K before constant to mean decimal number. For example, K100 means 100 in decimal number.

Exception:

The value that is made up of K and bit equipment X, Y, M will be bit, byte, word or double word. For example, K2Y10, K4M100. K1 means a 4-bit data and K2~K4 can be 8, 12 and 16-bit data separately.

Constant H:

In PLC, it is usually have H before constant to mean hexadecimal number. For example, H100 means 100 in hexadecimal number.

D.4.4 The Function of Auxiliary Relay

There are output coil and A, B contacts in auxiliary relay M and output relay Y. It is unlimited usage times in program. User can control loop by using auxiliary relay, but can't drive external load directly. There are two types divided by its characteristics.

1. Auxiliary relay for general: It will reset to Off when power loss during running. Its state will be Off when power on after power loss.

2. Auxiliary relay for special : Each special auxiliary relay has its special function. Please don't use undefined auxiliary relay.

D.4.5 The Function of Timer

The unit of timer is 100ms. The count method is count up. The output coil will be On when the present value of timer equals to the settings. The setting is K in decimal number. Data register D can be also used as settings.

The real setting time of timer = unit of timer * settings

D.4.6 The Features and Functions of Counter

Features:

Item	16 bits counters	32 bits counters		
Туре	General	High speed		
Count direction	Count up	Count up/down		
Settings	0~32,767	-2,147,483,648~-	+2,147,483,647	
Designate for constant	Constant K or data register D	Constant K or data register D (2 for designated)		
Present value change	Counter will stop when attaining settings	Counter will keep on counting when attaining settings		
Output contact	When count attains settings, contact will be On and latched.	When count up attains settings, contact will be On and latched. When count down attains settings, contact will reset to Off.		
Reset action	The present value will reset to will reset to Off.	o 0 when RST command is executed and contact		
Present register	16 bits	32 bits		
Contact action	After scanning, act together.	After scanning, act together.	Act immediately when count attains. It has no relation with scan period.	

Functions:

When pulse input signal of counter is from Off to On, the present value of counter equals to settings and output coil is On. Settings are decimal system and data register D can also be used as settings. 16-bit counters C0~C7:

- 1. Setting range of 16-bit counter is K0~K32,767. (K0 is the same as K1. output contact will be On immediately at the first count.
- General counter will be clear when PLC is power loss. If counter is latched, it will
 remember the value before power loss and keep on counting when power on after power
 loss.
- 3. If using MOV command or WPLSoft to send a value, which is large than setting to C0, register, at the next time that X1 is from Off to On, C0 counter contact will be On and present value will be set to the same as settings.
- 4. The setting of counter can use constant K or register D (not includes special data register D1000~D1044) to be indirect setting.
- 5. If using constant K to be setting, it can only be positive number but if setting is data register D, it can be positive/negative number. The next number that counter counts up from 32,767 is -32,768.

Example:

LD X0

RST C0


LD X1


CNT C0 K5

LD C0

OUT Y0

- When X0=On, RST command is executed, C0 reset to 0 and output contact reset to Off.
- 2. When X1 is from Off to On, counter will count up (add 1).
- 3. When counter C0 attains settings K5, C0 contact is On and C0 = setting =K5. C0 won't accept X1 trigger signal and C0 remains K5.





32-bit high-speed up/down counter C235:

- Setting range of 32-bit high-speed up/down counter is:
 K-2,147,483,648~K2,147,483,647.
- 2. The settings can be positive / negative numbers by using constant K or data register D (special data register D1000~D1044 is not included). If using data register D, the setting will occupy two continuous data register.

The total band width of high-speed counter that VFD-E supports is up to 30kHz and 500kHz for pulse input.

D.4.7 Register Types

There are two types of register which sorts by characters in the following:

1. General : The data in register will be cleared to 0 when PLC switches from RUN register to STOP or power is off.

2. Special : Each special register has the special definition and purpose. It is used register to save system status, error messages, monitor state.

D.4.8 Special Auxiliary Relays

Special M	Function	Read(R)/ Write(W)
M1000	Normally open contact (a contact). This contact is On when running and it is On when the status is set to RUN.	R
M1001	Normally closed contact (b contact). This contact is Off in running and it is Off when the status is set to RUN.	R
M1002	On only for 1 scan after RUN. Initial pulse is contact a. It will get positive pulse in the RUN moment. Pulse width=scan period.	R
M1003	Off only for 1 scan after RUN. Initial pulse is contact a. It will get negative pulse in the RUN moment. Pulse width=scan period.	R
M1004	-	
M1005	Fault indication of the AC motor drives	R
M1006	Output frequency is 0	R
M1007	The operation direction of AC motor drives (FWD: 0, REV: 1)	R
M1008		
M1009		
M1010		
M1011	10ms clock pulse, 5ms On/5ms Off	R
M1012	100ms clock pulse, 50ms On / 50ms Off	R
M1013	1s clock pulse, 0.5s On / 0.5s Off	R
M1014	1min clock pulse, 30s On / 30s Off	R
M1015	Frequency attained	R
M1016	Parameter read/write error	R
M1017	Succeed to write parameter	R
M1018	Enable high-speed counter function (When M1028=On)	R
M1019		
M1020	Zero flag	R
M1021	Borrow flag	R
M1022	Carry flag	R
M1023	Divisor is 0	R
M1024		
M1025	RUN(ON) / STOP(OFF) the AC motor drive	R/W

Special M	Function	Read(R)/ Write(W)
M1026	Setting operation direction of the AC motor drive (0: FWD, 1:REV)	R/W
M1027	Trigger motor drive reset	R/W
M1028	Enable(ON)/disable(OFF) high-speed counter function	R/W
M1029	Clear the value of high-speed counter	R/W
M1030	Decide to count up(OFF)/count down(ON)	R/W
M1031	Enforce setting current integral value of PID equal to D1019 (activate from 0 to 1)	R/W

D.4.9 Special Registers

Special D	Function	Read(R)/ Write(W)
D1000		
D1001	PLC firmware version	R
D1002	Program capacity	R
D1003	Checksum	R
D1004- D1009	Reserved	
D1010	Present scan time (Unit: 0.1ms)	R
D1011	Minimum scan time (Unit: 0.1ms)	R
D1012	Maximum scan time (Unit: 0.1ms)	R
D1013- D1017		
D1018	Current integral value	R
D1019	Enforce setting I integral value of PID	R/W
D1020	Output frequency(0.00~600.00Hz)	R
D1021	Output current (####.#A)	R
D1022	The ID of the extension card: 02 USB Card (CME-USB01) 03 12-Bit A/D (2CH) 12-Bit D/A (2CH) (EME-A22A) 04 Relay Card-2C (EME-R2CA) 05 Relay Card-3A (EME-R3AA) 06 3IN/3OUT Card (EME-D33A) 07 PG Card (EME-PG01) 08 6IN 110VAC card (EME-D611A) 09 AUI & 3OUT (EME-A1D3A)	R
D1023- D1024	Reserved	
D1025	The present value of the high-speed counter C235 (low byte)	R
D1026	The present value of the high-speed counter C235 (high byte)	R
D1027	Frequency command of the PID control	R
D1028	The value of AVI (analog voltage input) 0-10V corresponds to 0-1023	R

Special D	Function	Read(R)/ Write(W)
D1029	The value of ACI (analog current input) 4-20mA corresponds to 0-1023 or the value of AVI2 (analog voltage input) 0-10V corresponds to 0-1023	R
D1030	The value of V.R digital keypad 0-10V corresponds to 0-1023	R
D1031	Extension card Al1 analog input: 0~10V or 0~20mA correspond to (0~4095)	R
D1032	Extension card Al2 analog input: 0~10V or 0~20mA correspond to (0~4095)	R
D1033- D1035		
D1036	Motor Drive error code	R
D1037- D1039		
D1040	AFM analog output value	R/W
D1041	Extension card AO1 analog output: 0~10V or 0~20mA correspond to (0~65535)	R/W
D1042	Extension card AO2 analog output: 0~10V or 0~20mA correspond to (0~65535)	R/W
D1043	User defined (when Pr.00.04 is set to 2, the register data will be displayed as C xxx)	R/W
D1044	High-speed counter mode	R/W

D.4.10 Communication Addresses for Devices (only for PLC2 mode)

Device	Range	Туре	Address (Hex)
X	00–17 (octal)	Bit	0400-040F
Υ	00–17 (octal)	Bit	0500-050F
Т	00-15	Bit/word	0600-060F
М	000-159	Bit	0800-089F
М	1000-1031	Bit	0BE8-0C07
С	0-7	Bit/word	0E00-0E07
D	00-29	Word	1000-101D
D	1000-1044	Word	13E8-1414

D.4.11 Function Code (only for PLC2 mode)

Function Code	Description	Supported Devices
H1	Read coil status	Y, M, T, C
H2	Read input status	X, Y, M, T, C
H3	Read one data	T, C, D
H5	Force changing one coil status	Y, M, T, C
H6	Write in one data	T, C, D
HF	Force changing multiple coil status	Y, M, T, C
H10	Write in multiple data	T, C, D

NOTE:

In PLC1 mode, the Modbus communication will correspond to the registers of motor drive. In PLC2 mode, the Modbus communication will correspond to the registers of internal PLC.

For example:

In PLC1 mode, communication register 0400H corresponds to parameter 04.00.

In PLC2 mode, communication register 0400H corresponds to X0.

D.5 Commands

D.5.1 Basic Commands

Commands	Function	Operands	processing Speed(us)
LD	Load contact A	X, Y, M, T, C	10
LDI	Load contact B	X, Y, M, T, C	10
AND	Series connection with A contact	X, Y, M, T, C	10
ANI	Series connection with B contact	X, Y, M, T, C	10
OR	Parallel connection with A contact	X, Y, M, T, C	10
ORI	Parallel connection with B contact	X, Y, M, T, C	10
ANB	Series connects the circuit block		4
ORB	Parallel connects the circuit block		4
MPS	Save the operation result		4
MRD	Read the operation result (the pointer not moving)		4
MPP	Read the result		4
INV	Inverter the result		4

D.5.2 Output Commands

Commands	Function	Operands	processing Speed(us)
OUT	Drive coil	Y, M	14
SET	Action latched (ON)	Y, M	14
RST	Clear the contacts or the registers	Y, M, T, C, D	18

D.5.3 Timer and Counters

Commands	Function	Operands	processing Speed(us)
TMR	16-bit timer	T-K or T-D	32
CNT	16-bit counter	C-K or C-D	37

D.5.4 Main Control Commands

Commands	Function	Operands
MC	Connect the common series connection contacts	N0~N7
MCR	Disconnect the common series connection contacts	N0~N7

D.5.5 Rising-edge/falling-edge Detection Commands of Contact

Commands	Function	Operands
LDP	Rising-edge detection operation starts	X, Y, M, T, C
LDF	Falling-edge detection operation starts	X, Y, M, T, C
ANDP	Rising-edge detection series connection	X, Y, M, T, C
ANDF	Falling-edge detection series connection	X, Y, M, T, C
ORP	Rising-edge detection parallel connection	X, Y, M, T, C
ORF	Falling-edge detection parallel connection	X, Y, M, T, C

D.5.6 Rising-edge/falling-edge Output Commands

Commands	Function	Operands
PLS	Rising-edge output	Y, M
PLF	Falling-edge output	Y, M

D.5.7 End Command

Command	Function	Operands
END	Program end	none

D.5.8 Explanation for the Commands

Mnemonic	Function					
LD		Load A contact				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	✓	✓	✓	

Explanations:

The LD command is used on the A contact that has its start from the left BUS or the A contact that is the start of a contact circuit. Function of the command is to save present contents, and at the same time, save the acquired contact status into the accumulative register.

Program Example:

Ladder diagram	Command code		Operation	
X0 X1	LD	Х0	Load contact A of X0	
HHH Y1	AND	X1	Connect to contact A of X1 in series	
	OUT	Y1	Drive Y1 coil	


Mnemonic	Function					
LDI		Load B contact				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	√	✓	✓	✓	✓	

Explanations:

The LDI command is used on the B contact that has its start from the left BUS or the B contact that is the start of a contact circuit. Function of the command is to save present contents, and at the same time, save the acquired contact status into the accumulative register.

Program Example:

Ladder diagram: Command code: Operation:



Mnemonic Function

AND	Series connection- A contact					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	✓	✓	✓	

The AND command is used in the series connection of A contact. The function of the command is to readout the status of present specific series connection contacts first, and then to perform the "AND" calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

Program Example:

Ladder diagram:

X1 X0 Y1

Command code: Operation:

LDI X1 Load contact B of X1

AND X0 Connect to contact A of X0 in series

OUT Y1 Drive Y1 coil

Mnemonic	Function					
ANI	Series connection- B contact					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	✓	✓	✓	

Explanations:

The ANI command is used in the series connection of B contact. The function of the command is to readout the status of present specific series connection contacts first, and then to perform the "AND" calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

Program Example:


Command code: Ladder diagram: Operation: LD X1 Load contact A of X1 X1 X0 Y1 **ANI X0** Connect to contact B of X0 in series Y1 Drive Y1 coil OUT

Mnemonic	Function
OR	Parallel connection- A contact

Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	✓	✓	✓	

The OR command is used in the parallel connection of A contact. The function of the command is to readout the status of present specific series connection contacts, and then to perform the "OR" calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

Program Example:




Mnemonic	Function					
ORI	Parallel connection- B contact					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	√	✓	✓	

Explanations:

The ORI command is used in the parallel connection of B contact. The function of the command is to readout the status of present specific series connection contacts, and then to perform the "OR" calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

Program Example:




Mnemonic	Function
ANB	Series connection (Multiple Circuits)

Operand	None
---------	------

To perform the "ANB" calculation between the previous reserved logic results and contents of the accumulative register.

Program Example:




Mnemonic	Function
ORB	Parallel connection (Multiple circuits)
Operand	None

Explanations:

To perform the "OR" calculation between the previous reserved logic results and contents of the accumulative register.

Program Example:



Mnemonic	Function		
MPS	Store the current result of the internal PLC operations		
Operand	None		

To save contents of the accumulative register into the operation result. (the result operation pointer pluses 1)

Mnemonic	Function		
MRD	Reads the current result of the internal PLC operations		
Operand	None		

Explanations:

Reading content of the operation result to the accumulative register. (the pointer of operation result doesn't move)


Mnemonic	Function		
MPP	Reads the current result of the internal PLC operations		
Operand	None		

Explanations:

Reading content of the operation result to the accumulative register. (the stack pointer will decrease 1)

Program Example:

Ladder diagram:



Command code: Operation:

LD	X0	Load contact A of X0
MPS		Save in stack
AND	X1	Connect to contact A of X1 in series
OUT	Y1	Drive Y1 coil
MRD		Read from the stack (without moving pointer)
AND	X2	Connect to contact A of X2 in series
OUT	M0	Drive M0 coil
MPP		Read from the stack
OUT	Y2	Drive Y2 coil
END		End program

Mnemonic	Function		
INV	Inverting Operation		
Operand	None		

Explanations:

Inverting the operation result and use the new data as an operation result.

Program Example:

Ladder diagram:

Command code: Operation:



LD X0 Load A contact of X0

INV Inverting the operation result

OUT Y1 Drive Y1 coil

Mnemonic	Function					
OUT	Output coil					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
		✓	✓			

Explanations:

Output the logic calculation result before the OUT command to specific device.

Motion of coil contact

		OUT command		
Operation	Coil	C	Contact	
result	Coll	A contact (normally open)	B contact (normally closed)	
FALSE	OFF	Non-continuity	Continuity	
TRUE	ON	Continuity	Non-continuity	

Program Example:

Ladder diagram:

Command code: Operation:



LDI X0 Load contact B of X0

AND X1 Connect to contact A of X1 in

series


OUT Y1 Drive Y1 coil

Mnemonic	Function					
SET		Latch (ON)				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
		✓	✓			

Explanations:

When the SET command is driven, its specific device is set to be "ON," which will keep "ON" whether the SET command is still driven. You can use the RST command to set the device to "OFF".

Program Example:




Mnemonic	Function					
RST	Clear the contacts or the registers					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
		✓	✓	✓	✓	

Explanations:

When the RST command is driven, motion of its specific device is as follows:

Device	Status
Y, M	Coil and contact will be set to "OFF".
T, C	Present values of the timer or counter will be set to 0, and the coil and contact will be set to "OFF."
D	The content value will be set to 0.

Program Example:



Mnemonic	Function		
TMR	16-bit timer		
Operand	T-K	T0~T15, K0~K32,767	
	T-D	T0~T15, D0~D29	

Explanations:

When TMR command is executed, the specific coil of timer is ON and timer will start to count. When the setting value of timer is attained (counting value >= setting value), the contact will be as following:

NO(Normally Open) contact	Close
NC(Normally Closed) contact	Open

Program Example:

Ladder diagram: Command code: Operation:



Mnemonic	Function		
CNT	16-bit counter		
Operand	C-K	C0~C7, K0~K32,767	
	C-D	C0~C7, D0~D29	

Explanations:


1. When the CNT command is executed from OFF→ON, which means that the counter coil is driven, and 1 should thus be added to the counter's value; when the counter achieved specific set value (value of counter = the setting value), motion of the contact is as follows:

NO(Normally Open) contact	Close
NC(Normally Closed) contact	Open

2. If there is counting pulse input after counting is attained, the contacts and the counting values will be unchanged. To re-count or to conduct the CLEAR motion, please use the RST command.

Program Example:

Ladder diagram: Command code: Operation:



Mnemonic	Function	
MC / MCR	Master control Start/Reset	
Operand	N0~N7	

Explanations:

MC is the main-control start command. When the MC command is executed, the
execution of commands between MC and MCR will not be interrupted. When MC
command is OFF, the motion of the commands that between MC and MCR is described


as follows:

Timer	The counting value is set back to zero, the coil and the contact are both turned OFF
Accumulative timer	The coil is OFF, and the timer value and the contact stay at their present condition
Subroutine timer	The counting value is back to zero. Both coil and contact are turned OFF.
Counter	The coil is OFF, and the counting value and the contact stay at their present condition
Coils driven up by the OUT command	All turned OFF
Devices driven up by the SET and RST commands	Stay at present condition
Application commands	All of them are not acted , but the nest loop FOR-NEXT command will still be executed for times defined by users even though the MC-MCR commands is OFF.

- 2. MCR is the main-control ending command that is placed at the end of the main-control program and there should not be any contact commands prior to the MCR command.
- 3. Commands of the MC-MCR main-control program supports the nest program structure, with 8 layers as its greatest. Please use the commands in order from N0~ N7, and refer to the following:

Program Example:

Ladder diagram:



Command code: Operation:

00111111	and code.	Operation.
LD	X0	Load A contact of X0
MC	N0	Enable N0 common series connection contact
LD	X1	Load A contact of X1
OUT :	Y0	Drive Y0 coil
LD	X2	Load A contact of X2
MC	N1	Enable N1 common series connection contact
LD	X3	Load A contact of X3
OUT	Y1	Drive Y1 coil
:		
MCR	N1	Disable N1 common series connection contact
:		
MCR	N0	Disable N0 common series connection contact
:		
LD	X10	Load A contact of X10
MC	N0	Enable N0 common series connection contact
LD	X11	Load A contact of X11
OUT	Y10	Drive Y10 coil
:		

Disable N0 common series

connection contact

MCR


N0

Mnemonic	Function					
LDP	Rising-edge detection operation					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
	✓	✓	✓	✓	✓	1

Usage of the LDP command is the same as the LD command, but the motion is different. It is used to reserve present contents and at the same time, saving the detection status of the acquired contact rising-edge into the accumulative register.

Program Example:

Ladder diagram:



Command code: Operation:

LDP	X0	Start X0 rising-edge detection
AND	X1	Series connection A contact of X1
OUT	Y1	Drive Y1 coil


Mnemonic	Function					
LDF	Falling-edge detection operation					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
	✓	✓	✓	✓	✓	

Explanations:

Usage of the LDF command is the same as the LD command, but the motion is different. It is used to reserve present contents and at the same time, saving the detection status of the acquired contact falling-edge into the accumulative register.

Program Example:

Ladder diagram:





Mnemonic	Function					
ANDP	Rising-edge series connection					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
	✓	✓	✓	✓	✓	

ANDP command is used in the series connection of the contacts' rising-edge detection.

Program Example:

Ladder diagram: Command code: Operation:




Mnemonic	Function					
ANDF		Falling-edge series connection				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
	✓	✓	✓	✓	✓	

Explanations:

ANDF command is used in the series connection of the contacts' falling-edge detection.

Program Example:

Ladder diagram: Command code: Operation:




Mnemonic	Function					
ORP		Rising-edge parallel connection				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
	✓	✓	✓	✓	✓	


Explanations:

The ORP commands are used in the parallel connection of the contact's rising-edge detection.

Program Example:

Ladder diagram:





LD X0 Load A contact of X0

ORP X1 X1 rising-edge detection in parallel

connection

OUT Y1 Drive Y1 coil

Mnemonic	Function										
ORF	Falling-edge parallel connection										
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29					
Орегана	✓	✓	✓	✓	✓						


Explanations:

The ORP commands are used in the parallel connection of the contact's falling-edge detection.

Program Example:

Ladder diagram:

Command code: Operation:



LD X0 Load A contact of X0

ORF X1 X1 falling-edge detection in parallel

connection

OUT Y1 Drive Y1 coil

Mnemonic	Function										
PLS	Rising-edge output										
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29					
Operand		✓	✓								

Explanations:

When X0=OFF→ON (rising-edge trigger), PLS command will be executed and M0 will send the pulse of one time which the length is a scan time.

Program Example:

Ladder diagram:


Command code: Operation:

X0			LD	X0	Load A contact of X0		
M0	PLS	M0	PLS	МО	M0 rising-edge output		
	SET	Y0	LD	MO	Load the contact A of M0		

Timing Diagram:

SET Y0

Y0 latched (ON)




Mnemonic	Function											
PLF	Falling-edge output											
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29						
Орегани		✓	✓		-							

Explanations:

When X0= $ON \rightarrow OFF$ (falling-edge trigger), PLF command will be executed and M0 will send the pulse of one time which the length is the time for scan one time.

Program Example:


Ladder diagram:



Command code: Operation:

LD	X0	Load A contact of X0
PLF	MO	M0 falling-edge output
LD	MO	Load the contact A of M0
SET	Y0	Y0 latched (ON)

Timing Diagram:



Mnemonic	Function
END	Program End
Operand	None

Explanations:

It needs to add the END command at the end of ladder diagram program or command program. PLC will scan from address o to END command, after executing it will return to address 0 to scan again.

D.5.9 Description of the Application Commands

	API	_	monic	P	Function	St	eps
		16 bits	32 bits	Command		16-bit	32-bit
	10	СМР		✓	Compare	7	
Transmission	11	ZCP		✓	Zone compare	9	
Comparison	12	MOV		✓	Data Move	5	
	15	BMOV		✓	Block move	7	
	20	ADD		√	Perform the addition of BIN data	7	
	21	SUB		√	Perform the subtraction of BIN data	7	
Four Fundamental	22	MUL		√	Perform the multiplication of BIN data	7	
Operations of Arithmetic	23	DIV		√	Perform the division of BIN data	7	
	24	INC		√	Perform the addition of 1	3	
	25	DEC		√	Perform the subtraction of 1	3	
Rotation and	30	ROR		✓	Rotate to the right	5	
Displacement	31	ROL		√	Rotate to the left	5	
	53		DHSCS	X	High speed counter enable		13
Special command for	139	RPR		√	Control PID parameters of inverter	5	
AC motor drive	140	WPR		√	Control frequency of inverter	5	
	141	FPID		✓	Read the parameter	9	
	142	FREQ		✓	Write the parameter	7	

D.5.10 Explanation for the Application Commands

API	Mnemon	ic	Operands	Function
10	CMP	Р	S ₁ , S ₂ , D	Compare

Type	Bit	Devi	ces		Word devices							Program Steps
ОР	Х	Υ	М	K	Η	KnX	KnY	KnM	Т	С	D	CMP, CMPP: 7 steps
S ₁				*	*	*	*	*	*	*	*	
S ₂				*	*	*	*	*	*	*	*	
D		*	*									

Operands:

S1: Comparison Value 1 S2: Comparison Value 2 D: Comparison result Explanations:

- 1. Operand D occupies 3 consecutive devices.
- 2. See the specifications of each model for their range of use.
- 3. The contents in S1 and S2 are compared and the result will be stored in D.
- 4. The two comparison values are compared algebraically and the two values are signed binary values. When b15 = 1 in 16-bit instruction, the comparison will regard the value as negative binary values.

Program Example:

- 1. Designate device Y0, and operand D automatically occupies Y0, Y1, and Y2.
- 2. When X10 = On, CMP instruction will be executed and one of Y0, Y1, and Y2 will be On. When X10 = Off, CMP instruction will not be executed and Y0, Y1, and Y2 remain their status before X10 = Off.
- 3. If the user need to obtain a comparison result with $\geq \leq$, and \neq , make a series parallel connection between Y0 ~ Y2.

```
X10

Y0

If K10>D10

Y0


Y1

If K10=D10, Y1 = On

Y2

If K10<D10, Y2=On
```

4. To clear the comparison result, use RST instruction.



API	Mnemon	ic	Operands	Function				
11	ZCP	Р	S ₁ , S ₂ , S, D	Zone Compare				

Туре	Bit	Devi	ces		Word devices							Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ZCP, ZCPP: 9 steps
S ₁				*	*	*	*	*	*	*	*	
S ₂				*	*	*	*	*	*	*	*	
S				*	*	*	*	*	*	*	*	
D		*	*									

S1: Lower bound of zone comparison S2: Upper bound of zone comparison S: Comparison value D: Comparison result

Explanations:

- 1. The content in S1 should be smaller than the content in S2.
- 2. Operand D occupies 3 consecutive devices.
- 3. See the specifications of each model for their range of use.
- 4. S is compared with its S1 S2 and the result is stored in D.
- 5. When S1 > S2, the instruction performs comparison by using S1 as the lower/upper bound.
- 6. The two comparison values are compared algebraically and the two values are signed binary values. When b15 = 1 in 16-bit instruction or b31 = 1 in 32-bit instruction, the comparison will regard the value as negative binary values.

Program Example:

- 1. Designate device M0, and operand D automatically occupies M0, M1 and M2.
- 2. When X0 = On, ZCP instruction will be executed and one of M0, M1, and M2 will be On. When X0 = Off, ZCP instruction will not be executed and M0, M1, and M2 remain their status before X0 = Off.

```
X0
ZCP
K10
K100
C10
M0
M0
If
C10 < K10, M0 = On
M1
If
K10 \le C10 \le K100, M1 = On
M2
If
C10 > K100, M2 = On
```

3. To clear the comparison result, use RST instruction.

API	Mnemon	ic	Operands	Function				
12	MOV	Р	S, D	Move				

Type	Type Bit Devices					W	ord de	vices				Program Steps
ОР	X	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	MOV, MOVP: 5 steps
S				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	

S: Source of data D: Destination of data Explanations:

- 1. See the specifications of each model for their range of use.
- 2. When this instruction is executed, the content of S will be moved directly to D. When this instruction is not executed, the content of D remains unchanged.

Program Example:

MOV instruction has to be adopted in the moving of 16-bit data.

- When X0 = Off, the content in D10 will remain unchanged. If X0 = On, the value K10 will be moved to D10 data register.
- 2. When X1 = Off, the content in D10 will remain unchanged. If X1 = On, the present value T0 will be moved to D10 data register.

API	Mnemon	ic	Operands	Function
15	BMOV	Р	S, D, n	Block Move

Туре	Bit Devices					W	ord de	vices				Program Steps
ОР	X	Υ	М	K	Ι	KnX	KnY	KnM	Т	C	D	BMOV, BMOVP: 7 steps
S						*	*	*	*	*	*	
D							*	*	*	*	*	
n				*	*				*	*	*	

Operands:


S: Start of source devices D: Start of destination devices n: Number of data to be moved Explanations:

1. Range of **n**: 1 ~ 512

- 2. See the specifications of each model for their range of use.
- 3. The contents in n registers starting from the device designated by S will be moved to n registers starting from the device designated by D. If n exceeds the actual number of available source devices, only the devices that fall within the valid range will be used.


Program Example 1:

When X10 = On, the contents in registers D0 ~ D3 will be moved to the 4 registers D20 ~ D23.



Program Example 2:

Assume the bit devices KnX, KnY, KnM and KnS are designated for moving, the number of digits of S and D has to be the same, i.e. their n has to be the same.



API	Mnemon	ic	Operands	Function
20	ADD	Р	S ₁ , S ₂ , D	Addition

Type	Bit Devices					W	ord de	vices	Program Steps			
ОР	X	Y	М	K	Η	KnX	KnY	KnM	Т	С	D	ADD, ADDP: 7 steps
S ₁				*	*	*	*	*	*	*	*	
S ₂				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	

S1: Summand S2: Addend D: Sum

Explanations:

- 1. See the specifications of each model for their range of use.
- 2. This instruction adds S1 and S2 in BIN format and store the result in D.
- 3. The highest bit is symbolic bit 0 (+) and 1 (-), which is suitable for algebraic addition, e.g. 3 + (-9) = -6.
- 4. Flag changes in binary addition

16-bit command:

- A. If the operation result = 0, zero flag M1020 = 0n.
- B. If the operation result < -32,768, borrow flag M1021 = On.
- C. If the operation result > 32,767, carry flag M1022 = On.

Program Example 1:


16-bit command:

When X0 = On, the content in D0 will plus the content in D10 and the sum will be stored in D20.



Remarks:

Flags and the positive/negative sign of the values:



API	Mnemon	ic	Operands	Function
21	SUB	Р	S ₁ , S ₂ , D	Subtraction

Туре	Bit Devices					W	ord de	vices				Program Steps
ОР	Χ	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	SUB, SUBP: 7 steps
S ₁				*	*	*	*	*	*	*	*	DSUB, DSUBP: 13 steps
S ₂				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	

S1: Minuend S2: Subtrahend D: Remainder

Explanations:

- 1. This instruction subtracts S1 and S2 in BIN format and stores the result in D.
- 2. The highest bit is symbolic bit 0 (+) and 1 (-), which is suitable for algebraic subtraction.
- 3. Flag changes in binary subtraction


In 16-bit instruction:

- A. If the operation result = 0, zero flag M1020 = 0n.
- B. If the operation result < -32,768, borrow flag M1021 = On.
- C. If the operation result > 32,767, carry flag M1022 = On.

Program Example:

In 16-bit BIN subtraction:

When X0 = On, the content in D0 will minus the content in D10 and the remainder will be stored in D20.




API	Mnemon	ic	Operands	Function
22	MUL	Р	S ₁ , S ₂ , D	Multiplication

Type	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \					W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	MUL, DMULP: 7 steps
S ₁				*	*	*	*	*	*	*	*	
S ₂				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	

S1: Multiplicand S2: Multiplicator D: Product

Explanations:

- 1. In 16-bit instruction, D occupies 2 consecutive devices.
- 2. This instruction multiplies S1 by S2 in BIN format and stores the result in D. Be careful with the positive/negative signs of S1, S2 and D when doing 16-bit and 32-bit operations. 16-bit command:



Symbol bit = 0 refers to a positive value. Symbol bit = 1 refers to a negative value.

When D serves as a bit device, it can designate K1 ~ K4 and construct a 16-bit result, occupying consecutive 2 groups of 16-bit data.

Program Example:

The 16-bit D0 is multiplied by the 16-bit D10 and brings forth a 32-bit product. The higher 16 bits are stored in D21 and the lower 16-bit are stored in D20. On/Off of the most left bit indicates the positive/negative status of the result value.




API	Mnemon	ic	Operands	Function
23	DIV	Р	S ₁ , S ₂ , D	Division

Туре	Bit Devices					W	ord de	vices				Program Steps
ОР	X	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	DIV, DIVP: 7 steps
S ₁				*	*	*	*	*	*	*	*	
S ₂				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	


 S_1 : Dividend S_2 : Divisor D: Quotient and remainder Explanations:

- 1. In 16-bit instruction, **D** occupies 2 consecutive devices.
- 2. This instruction divides S_1 and S_2 in BIN format and stores the result in D. Be careful with the positive/negative signs of S_1 , S_2 and D when doing 16-bit and 32-bit operations. 16-bit instruction:



Program Example:

When X0 = On, D0 will be divided by D10 and the quotient will be stored in D20 and remainder in D21. On/Off of the highest bit indicates the positive/negative status of the result value.



API	Mnemon	ic	Operands	Function
24	INC	Р	D	Increment

Туре	pe Bit Devices					W	ord de	vices				Program Steps
ОР	X	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	INC, INCP: 3 steps
D							*	*	*	*	*	


D: Destination device

Explanations:

- 1. If the instruction is not a pulse execution one, the content in the designated device D will plus "1" in every scan period whenever the instruction is executed.
- 2. This instruction adopts pulse execution instructions (INCP).
- 3. In 16-bit operation, 32,767 pluses 1 and obtains -32,768.

Program Example:

When X0 goes from Off to On, the content in D0 pluses 1 automatically.



API	Mnemon	ic	Operands	Function
25	DEC	Р	D	Decrement

Туре	Bit Devices					W	ord de	vices	Program Steps			
ОР	X	Υ	М	K	Η	KnX	KnY	KnM	Т	O	D	DEC, DECP: 3 steps
D							*	*	*	*	*	

Operands:

D: Destination

Explanations:

- 1. If the instruction is not a pulse execution one, the content in the designated device D will minus "1" in every scan period whenever the instruction is executed.
- 2. This instruction adopts pulse execution instructions (DECP).
- 3. In 16-bit operation, -32,768 minuses 1 and obtains 32,767.

Program Example:

When X0 goes from Off to On, the content in D0 minuses 1 automatically.


API	Mnemon	ic	Operands	Function
30	ROR	Р	D, n	Rotate to the Right

Туре	ype Bit Devices					W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Ι	KnX	KnY	KnM	Т	C	D	ROR, RORP: 5 steps
D							*	*	*	*	*	
n				*	*							

- D: Device to be rotated n: Number of bits to be rotated in 1 rotation Explanations:
 - 1. This instruction rotates the device content designated by **D** to the right for **n** bits.
 - 2. This instruction adopts pulse execution instructions (RORP).

Program Example:

When X0 goes from Off to On, the 16 bits (4 bits as a group) in D10 will rotate to the right, as shown in the figure below. The bit marked with $\frac{1}{2}$ will be sent to carry flag M1022.




API	Mnemon	ic	Operands	Function
31	ROL	Р	D, n	Rotate to the Left

Type	Bit Devices					W	ord de	vices	Program Steps			
ОР	Х	Υ	М	K	Η	KnX	KnY	KnM	Т	С	D	ROL, ROLP: 5 steps
D							*	*	*	*	*	
n				*	*							

- 1. This instruction rotates the device content designated by $\bf D$ to the left for $\bf n$ bits.
- 2. This instruction adopts pulse execution instructions (ROLP).

Program Example:

When X0 goes from Off to On, the 16 bits (4 bits as a group) in D10 will rotate to the left, as shown in the figure below. The bit marked with % will be sent to carry flag M1022.



D.5.11 Special Application Commands for the AC Motor Drive


API		Mnemon	ic	Operands	Function
53	D	HSCS		S1, S2, D	Compare (for high-speed counter)

Type	Bit Devices					W	ord de	vices				Program Steps
ОР	X	Υ	М	K	Η	KnX	KnY	KnM	Т	С	D	DHSCS: 13 steps
S1				*	*	*	*	*	*	*	*	
S2										*		
D		*	*									

Operands:

S1: Comparison Value S2: High-speed counter C235 D: Comparison result Explanations:


- 1. It needs optional PG card to receive external input pulse.
- 2. To count automatically, please set the target value by using DHSCS command and set M1028=On. The counter C235 will be ON when the count number = target value. If you want to clear C235, please set M1029=ON.
- 3. Please use rising-edge/falling-edge command, such as LDP/LDF, for the contact condition. Please notice that error may occur when using contact A/B for the contact condition. When M1028 is On, M1018 will be set ON after executing DHSCS command. In addition, M1029 can be sued to clear high speed counter, and M1018 will be cleared as Off after executing.
- 4. There are three input modes for high-speed counter in the following can be set by D1044.
- A-B phase mode(4 times frequency)(D1044=0): user can input the A and B pulse through A and B terminal of EME-PG01 for counting. Make sure that \overline{A} , \overline{B} and GND are grounding.



- Pulse + counting direction mode (D1044=1): user can use pulse input and counting direction to execute counting up or down or signal. A terminal of PG feedback card needs to be defined as pulse input, and B terminal as switching between counting up or down. Make sure that \overline{A} , \overline{B} and GND are grounding.
- Pulse + internal flag (M1030) mode (D1044=2): user can use pulse input and internal flag (M1030). A terminal of PG feedback card needs to be used for pulse input, and internal flag (M1030) is used for switching between counting up or down. Only A is needed for this mode and make sure that \overline{A} , and GND are grounding.

Program Example:

- Assume that when M100=ON, it is set to A-B phase mode. When M101=ON, it is set to Pulse + counting direction mode. When M102=ON, it is set to Pulse + internal flag (M1030) mode.
- 2. M1030 is used to set to count up (OFF) and count down (ON).
- 3. If M0 goes from OFF to ON, DHSCS command starts to execute the comparison of high-speed counter. When C235 goes from H'2 to H'3 or from H'4 to H'3, M3 will be always be ON.
- 4. If M1 goes from OFF to ON, DHSCS command starts to execute the comparison of high-speed counter. When C235 goes from H'1004F to H'10050 or from H'10051 to H'10050, M2 will be always be ON.
- 5. M1028: it is used to enable(ON)/disable(OFF) the high-speed counter function.
- 6. M1029: it is used to clear the high-speed counter.
- 7. M1018: it is used to start high-speed counter function. (when M1028 is ON).
- 8. D1025: the low word of high-speed counter C235.
- 9. D1026: the high word of high-speed counter C235.



API	Mnemon	ic	Operands	Function						
139	RPR	Р	S1, S2	Read the AC motor drive's parameters						

Туре	Bit Devices					W	ord de	vices	Program Steps			
ОР	Х	Υ	М	K	Η	KnX	KnY	KnM	Т	С	D	RPR, RPRP: 5 steps
S1				*	*						*	
S2											*	

S1: Data address for reading S2: Register that saves the read data


API	Mnemon	ic	Operands	Function						
140	WPR	Р	S1, S2	Write the AC motor drive's parameters						

Туре	Bit	Devi	ces			W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Η	KnX	KnY	KnM	Т	T C D		WPR, WPRP: 5 steps
S1				*	*						*	
S2				*	*			*				

Operands:

S1: Data address for writing S2: Register that saves the written data Program Example:

- 1. Assume that it will read the data from MODBUS address H2100, and then write to D0; read from H2101 and write to D0.
- 2. When M0=ON, it will write the data in D10 to the MODBUS address H2001 of the VFD-E.
- 3. When M1=ON, it will write the data in H2 to the MODBUS address H2000 of the VFD-E, i.e. start the AC motor drive.
- 4. When M2=ON, it will write the data in H1 to the MODBUS address H2000 of the VFD-E, i.e. stop the AC motor drive.
- 5. When data is written successfully, M1017 will be ON.
- 6. When writing parameters, the allowable times to revise a parameter is 10⁶ times. A memory write error may occur at EEPROM if parameters are written too often.



API	Mnemon			Function								
141	FPID	Р	S1, S2, S3, S4	PID control for the AC motor drive								

Туре	Bit	Devic	ces			W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Η	KnX	KnY	KnM	Т	С	D	FPID, FPIDP: 9 steps
S1				*	*						*	
S2				*	*						*	
S3				*	*						*	
S4				*	*						*	


S1: PID Set Point Selection(0-4), S2: Proportional gain P (0-100), S3: Integral Time I (0-1000), S4: Derivative control D (0-100)

Explanation:

 This command FPID can control the PID parameters of the AC motor drive directly, including Pr.10.00 PID set point selection, Pr.10.02 Proportional gain (P), Pr.10.03 Integral time (I) and Pr.10.04 Derivative control (D)

Program Example:

- 1. Assume that when M0=ON, S1 is set to 0 (PID function is disabled), S2=0, S3=1 (unit: 0.01 seconds) and S4=1 (unit: 0.01 seconds).
- 2. Assume that when M1=ON, S1 is set to 0 (PID function is disabled), S2=1 (unit: 0.01), S3=0 and S4=0.
- 3. Assume that when M2=ON, S1 is set to 1(frequency is inputted by digital keypad), S2=1 (unit: 0.01), S3=0 and S4=0.
- 4. D1027: frequency command controlled by PID.



API	Mnemon	ic	Operands	Function
142	FREQ	Р	S1, S2, S3	Speed control of the AC motor drive

Туре	Bit	Devi	ces			W	ord de	vices				Program Steps
ОР	Υ	М	K	H KnX		KnY	KnM	Τ	CD		FREQ, FREQP: 7 steps	
S1				*	*						*	
S2				*	*						*	
S3				*	*						*	

S1: frequency command, S2: acceleration time, S3: deceleration time

Explanation:


This command can control frequency command, acceleration time and deceleration time
of the AC motor drive. Please use M1025 to RUN(ON)/STOP(OFF) the AC motor drive
and use M1025 to control the operation direction: FWD(ON)/REV(OFF).

Program Example:

- M1025: RUN(ON)/STOP(Off) the AC motor drive. M1026: operation direction of the AC motor drive FWD(OFF)/REV(ON). M1015: frequency is reached.
- 2. When M10=ON, setting frequency command of the AC motor drive to K300(3.00Hz) and acceleration/deceleration time is 0.
- 3. When M11=ON, setting frequency command of the AC motor drive to K3000(30.00Hz), acceleration time is 50 and deceleration time is 60.
- 4. S2, S3: In the setting of Accel / Decel time, the decimal places are depends on the setting of Pr01.09. When Pr01.09=1, the unit is 0.01 unit.

As shown in the diagram below, S2(Accelerating time) = 50 which means 0.5sec .

S3(Decelerating time) = 60 which means 0.6sec.



D.6 Error Code

Code	ID	Description	Corrective Actions
PLod	20	When downloading PLC program the elements of the codes exceed its range, it will show Plod error. For example, the supportive range of T elements is T0~T15, when there is T16 in the syntax, it will show Plod error.	Check if the program is error and download the program again
PLSv	21	In executing PLC program, it will show PLSv error when PLC would like to write data to appointed address but found the address is unreasonable.	Check if the program is error and download the program again
PLdA	22	In executing PLC program, it will show PLdA error when external MODBUS read or write unreasonable elements to internal PLC.	Make sure the command from the host controller is correct.
PLFn	23	In downloading program, it will show PLFn error when it found the unsupportive command.	Make sure if WPL version is too old, and download the latest version from Delta website.
PLor	30	In executing PLC program, it will show PLor error when it found there is abnormal code inside the program.	Reset PLC program(set 6 in Pr00.02).Power on again and download program again
PLFF	31	It will show PLFF error when the corresponding command is unreasonable in executing PLC program.	When activating PLC function, it will show PLFF if there is no internal PLC program. It is normal status, and please download the program directly
PLSn	32	It will show PLSn error when finding check sum is error in executing PLC program	Reset PLC program(set 6 in Pr00.02).Power on again and download program again
PLEd	33	It will show PLEd error when finding there is no END command in the code in executing PLC program	Reset PLC program(set 6 in Pr00.02).Power on again and download program again
PLCr	34	The command MC is continuous used more than nine times	Check if the program is error and download the program again

*ID : Warning code

Appendix E: CANopen Function

The built-in CANopen function is a kind of remote control. Master can control the AC motor drive by using CANopen protocol. CANopen is a CAN-based higher layer protocol. It provides standardized communication objects, including real-time data (Process Data Objects, PDO), configuration data (Service Data Objects, SDO), and special functions (Time Stamp, Sync message, and Emergency message). And it also has network management data, including Boot-up message, NMT message, and Error Control message. Refer to CiA website http://www.can-cia.org/ for details. The content of this instruction sheet may be revised without prior notice. Please consult our distributors or download the most updated version at http://www.delta.com.tw/industrialautomation

Delta CANopen supports functions:

- Support CAN2.0A Protocol;
- Support CANopen DS301 V4.02;
- Support DSP-402 V2.0.

Delta CANopen supports services:

- PDO (Process Data Objects): PDO1~ PDO2
- SDO (Service Data Object):

Initiate SDO Download:

Initiate SDO Upload;

Abort SDO;

SDO message can be used to configure the slave node and access the Object Dictionary in every node.

■ SOP (Special Object Protocol):

Support default COB-ID in Predefined Master/Slave Connection Set in DS301 V4.02;

Support SYNC service;

Support Emergency service.

NMT (Network Management):

Support NMT module control;

Support NMT Error control;

Support Boot-up.


Delta CANopen doesn't support service:

Time Stamp service


E.1 Overview

E.1.1 CANopen Protocol

CANopen is a CAN-based higher layer protocol, and was designed for motion-oriented machine control networks, such as handling systems. Version 4 of CANopen (CiA DS301) is standardized as EN50325-4. The CANopen specifications cover application layer and communication profile (CiA DS301), as well as a framework for programmable devices (CiA 302), recommendations for cables and connectors (CiA 303-1) and SI units and prefix representations (CiA 303-2).



E.1.2 RJ-45 Pin Definition



plug

PIN	Signal	Description
1	CAN_H	CAN_H bus line (dominant high)
2	CAN_L	CAN_L bus line (dominant low)
3	CAN_GND	Ground / 0V /V-
4	SG-	485 communication
5	SG+	485 communication
6	GND	Ground
7	CAN_GND	Ground / 0V /V-
8	EV	Power

E.1.3 Pre-Defined Connection Set

To reduce configuration effort for simple networks, CANopen define a mandatory default identifier allocation scheme. The 11-bit identifier structure in predefined connection is set as follows:

	COB Identifier (CAN Identifier)													
10	9	8	7	6	5	4	3	2	1	0				
	Function Code Node Number													

Object	Function Code	Node Number	COB-ID	Object Dictionary Index										
Broadcast messag	Broadcast messages													
NMT	0000	-	0	-										
SYNC	0001	-	0x80	0x1005, 0x1006, 0x1007										
TIME STAMP	0010	-	0x100	0x1012, 0x1013										
Point-to-point mes	sages													
Emergency	0001	1-127	0x81-0xFF	0x1014, 0x1015										
TPDO1	0011	1-127	0x181-0x1FF	0x1800										
RPDO1	0100	1-127	0x201-0x27F	0x1400										
TPDO2	0101	1-127	0x281-0x2FF	0x1801										
RPDO2	0110	1-127	0x301-0x37F	0x1401										
TPDO3	0111	1-127	0x381-0x3FF	0x1802										
RPDO3	1000	1-127	0x401-0x47F	0x1402										
TPDO4	1001	1-127	0x481-0x4FF	0x1803										
RPDO4	1010	1-127	0x501-0x57F	0x1403										
Default SDO (tx)	1011	1-127	0x581-0x5FF	0x1200										
Default SDO (rx)	1100	1-127	0x601-0x67F	0x1200										
NMT Error Control	1110	1-127	0x701-0x77F	0x1016, 0x1017										


E.1.4 CANopen Communication Protocol

It has services as follows:

- NMT (Network Management Object)
- SDO (Service Data Object)
- PDO (Process Data Object)
- EMCY (Emergency Object)

E.1.4.1 NMT (Network Management Object)

The Network Management (NMT) follows a Master/Slave structure for executing NMT service. Only one NMT master is in a network, and other nodes are regarded as slaves. All CANopen nodes have a present NMT state, and NMT master can control the state of the slave nodes. The state diagram of a node are shown as follows:



(1) After power is applied, it is auto in initialization state

(2) Enter pre-operational state automatically

(3) (6) Start remote node

(4) (7) Enter pre-operational state

(5) (8) Stop remote node

(9) (10) (11) Reset node


(12) (13) (14) Reset communication

(15) Enter reset application state automatically

(16) Enter reset communication state automatically

	Initializing	Pre-Operational	Operational	Stopped
PDO			0	
SDO		0	0	
SYNC		0	0	
Time Stamp		0	0	
EMERG		0	0	
Boot-up	0			
NMT		0	0	0

NMT Protocol is shown as follows:



Cs

Value	Definition
1	Start
2	Stop
128	Enter Pre-Operational
129	Reset Node
130	Reset Communication

E.1.4.2 SDO (Service Data Object)

SDO is used to access the Object Dictionary in every CANopen node by Client/Server model. One SDO has two COB-ID (request SDO and response SDO) to upload or download data between two nodes. No data limit for SDOs to transfer data. But it needs to transfer by segment when data exceeds 4 bytes with an end signal in the last segment.

The Object Dictionary (OD) is a group of objects in CANopen node. Every node has an OD in the system, and OD contains all parameters describing the device and its network behavior. The access path of OD is the index and sub-index, each object has a unique index in OD, and has sub-index if necessary.

The request and response frame structure of SDO communication is shown as follows:

				D	ata	0				Data	Data	Data	Data	Data	Data	Data
T.//p.o										1	2	3	4	5	6	7
Туре		7	6	5	4	3	2	1	0	Index	Index	Index	Data	Data	Data	Data
		com	ma						L	Н	Sub	LL	LH	HL	HH	
Initiate Domain	Client	0	0	1	-	١	1	Ε	S							
Download	Server	0	1	1	-	-	-	-	-							
Initiate Domain	Client	0	1	0	-	-	-	-	-							
Upload	Server	0	1	0	-	N	1	Е	S							
Abort Domain	Client	1	0	0	-	-	-	-	-							
Transfer	Server	1	0	0	-	-	-	-	-							

N: Bytes not use

E: normal(0)/expedited(1)

S: size indicated

E.1.4.3 PDO (Process Data Object)

PDO communication can be described by the producer/consumer model. Each node of the network will listen to the messages of the transmission node and distinguish if the message has to be processed or not after receiving the message. PDO can be transmitted from one device to one another device or to many other devices. Every PDO has two PDO services: a TxPDO and a RxPDO. PDOs are transmitted in a non-confirmed mode.

PDO Transmission type is defined in the PDO communication parameter index (1400h for the 1st RxPDO or 1800h for the 1st TxPDO), and all transmission types are listed in the following table:

Type Number	PDO							
Type Itamber	Cyclic	Acyclic	Synchronous	Asynchronous	RTR only			
0		0	0					
1-240	0		0					
241-251		Reserved						
252			0		0			
253				0	0			
254				0				
255				0				

Type number 1-240 indicates the number of SYNC message between two PDO transmissions.

Type number 252 indicates the data is updated (but not sent) immediately after receiving SYNC.

Type number 253 indicates the data is updated immediately after receiving RTR.

Type number 254: Delta CANopen doesn't support this transmission format.

Type number 255 indicates the data is asynchronous transmission.

All PDO transmission data must be mapped to index via Object Dictionary.

Example:

Master transmits PDO data to Slave



PDO1 data value Data 0, Data 1, Data 2, Data 3, Data 4, Data 5, Data 6, Data 7, 0x11, 0x22, 0x33, 0x44, 0x55, 0x66, 0x77, 0x88,

	Index	Sub	Definition	Value	R/W	Size
	0x1600	0	0. Number	1	R/W	U8
'	0x1600	1	1. Mapped Object	0x604000 <u>10</u>	R/W	U32
PDO1 Map	0x1600	2	2. Mapped Object	0	R/W	U32
	0x1600	3	3. Mapped Object	\ 0	R/W	U32
	0x1600	4	4. Mapped Object	\ 0	R/W\	U32
				\		
0x60400010	0x6040	0	0. Control word	0x2211	R/W	▼U16 (2 Bytes)

Slave returns message to Master PDO1



PDO1 data value Data 0, Data 1, Data 2, Data 3, Data 4, Data 5, Data 6, Data 7, 0xF3, 0x00,

	Index	Sub	Definition	Value	R/W	Size
	0x1A00	4	0. Number	1	R/W	U8
	0x1A00	1	1. Mapped Object	0x604100 <u>10</u>	R/W	U32
PDO1 Map	0x1A00	2	2. Mapped Object	0	R/W	U32
	0x1A00	3	3. Mapped Object	0	R/W	U32
	0x1A00	4	4. Mapped Object	0	R/W	\ U32
	0x6041	0	Status Word	0xF3	R/W	U16

E.1.4.4 EMCY (Emergency Object)

Emergency objects are triggered when hardware failure occurs for a warning interrupt. The data format of a emergency object is a 8 bytes data as shown in the following:

Byte	0	1	2	3	4	5	6	7
Content		gency Error Code	Error register (Object 1001H)	Manu	facturer	speci	fic Erro	or Field

Definition of Emergency Object:

D: 1	Controller	geney object.	CANopen	CANopen Error
Display	Error Code	Description	Error Code	Register (bit 0~7)
ос	0001H	Over current	2130H	1
00	0002H	Over voltage	3210H	2
oX:	0003H	Overheating	4310H	3
οĹ	0005H	Overload	2310H	1
ol !	0006H	Overload 1	2310H	1
013	0007H	Overload 2	2310H	1
8.5	0008H	External Fault	9000H	5
oc 8	0009H	Over-current during acceleration	2310H	1
ocd	000AH	Over-current during deceleration	2310H	1
000	000BH	Over-current during constant speed operation	2310H	1
SFF	000CH	Ground fault	2240H	1
Lu	000DH	Lower than standard voltage	3220H	2
PHL	000EH	Phase Loss	3130H	2
66	000FH	External Base Block	9000H	5
codE	0011H	Software protection failure	6320H	5
c F 1.0	0013H	Internal EEPROM can not be programmed	5530H	5
c F 2.0	0014H	Internal EEPROM can not be read	5530H	5
HPF :	0015H	CC (current clamp)	5000H	5
XPF2	0016H	OV hardware error	5000H	2
XPF3	0017H	GFF hardware error	5000H	2
XPFY	0018H	OC hardware error	5000H	1
c F 3.0	0019H	U-phase error	2300H	1
c F 3. 1	001AH	V-phase error	2300H	1
c F 3.2	001BH	W-phase error	2300H	1
c F 3.3	001CH	OV or LV	3210H	2
c F 3.4	001DH	Temperature sensor error	4310H	3
cF ! !	001FH	Internal EEPROM can not be programmed	5530H	5

Display	Controller Error Code	Description	CANopen Error Code	CANopen Error Register (bit 0~7)
c F 2. 1	0020H	Internal EEPROM can not be read	5530H	5
88	0021H	Analog signal error	FF00H	7
P & { !	0023H	Motor overheat protection	7120H	5
P58r	0024H	PG signal error	7300H	7
c P 10	0029H	Communication time-out error on the control board or power board	7500H	4
886	0029H	dEb error	3320H	2
861	002AH	ACL (Abnormal Communication Loop)	7500H	4

Definition of Index:

Index	Sub	Definition	Factory Setting	R/W	Size	Unit	NOTE
0x1000	0	Abort connection option code	0x00010192	RO	U32		
0x1001	0	Error register	0	RO	U8		
0.4005	0	COB-ID SYNC		DW	1100		
0x1005	0	message	0x80	RW	U32		
0x1006	0	Communication cycle period	0	RW	U32	us	500us~15000us
0x1008	0	Manufacturer device name	0	RO	U32		
0x1009	0	Manufacturer hardware version	0	RO	U32		
0x100A	0	Manufacturer software version	0	RO	U32		
0x100C	0	Guarding time	0	RW	U16	ms	0x80 + node 1
0x100D	0	Guarding factor	0	RW	U8		
0x1014	0	COB-ID emergency	0x0000080 +Node-ID	RO	U32		
0x1015	0	Inhibit time EMCY	0	RW	U16	100us	It is set to be multiple of 10.
	0	Number	0x1	RO	U8		
0x1016	1	Consumer heartbeat time	0x0	RW	U32	1ms	Heartbeat time can be used when Guarding time is invalid.
0x1017	0	Producer heartbeat time	0x0	RW	U16	1ms	Heartbeat time can be used when Guarding time is invalid.
	0	Number	0x3	RO	U8		
	1	Vender ID	0x000001DD	RO	U32		
0x1018	2	Product code	0x00002600 +model	RO	U32		
	3	Revision	0x00010000	RO	U32		
	0	Server SDO Parameter	2	RO	U8		
0x1200	1	COB-ID Client -> Server	0x0000600+ Node-ID	RO	U32		
	2	COB-ID Client <- Server	0x0000580+ Node-ID	RO	U32		
	0	Number	2	RO	U8		
	1	COB-ID used by PDO	0x00000200 +Node-ID	RW	U32		
0x1400	2	Transmission Type	5	RW	U8		00:Acyclic & Synchronous 01~240:Cyclic & Synchronous 255: Asynchronous
0x1401	0	Number	2	RO	U8		

Index	Sub	Definition	Factory Setting	R/W	Size	Unit	NOTE
	1	COB-ID used by PDO	0x80000300 +Node-ID	RW	U32		
	2	Transmission Type	5	RW	U8		00:Acyclic & Synchronous 01~240:Cyclic & Synchronous 255: Asynchronous
	0	Number	2	RW	U8		
	1	1.Mapped Object	0x60400010	RW	U32		
0x1600	2	2.Mapped Object	0x60420020	RW	U32		
	3	3.Mapped Object	0	RW	U32		
	4	4.Mapped Object	0	RW	U32		
	0	Number	0	RW	U8		
	1	1.Mapped Object	0	RW	U32		
0x1601	2	2.Mapped Object	0	RW	U32		
	3	3.Mapped Object	0	RW	U32		
	4	4.Mapped Object	0	RW	U32		
	0	Number	5	RO	U8		
	1	COB-ID used by PDO	0x00000180 +Node-ID	RW	U32		
0x1800	2	Transmission Type	5	RW	U8		00:Acyclic & Synchrouous 01~240:Cyclic & Synchrouous 253: Remote function 255: Asynchronous
	3	Inhibit time	0	RW	U16	100us	It is set to be multiple of 10.
	4	Reserved	3	RW	U8		Reserved
	5	Event timer	0	RW	U16	1ms	
	0	Number	5	RO	U8		
	1	COB-ID used by PDO	0x80000280 +Node-ID	RW	U32		
0x1801	2	Transmission Type	5	RW	U8		00:Acyclic & Synchrouous 01~240:Cyclic & Synchrouous 253: Remote function 255: Asynchronous
	3	Inhibit time	0	RW		100us	It is set to be multiple of 10.
	4	Reserved	3	RW	U8		
	5	Event timer	0	RW	U16	1ms	
	0	Number	2	RW	U8		
	1	1.Mapped Object	0x60410010	RW	U32		
0x1A00	2	2.Mapped Object	0x60430010	RW	U32		
	3	3.Mapped Object	0	RW	U32		
	4	4.Mapped Object	0	RW	U32		

Index	Sub	Definition	Factory Setting	R/W	Size	Unit	NOTE
	0	Number	0	RW	U8		
	1	1.Mapped Object	0	RW	U32		
0x1A01	2	2.Mapped Object	0	RW	U32		
	3	3.Mapped Object	0	RW	U32		
	4	4.Mapped Object	0	RW	U32		

Delta Definition Part:

Index	Sub	Definition	Factory Setting	R/W	Size	Unit		NOTE
	0	Number	3	RO	U8			
								00B : No function
							bit 0 ~ 1	01B : Stop
							Dit 0 · · ·	10B : Start
								11B: JOG Start
					U16		Bit2~3	Reserved
							Bit4~5	00B: No function
	1	Control word	0	RW				01B : Forward Command
2020								10B : Reverse Command
								11B: Direction Change Command
							Bit6~7	00B: 1st step accel / decal
								01B : 2nd step accel / decel
							Bit8~15	Reserved
	2	vl target velocity	0	RW	U16	Hz		
							Bit0	1 : E.F. ON
	3	Other trigger	0	RW	U16		Bit1	1 : Reset Command
							Bit2~15	Reserved
	0	Number	0xD	RO	U8			
	1	Error code	0	RO	U16			
0x2021	_							00B: Drive stop
	2	Drive Status	0	RO	U16		Bit 0~1	01B : Drive decelerates stopping

							10B : Drive operation waits for frequency command
							11B: Drive operates
						Bit 2	1 : JOG Command
							00B : Drive Forward
						Bit 3~4	01B: Drive from reverse to forward
						Ы≀ 3~4	10B: Drive from forward to reverse
							11B: Drive Reverse
						Bit 5~7	Reserved
						Bit 8	1 : Main frequency source from the communication interface
						Bit 9	1 : Main frequency source from the analog signal input
						Bit 10	1 : Operation command from the communication interface
						Bit 11~15	Reserved
3	Frequency Command (F)	0	RO	U16	Hz		
4	Output Frequency (H)	0	RO	U16			
5	Input Current (AXX.X)	0	RO	U16			
6	Reserved	0	RO	U16			
7	Reserved	0	RO	U16			
8	Reserved	0	RO	U16			
9	DC-BUS Voltage (uXXX.X)	0	RO	U16			

А	Input Voltage (EXXX.X)	0	RO	U16		
В	IGBT Temperature (°C)	0	RO	U16		
С	User Definition (Low word)	0	RO	U16		
D	User Definition (High word)	0	RO	U16		

DS402 Part:

D3402	ı art.							
Index	Sub	Definition	Factory Setting	RW	Size	Unit	Мар	NOTE
0x6007	0	Abort connection option code	2	RW	S16		Yes	0: No action 2: Disable Voltage 3: Quick stop
0x603F	0	Error code	0	RO	U16		Yes	o. Quion stop
0x6040	0	Control word	0	RW			Yes	bit 0 ~ 3: switch status bit 4: rfg enable bit 5: rfg unlock bit 6: rfg use ref bit 7: Fault reset
0x6041	0	Status word	0	RO	U16		Yes	Bit0 Ready to switch on Bit1 Switched on Bit2 Operation enabled Bit3 Fault Bit4 Voltage enabled Bit5 Quick stop Bit6 Switch on disabled Bit7 Warning Bit8 Desired frequency arrived Bit9 Remote Bit10 Target reached Bit11 Internal limit active Bit12 - 13 Bit14 - 15
0x6042	0	vl target velocity	0	RW	S16	rpm	Yes	
0x6043	0	vl velocity demand	0	RO	S16	rpm	Yes	
0x604F	0	vl ramp function time	10000	RW	U32	1ms	Yes	If Pr.01.19 is set to 0.1, the unit must be 100ms and can't be set to 0.
0x6050	0	vl slow down time	10000	RW	U32	1ms	Yes	If Pr.01.19 is set to 0.1, the unit must be 100ms and can't be set to 0.
0x6051	0	vI quick stop time	1000	RW	U32	1ms	Yes	If Pr.01.19 is set to 0.1, the unit must be 100ms and can't be set to 0.
0x605A	0	Quick stop option code	2	RW	S16	1ms	Yes	O: disable drive function 1:slow down on slow down ramp 2: slow down on quick stop ramp (2 nd decel. time) 5 slow down on slow down ramp and stay in QUICK STOP 6 slow down on quick stop ramp and stay in QUICK STOP
0x6060	0	Mode of operation	2	RO	U8		Yes	Speed mode
0x6061	0	Mode of operation display	2	RO	U8		Yes	

Remote I/O Part:

Index	Sub	Define	Default	R/W	Size	Remark		
	0h	Number	DFh	R	U8			
						Bit 0	MI1	
						Bit 1	MI2	
						Bit 2	MI3	
						Bit 3	MI4	
						Bit 4	MI5	
						Bit 5	MI6	
						Bit 6	MI7(External card)	
						Bit 7	MI8(External card)	
						Bit 8	MI9(External card)	
						Bit 9		
	1h	MI Status	0x00	R	U16	Bit		
	111	Wii Otatas	OXOO	'`	010	10		
						Bit		
						11		
						Bit		
						12		
						Bit		
						13		
						Bit		
						14		
						Bit		
						15		
000011	2h~40h	Reserved	0x00	R	U16	D '' 0	577	
2026H						Bit 0	RY	
						Bit 1	MO1	
							RY2/MO2(External card)	
							RY3/MO3(External card)	
							RY4/MO4(External card)	
						Bit 5		
						Bit 6		
						Bit 7		
						Bit 8		
						Bit 9 Bit		
	41h	MO Control	0x00	RW	U16	10		
						Bit		
						11		
						Bit		
						12		
						Bit		
						13		
						Bit		
						14		
						Bit		
						15		
	42h~60h	Reserved	0x00	R	U16			
	61h	AVI	0x00	R	U16		0.00 ~100.00%	
	62h	ACI	0x00	R	U16		0.00 ~100.00%	

Index	Sub	Define	Default	R/W	Size	Remark
	63h	VR	0x00	R	U16	0.00 ~100.00%
	64h	AI1/AUI1	0x00	R	U16	0.00 ~100.00%
	65h	Al2	0x00	R	U16	0.00 ~100.00%
	66h~A0h	Reserved	0x00	R	U16	
	A1h	AFM1	0x00	RW	U16	0.00 ~100.00%
	A2h	AO1	0x00	RW	U16	0.00 ~100.00%
	A3h	AO2	0x00	RW	U16	0.00 ~100.00%
	A4h~DFh	Reserved				

E.2 CANopen Communication Interface Description

E-2-1 Select control mode

There are two kinds of control mode for CANOpen, when Pr.09.24 sets to 1(default factory settings), the control mode is using DS402 standard; when Pr.09.24 sets to 0, the control mode is adopting Delta standard.

E-2-2 Control mode use DS402 standard

To control the AC motor drive by CANopen, please set parameters by the following steps:

- 1. Operation source setting: set Pr.02.01 to 5 and select CANopen communication mode.
- 2. Frequency source setting: set Pr.02.00 to 5 and select via CANopen settings.
- CANopen station setting: set CANopen communication address (1-127) via Pr.09.20 settings.
- CANopen baud rate setting: set Pr.09.21 for CANopen baud rate (items: 1M, 500K, 250K, 125K and 50K).
- CANopen control decoding setting: set Pr.09.24 to 1 and select DS402 specification for decoding.
- 6. Set multiple input functions to quick stop when necessary: Set Pr.04.05 ~ 04.08 or Pr.11.06 ~ 11.11 to 23.
- 7. According to DS402 specification for motion control, CANopen provide the speed control mode. The control flow has multiple statuses which can switch between "Start" to "Quick Stop". If you want to know the current status, you can get it by "Status Word". The status switch mode needs to go through the "Control Word" of PDO with external terminals.
- 8. To switch the operation mode of drive (Operation Enable, via NMT characters). The switch flow is controlling by word "0x6040" bit 0 ~bit3 and bit7 with status word "0x6041".

For example:

If there is a hardware Quick stop function,

- A. Connect the Quick stop signal
- B. Set Index 0x6040 = 0x7E
- C. Set Index 0x6040 = 0x7F, now the drive status is operating.
- D. Set Index 0x6042 = 1500 (rpm), the default pole number is 4,frequency is 1500(120/4)=50Hz, and pole settings is on $5-04(1^{st} \text{ motor}) \cdot 5-16(2^{nd} \text{ motor})$.

$$\text{Motor speed formula}: \ n = f \times \frac{120}{p}$$

rpm=(120*frequency)/pole n: rotation speed (rpm) (rounds/minute)

p: motor's pole number (Pole)

f: rotation frequency (Hz)


Example 1: Set forward 30 Hz, pole number is 4 (120*30)/4 = 900rpm

Example 2 : Set reverse 20 Hz, pole number is 6 (120*15)/6 = 300rpm

And 300 = 0x012C the plus or minus sign is defining as bit15

So that Index 6042 = -300 = (300' + 1) = 0x012C' + 1 = 0xFED3 + 1 = 0xFED4

Following is the flow chart for status switch:



<State switching flowchart>

9. According to DSP-402 standard for motion control, by using control word 0x6040 bit 4 ~bit6 to make the drive is running or not, and the definition is as follows:

bit 6	bit 5	bit 4	
Ramp function reference	Ramp function disable	Ramp function enable	Result
0	0	0	STOP
1	0	0	STOP
0	1	0	STOP
1	1	0	STOP
0	0	1	STOP
1	0	1	LOCK in current frequency
0	1	1	STOP
1	1	1	RUN

10. Please refer to the state switching flowchart for status word 0x6041 bit 0 ~ bit 6 ,and bit 7 is defining as warn, bit 9 is always 1 , bit 10 is defining as desired frequency arrived ,bit
11 is defining as output exceeds the maximum frequency.

E-2-3 Control mode use Delta standard

- 1. Operation source setting: set Pr.02.01 to 5 and select CANopen communication mode.
- 2. Frequency source setting: set Pr.02.00 to 5 and select via CANopen settings.
- CANopen station setting: set CANopen communication address (1-127) via Pr.09.20 settings.
- 4. CANopen baud rate setting: set Pr.09.21 for CANopen baud rate (items: 1M, 500K, 250K, 125K and 50K).
- 5. CANopen control decoding setting: set Pr.09.24 to 0 and select Delta's specification for decoding.
- 6. For Index 2020.01, if you give command 0002H, it will run; if you give command 0001H, it will stop. If you give command 1000 for Index 2020.02, drive frequency is 10.00Hz; related usage can refer to Index 2020 and 2021 definition.

- F.1 Maintenance and Inspections
- F.2 Greasy Dirt Problem
- F.3 Fiber Dust Problem
- F.4 Erosion Problem
- F.5 Industrial Dust Problem
- F.6 Wiring and Installation Problem
- F.7 Multi-function Input/Output Terminals Problem

The AC motor drive has a comprehensive fault diagnostic system that includes several different alarms and fault messages. Once a fault is detected, the corresponding protective functions will be activated. The following faults are displayed as shown on the AC motor drive digital keypad display. The six most recent faults can be read from the digital keypad or communication.

The AC motor drive is made up by numerous components, such as electronic components, including IC, resistor, capacity, transistor, and cooling fan, relay, etc. These components can't be used permanently. They have limited-life even under normal operation. Preventive maintenance is required to operate this AC motor drive in its optimal condition, and to ensure a long life.

Check your AC motor drive regularly to ensure there are no abnormalities during operation and follows the precautions:



- ☑ Wait 5 seconds after a fault has been cleared before performing reset via keypad of input terminal.
- When the power is off after 5 minutes for \leq 22kW models and 10 minutes for \geq 30kW models, please confirm that the capacitors have fully discharged by measuring the voltage between + and -. The voltage between + and should be less than 25VDC.
- Only qualified personnel can install, wire and maintain drives. Please take off any metal objects, such as watches and rings, before operation. And only insulated tools are allowed.
- ✓ Never reassemble internal components or wiring.
- Make sure that installation environment comply with regulations without abnormal noise, vibration and smell.

F.1 Maintenance and Inspections

Before the check-up, always turn off the AC input power and remove the cover. Wait at least 10 minutes after all display lamps have gone out, and then confirm that the capacitors have fully discharged by measuring the voltage between DC+ and DC-. The voltage between DC+ and DC-should be less than 25VDC.

Ambient environment

		Maintenance Period			
Check Items	Methods and Criterion	Daily	Half Year	One Year	
Check the ambient temperature, humidity, vibration and see if there are any dust, gas, oil or water drops	Visual inspection and measurement with equipment with standard specification	0			
If there are any dangerous objects	Visual inspection	0			

Voltage

		Maintenance Period			
Check Items	Methods and Criterion	Daily	Half	One	
		Daily	Year	Year	
Check if the voltage of main circuit	Measure with multimeter				
and control circuit is correct	with standard specification				

Digital Keypad Display

		Maintenance Period			
Check Items	Methods and Criterion	Daily	Half	One	
		Daily	Year	Year	
Is the display clear for reading	Visual inspection				
Any missing characters	Visual inspection	0			

Mechanical parts

		Maintenance Period			
Check Items	Methods and Criterion	Daily	Half	One	
			Year	Year	
If there is any abnormal sound or	Visual and aural				
vibration	inspection				
If there are any loose screws	Tighten the screws		\bigcirc		
If any part is deformed or damaged	Visual inspection				
If there is any color change by overheating	Visual inspection				
If there is any dust or dirt	Visual inspection		0		

Main circuit

		Maintenance Period			
Check Items	Methods and Criterion	Daily	Half Year	One Year	
If there are any loose or missing screws	Tighten or replace the screw	0			
If machine or insulator is deformed, cracked, damaged or with color change due to overheating or ageing	Visual inspection NOTE: Please ignore the color change of copper plate		0		
If there is any dust or dirt	Visual inspection		0		

Terminals and wiring of main circuit

		Maintenance Period		
Check Items	Methods and Criterion	Daily	Half Year	One Year
If the terminal or the plate is color change or deformation due to overheat	Visual inspection		0	
If the insulator of wiring is damaged or color change	Visual inspection		0	
If there is any damage	Visual inspection	0		

DC capacity of main circuit

		Maintenance Period		
Check Items	Methods and Criterion	Daily	Half Year	One Year
If there is any leak of liquid, color change, crack or deformation	Visual inspection	0		
If the safety valve is not removed? If valve is inflated?	Visual inspection	0		
Measure static capacity when required		0		

Resistor of main circuit

		Maintenance Period			
Check Items	Methods and Criterion	Daily	Half Year	One Year	
If there is any peculiar smell or insulator cracks due to overheat	Visual inspection, smell	0			
If there is any disconnection	Visual inspection	0			
If connection is damaged?	Measure with multimeter with standard specification	0			

Transformer and reactor of main circuit

		Maintenance Period		
Check Items	Methods and Criterion	Daily	Half Year	One Year
If there is any abnormal vibration or peculiar smell	Visual, aural inspection and smell	0		

Magnetic contactor and relay of main circuit

		Maintenance Perio			
Check Items	Methods and Criterion	Daily	Half	One	
		•	Year	Year	
I IT There are any loose screws	Visual and aural				
	inspection				
If the contact works correctly	Visual inspection	0			

Printed circuit board and connector of main circuit

		Maintenance Period		
Check Items	Methods and Criterion	Daily	Half	One
		Daily	Year	Year
If there are any loose scrows and	Tighten the screws and			
If there are any loose screws and connectors	press the connectors			
Connectors	firmly in place.			
If there is any peculiar smell and color	Visual and smell			
change	inspection	inspection		
If there is any crack, damage,	Visual inspection			
deformation or corrosion	Visual Inspection			
If there is any liquid is leaked or	Visual inspection			
deformation in capacity	v isuai irispection			

Cooling fan of cooling system

		Maintenance Period		
Check Items	Methods and Criterion	Daily	Half	One
			Year	Year
	Visual, aural inspection			
If there is any abnormal sound or vibration	and turn the fan with			
	hand (turn off the power			
	before operation) to see if			
	it rotates smoothly			
If there is any loose screw	Tighten the screw			
If there is any color change due to overheat	Change fan		0	

Ventilation channel of cooling system

		Maintenance Period		
Check Items	Methods and Criterion	Daily	Half Year	One Year
If there is any obstruction in the heat sink, air intake or air outlet	Visual inspection		0	

The lifetime of components

		Replace Period			
Check Items	Methods and Criterion	5	8	10	
		years	years	years	
Cooling Fan	Visual inspection		0		
Main Circuit-Capacitor	Visual inspection			0	



Use neutral fabrics to clean the cooling fan and use dust cleaner to remove dust when necessary.

F.2 Greasy Dirt Problem

Serious greasy dirt problems generally occur in processing industries such as machine tools, punching machines and so on. Please be aware of the possible damages that greasy oil may cause to your drive:

- 1. Electronic components that silt up with greasy oil may cause the drive to burn out or even explode.
- 2. Most greasy dirt contains corrosive substances that may damage the drive.

Solution:

Install the AC motor drive in a standard cabinet to keep it away from dirt. Clean and remove greasy dirt regularly to prevent damage of the drive.





F.3 Fiber Dust Problem

Serious fiber dust problems generally occur in the textile industry. Please be aware of the possible damages that fiber may cause to your drives:

- 1. Fiber that accumulates or adheres to the fans will lead to poor ventilation and cause overheating problems.
- 2. Plant environments in the textile industry have higher degrees of humidity that may cause the drive to burn out, become damaged or explode due to wet fiber dust adhering to the devices.

Solution:

Install the AC motor drive in a standard cabinet to keep it away from fiber dust. Clean and remove fiber dust regularly to prevent damage to the drive.



F.4 Erosion Problem


Erosion problems may occur if any fluids flow into the drives. Please be aware of the damages that erosion may cause to your drive.

1. Erosion of internal components may cause the drive to malfunction and possibility to explode.

Solution:

Install the AC motor drive in a standard cabinet to keep it away from fluids. Clean the drive

regularly to prevent erosion.




F.5 Industrial Dust Problem

Serious industrial dust pollution frequently occurs in stone processing plants, flour mills, cement plants, and so on. Please be aware of the possible damage that industrial dust may cause to your drives:

- 1. Dust accumulating on electronic components may cause overheating problem and shorten the service life of the drive.
- 2. Conductive dust may damage the circuit board and may even cause the drive to explode.

Solution:

Install the AC motor drive in a standard cabinet and cover the drive with a dust cover. Clean







F.6 Wiring & Installation Problem

When wiring the drive, the most common problem is wrong wire installation or poor wiring. Please be aware of the possible damages that poor wiring may cause to your drives:

- 1. Screws are not fully fastened. Occurrence of sparks as impedance increases.
- 2. If a customer has opened the drive and modified the internal circuit board, the internal components may have been damaged.

Solution:

Ensure all screws are fastened when installing the AC motor drive. If the AC motor drive functions abnormally, send it back to the repair station. DO NOT try to reassemble the internal components or wire.



F.7 Multi-function Input/ Output Terminal Problem:

Multi-function input/output terminal errors are generally caused by over usage of terminals and not following specifications. Please be aware of the possible damages that errors on multi-function input/output terminals may cause to your drives:

1. Input/output circuit may burns out when the terminal usage exceeds its limit. **Solution:**

Refer to the user manual for multi-function input output terminals usage and follow the specified voltage and current. DO NOT exceed the specification limits.

